

The GNU linker

ld
(GNU Binutils)
Version 2.23.2

Steve Chamberlain
Ian Lance Taylor

Red Hat Inc
nickc@redhat.com, doc@redhat.com
The GNU linker
Edited by Jeffrey Osier (jeffrey@cygnus.com)

Copyright © 1991, 1992, 1993, 1994, 1995, 1996, 1997, 1998, 1999, 2000, 2001, 2002, 2003, 2004, 2005, 2006, 2007, 2008, 2009 Free Software Foundation, Inc.

Permission is granted to copy, distribute and/or modify this document under the terms of the GNU Free Documentation License, Version 1.3 or any later version published by the Free Software Foundation; with no Invariant Sections, with no Front-Cover Texts, and with no Back-Cover Texts. A copy of the license is included in the section entitled “GNU Free Documentation License”.

Table of Contents

1	Overview	1
2	Invocation	3
2.1	Command Line Options	3
2.1.1	Options Specific to i386 PE Targets	28
2.1.2	Options specific to C6X uClinux targets	35
2.1.3	Options specific to Motorola 68HC11 and 68HC12 targets	36
2.1.4	Options specific to Motorola 68K target	36
2.2	Environment Variables	36
3	Linker Scripts	39
3.1	Basic Linker Script Concepts	39
3.2	Linker Script Format	40
3.3	Simple Linker Script Example	40
3.4	Simple Linker Script Commands	41
3.4.1	Setting the Entry Point	41
3.4.2	Commands Dealing with Files	41
3.4.3	Commands Dealing with Object File Formats	43
3.4.4	Assign alias names to memory regions	43
3.4.5	Other Linker Script Commands	46
3.5	Assigning Values to Symbols	47
3.5.1	Simple Assignments	47
3.5.2	HIDDEN	48
3.5.3	PROVIDE	48
3.5.4	PROVIDE_HIDDEN	49
3.5.5	Source Code Reference	49
3.6	SECTIONS Command	50
3.6.1	Output Section Description	51
3.6.2	Output Section Name	51
3.6.3	Output Section Address	51
3.6.4	Input Section Description	52
3.6.4.1	Input Section Basics	52
3.6.4.2	Input Section Wildcard Patterns	54
3.6.4.3	Input Section for Common Symbols	55
3.6.4.4	Input Section and Garbage Collection	56
3.6.4.5	Input Section Example	56
3.6.5	Output Section Data	56
3.6.6	Output Section Keywords	57
3.6.7	Output Section Discarding	58
3.6.8	Output Section Attributes	59
3.6.8.1	Output Section Type	59

3.6.8.2	Output Section LMA	59
3.6.8.3	Forced Output Alignment	60
3.6.8.4	Forced Input Alignment	60
3.6.8.5	Output Section Constraint	61
3.6.8.6	Output Section Region	61
3.6.8.7	Output Section Phdr	61
3.6.8.8	Output Section Fill	61
3.6.9	Overlay Description	61
3.7	MEMORY Command	63
3.8	PHDRS Command	64
3.9	VERSION Command	66
3.10	Expressions in Linker Scripts	69
3.10.1	Constants	69
3.10.2	Symbolic Constants	70
3.10.3	Symbol Names	70
3.10.4	Orphan Sections	70
3.10.5	The Location Counter	70
3.10.6	Operators	72
3.10.7	Evaluation	73
3.10.8	The Section of an Expression	73
3.10.9	Builtin Functions	75
3.11	Implicit Linker Scripts	78
4	Machine Dependent Features	79
4.1	ld and the H8/300	79
4.2	ld and the Intel 960 Family	79
4.3	ld and the Motorola 68HC11 and 68HC12 families	80
4.3.1	Linker Relaxation	80
4.3.2	Trampoline Generation	80
4.4	ld and the ARM family	80
4.5	ld and HPPA 32-bit ELF Support	83
4.6	ld and the Motorola 68K family	83
4.7	ld and MMIX	84
4.8	ld and MSP430	84
4.9	ld and PowerPC 32-bit ELF Support	84
4.10	ld and PowerPC64 64-bit ELF Support	85
4.11	ld and SPU ELF Support	87
4.12	ld's Support for Various TI COFF Versions	88
4.13	ld and WIN32 (cygwin/mingw)	88
4.14	ld and Xtensa Processors	96
5	BFD	97
5.1	How It Works: An Outline of BFD	97
5.1.1	Information Loss	97
5.1.2	The BFD canonical object-file format	98

6	Reporting Bugs	101
6.1	Have You Found a Bug?	101
6.2	How to Report Bugs	101
Appendix A	MRI Compatible Script Files ..	105
Appendix B	GNU Free Documentation License	
	107
LD Index	115

1 Overview

`ld` combines a number of object and archive files, relocates their data and ties up symbol references. Usually the last step in compiling a program is to run `ld`.

`ld` accepts Linker Command Language files written in a superset of AT&T's Link Editor Command Language syntax, to provide explicit and total control over the linking process.

This version of `ld` uses the general purpose BFD libraries to operate on object files. This allows `ld` to read, combine, and write object files in many different formats—for example, COFF or `a.out`. Different formats may be linked together to produce any available kind of object file. See [Chapter 5 \[BFD\]](#), [page 97](#), for more information.

Aside from its flexibility, the GNU linker is more helpful than other linkers in providing diagnostic information. Many linkers abandon execution immediately upon encountering an error; whenever possible, `ld` continues executing, allowing you to identify other errors (or, in some cases, to get an output file in spite of the error).

2 Invocation

The GNU linker `ld` is meant to cover a broad range of situations, and to be as compatible as possible with other linkers. As a result, you have many choices to control its behavior.

2.1 Command Line Options

The linker supports a plethora of command-line options, but in actual practice few of them are used in any particular context. For instance, a frequent use of `ld` is to link standard Unix object files on a standard, supported Unix system. On such a system, to link a file `hello.o`:

```
ld -o output /lib/crt0.o hello.o -lc
```

This tells `ld` to produce a file called `output` as the result of linking the file `/lib/crt0.o` with `hello.o` and the library `libc.a`, which will come from the standard search directories. (See the discussion of the `-l` option below.)

Some of the command-line options to `ld` may be specified at any point in the command line. However, options which refer to files, such as `-l` or `-T`, cause the file to be read at the point at which the option appears in the command line, relative to the object files and other file options. Repeating non-file options with a different argument will either have no further effect, or override prior occurrences (those further to the left on the command line) of that option. Options which may be meaningfully specified more than once are noted in the descriptions below.

Non-option arguments are object files or archives which are to be linked together. They may follow, precede, or be mixed in with command-line options, except that an object file argument may not be placed between an option and its argument.

Usually the linker is invoked with at least one object file, but you can specify other forms of binary input files using `-l`, `-R`, and the script command language. If *no* binary input files at all are specified, the linker does not produce any output, and issues the message ‘No input files’.

If the linker cannot recognize the format of an object file, it will assume that it is a linker script. A script specified in this way augments the main linker script used for the link (either the default linker script or the one specified by using `-T`). This feature permits the linker to link against a file which appears to be an object or an archive, but actually merely defines some symbol values, or uses `INPUT` or `GROUP` to load other objects. Specifying a script in this way merely augments the main linker script, with the extra commands placed after the main script; use the `-T` option to replace the default linker script entirely, but note the effect of the `INSERT` command. See [Chapter 3 \[Scripts\], page 39](#).

For options whose names are a single letter, option arguments must either follow the option letter without intervening whitespace, or be given as separate arguments immediately following the option that requires them.

For options whose names are multiple letters, either one dash or two can precede the option name; for example, `-trace-symbol` and `--trace-symbol` are equivalent. Note—there is one exception to this rule. Multiple letter options that start with a lower case ‘o’ can only be preceded by two dashes. This is to reduce confusion with the `-o` option. So for example `-omagic` sets the output file name to ‘magic’ whereas `--omagic` sets the NMAGIC flag on the output.

Arguments to multiple-letter options must either be separated from the option name by an equals sign, or be given as separate arguments immediately following the option that requires them. For example, ‘`--trace-symbol foo`’ and ‘`--trace-symbol=foo`’ are equivalent. Unique abbreviations of the names of multiple-letter options are accepted.

Note—if the linker is being invoked indirectly, via a compiler driver (e.g. ‘`gcc`’) then all the linker command line options should be prefixed by ‘`-Wl,`’ (or whatever is appropriate for the particular compiler driver) like this:

```
gcc -Wl,--start-group foo.o bar.o -Wl,--end-group
```

This is important, because otherwise the compiler driver program may silently drop the linker options, resulting in a bad link. Confusion may also arise when passing options that require values through a driver, as the use of a space between option and argument acts as a separator, and causes the driver to pass only the option to the linker and the argument to the compiler. In this case, it is simplest to use the joined forms of both single- and multiple-letter options, such as:

```
gcc foo.o bar.o -Wl,-eENTRY -Wl,-Map=a.map
```

Here is a table of the generic command line switches accepted by the GNU linker:

@file Read command-line options from *file*. The options read are inserted in place of the original @file option. If *file* does not exist, or cannot be read, then the option will be treated literally, and not removed.

Options in *file* are separated by whitespace. A whitespace character may be included in an option by surrounding the entire option in either single or double quotes. Any character (including a backslash) may be included by prefixing the character to be included with a backslash. The *file* may itself contain additional @file options; any such options will be processed recursively.

-a keyword

This option is supported for HP/UX compatibility. The *keyword* argument must be one of the strings ‘`archive`’, ‘`shared`’, or ‘`default`’. ‘`-aarchive`’ is functionally equivalent to ‘`-Bstatic`’, and the other two keywords are functionally equivalent to ‘`-Bdynamic`’. This option may be used any number of times.

--audit AUDITLIB

Adds *AUDITLIB* to the DT_AUDIT entry of the dynamic section. *AUDITLIB* is not checked for existence, nor will it use the DT_SONAME specified in the library. If specified multiple times DT_AUDIT will contain a colon separated list of audit interfaces to use. If the linker finds an object with an audit entry while searching for shared libraries, it will add a corresponding DT_DEPAUDIT entry in the output file. This option is only meaningful on ELF platforms supporting the rtld-audit interface.

-A architecture

--architecture=architecture

In the current release of `ld`, this option is useful only for the Intel 960 family of architectures. In that `ld` configuration, the *architecture* argument identifies the particular architecture in the 960 family, enabling some safeguards and modifying the archive-library search path. See [Section 4.2 \[ld and the Intel 960 family\]](#), [page 79](#), for details.

Future releases of `ld` may support similar functionality for other architecture families.

`-b input-format`

`--format=input-format`

`ld` may be configured to support more than one kind of object file. If your `ld` is configured this way, you can use the ‘`-b`’ option to specify the binary format for input object files that follow this option on the command line. Even when `ld` is configured to support alternative object formats, you don’t usually need to specify this, as `ld` should be configured to expect as a default input format the most usual format on each machine. *input-format* is a text string, the name of a particular format supported by the BFD libraries. (You can list the available binary formats with ‘`objdump -i`’.) See [Chapter 5 \[BFD\]](#), page 97.

You may want to use this option if you are linking files with an unusual binary format. You can also use ‘`-b`’ to switch formats explicitly (when linking object files of different formats), by including ‘`-b input-format`’ before each group of object files in a particular format.

The default format is taken from the environment variable `GNUTARGET`. See [Section 2.2 \[Environment\]](#), page 36. You can also define the input format from a script, using the command `TARGET`; see [Section 3.4.3 \[Format Commands\]](#), page 43.

`-c MRI-commandfile`

`--mri-script=MRI-commandfile`

For compatibility with linkers produced by MRI, `ld` accepts script files written in an alternate, restricted command language, described in [Appendix A \[MRI Compatible Script Files\]](#), page 105. Introduce MRI script files with the option ‘`-c`’; use the ‘`-T`’ option to run linker scripts written in the general-purpose `ld` scripting language. If *MRI-cmdfile* does not exist, `ld` looks for it in the directories specified by any ‘`-L`’ options.

`-d`

`-dc`

`-dp`

These three options are equivalent; multiple forms are supported for compatibility with other linkers. They assign space to common symbols even if a relocatable output file is specified (with ‘`-r`’). The script command `FORCE_COMMON_ALLOCATION` has the same effect. See [Section 3.4.5 \[Miscellaneous Commands\]](#), page 46.

`--depaudit AUDITLIB`

`-P AUDITLIB`

Adds *AUDITLIB* to the `DT_DEPAUDIT` entry of the dynamic section. *AUDITLIB* is not checked for existence, nor will it use the `DT_SONAME` specified in the library. If specified multiple times `DT_DEPAUDIT` will contain a colon separated list of audit interfaces to use. This option is only meaningful on ELF platforms supporting the `rtld-audit` interface. The `-P` option is provided for Solaris compatibility.

-e *entry*

--entry=*entry*

Use *entry* as the explicit symbol for beginning execution of your program, rather than the default entry point. If there is no symbol named *entry*, the linker will try to parse *entry* as a number, and use that as the entry address (the number will be interpreted in base 10; you may use a leading ‘0x’ for base 16, or a leading ‘0’ for base 8). See [Section 3.4.1 \[Entry Point\], page 41](#), for a discussion of defaults and other ways of specifying the entry point.

--exclude-libs *lib,lib,...*

Specifies a list of archive libraries from which symbols should not be automatically exported. The library names may be delimited by commas or colons. Specifying **--exclude-libs ALL** excludes symbols in all archive libraries from automatic export. This option is available only for the i386 PE targeted port of the linker and for ELF targeted ports. For i386 PE, symbols explicitly listed in a .def file are still exported, regardless of this option. For ELF targeted ports, symbols affected by this option will be treated as hidden.

--exclude-modules-for-implib *module,module,...*

Specifies a list of object files or archive members, from which symbols should not be automatically exported, but which should be copied wholesale into the import library being generated during the link. The module names may be delimited by commas or colons, and must match exactly the filenames used by `ld` to open the files; for archive members, this is simply the member name, but for object files the name listed must include and match precisely any path used to specify the input file on the linker’s command-line. This option is available only for the i386 PE targeted port of the linker. Symbols explicitly listed in a .def file are still exported, regardless of this option.

-E

--export-dynamic

--no-export-dynamic

When creating a dynamically linked executable, using the ‘-E’ option or the ‘**--export-dynamic**’ option causes the linker to add all symbols to the dynamic symbol table. The dynamic symbol table is the set of symbols which are visible from dynamic objects at run time.

If you do not use either of these options (or use the ‘**--no-export-dynamic**’ option to restore the default behavior), the dynamic symbol table will normally contain only those symbols which are referenced by some dynamic object mentioned in the link.

If you use `dlopen` to load a dynamic object which needs to refer back to the symbols defined by the program, rather than some other dynamic object, then you will probably need to use this option when linking the program itself.

You can also use the dynamic list to control what symbols should be added to the dynamic symbol table if the output format supports it. See the description of ‘**--dynamic-list**’.

Note that this option is specific to ELF targeted ports. PE targets support a similar function to export all symbols from a DLL or EXE; see the description of ‘`--export-all-symbols`’ below.

-EB Link big-endian objects. This affects the default output format.

-EL Link little-endian objects. This affects the default output format.

-f *name*

--auxiliary=*name*

When creating an ELF shared object, set the internal `DT_AUXILIARY` field to the specified name. This tells the dynamic linker that the symbol table of the shared object should be used as an auxiliary filter on the symbol table of the shared object *name*.

If you later link a program against this filter object, then, when you run the program, the dynamic linker will see the `DT_AUXILIARY` field. If the dynamic linker resolves any symbols from the filter object, it will first check whether there is a definition in the shared object *name*. If there is one, it will be used instead of the definition in the filter object. The shared object *name* need not exist. Thus the shared object *name* may be used to provide an alternative implementation of certain functions, perhaps for debugging or for machine specific performance.

This option may be specified more than once. The `DT_AUXILIARY` entries will be created in the order in which they appear on the command line.

-F *name*

--filter=*name*

When creating an ELF shared object, set the internal `DT_FILTER` field to the specified name. This tells the dynamic linker that the symbol table of the shared object which is being created should be used as a filter on the symbol table of the shared object *name*.

If you later link a program against this filter object, then, when you run the program, the dynamic linker will see the `DT_FILTER` field. The dynamic linker will resolve symbols according to the symbol table of the filter object as usual, but it will actually link to the definitions found in the shared object *name*. Thus the filter object can be used to select a subset of the symbols provided by the object *name*.

Some older linkers used the ‘-F’ option throughout a compilation toolchain for specifying object-file format for both input and output object files. The GNU linker uses other mechanisms for this purpose: the ‘-b’, ‘--format’, ‘--oformat’ options, the `TARGET` command in linker scripts, and the `GNUTARGET` environment variable. The GNU linker will ignore the ‘-F’ option when not creating an ELF shared object.

-fini=*name*

When creating an ELF executable or shared object, call `NAME` when the executable or shared object is unloaded, by setting `DT_FINI` to the address of the function. By default, the linker uses `_fini` as the function to call.

-g Ignored. Provided for compatibility with other tools.

-G *value*

--gpsize=*value*

Set the maximum size of objects to be optimized using the GP register to *size*. This is only meaningful for object file formats such as MIPS ECOFF which supports putting large and small objects into different sections. This is ignored for other object file formats.

-h *name*

-soname=*name*

When creating an ELF shared object, set the internal DT_SONAME field to the specified name. When an executable is linked with a shared object which has a DT_SONAME field, then when the executable is run the dynamic linker will attempt to load the shared object specified by the DT_SONAME field rather than the using the file name given to the linker.

-i Perform an incremental link (same as option ‘-r’).

-init=*name*

When creating an ELF executable or shared object, call NAME when the executable or shared object is loaded, by setting DT_INIT to the address of the function. By default, the linker uses `_init` as the function to call.

-l *namespec*

--library=*namespec*

Add the archive or object file specified by *namespec* to the list of files to link. This option may be used any number of times. If *namespec* is of the form ‘:*filename*’, ld will search the library path for a file called *filename*, otherwise it will search the library path for a file called ‘lib*namespec*.a’.

On systems which support shared libraries, ld may also search for files other than ‘lib*namespec*.a’. Specifically, on ELF and SunOS systems, ld will search a directory for a library called ‘lib*namespec*.so’ before searching for one called ‘lib*namespec*.a’. (By convention, a .so extension indicates a shared library.) Note that this behavior does not apply to ‘:*filename*’, which always specifies a file called *filename*.

The linker will search an archive only once, at the location where it is specified on the command line. If the archive defines a symbol which was undefined in some object which appeared before the archive on the command line, the linker will include the appropriate file(s) from the archive. However, an undefined symbol in an object appearing later on the command line will not cause the linker to search the archive again.

See the ‘-(’ option for a way to force the linker to search archives multiple times.

You may list the same archive multiple times on the command line.

This type of archive searching is standard for Unix linkers. However, if you are using ld on AIX, note that it is different from the behaviour of the AIX linker.

-L *searchdir***--library-path=*searchdir***

Add path *searchdir* to the list of paths that `ld` will search for archive libraries and `ld` control scripts. You may use this option any number of times. The directories are searched in the order in which they are specified on the command line. Directories specified on the command line are searched before the default directories. All ‘-L’ options apply to all ‘-l’ options, regardless of the order in which the options appear. ‘-L’ options do not affect how `ld` searches for a linker script unless ‘-T’ option is specified.

If *searchdir* begins with `=`, then the `=` will be replaced by the *sysroot prefix*, a path specified when the linker is configured.

The default set of paths searched (without being specified with ‘-L’) depends on which emulation mode `ld` is using, and in some cases also on how it was configured. See [Section 2.2 \[Environment\]](#), page 36.

The paths can also be specified in a link script with the `SEARCH_DIR` command. Directories specified this way are searched at the point in which the linker script appears in the command line.

-m *emulation*

Emulate the *emulation* linker. You can list the available emulations with the ‘--verbose’ or ‘-V’ options.

If the ‘-m’ option is not used, the emulation is taken from the `LDEMULATION` environment variable, if that is defined.

Otherwise, the default emulation depends upon how the linker was configured.

-M**--print-map**

Print a link map to the standard output. A link map provides information about the link, including the following:

- Where object files are mapped into memory.
- How common symbols are allocated.
- All archive members included in the link, with a mention of the symbol which caused the archive member to be brought in.
- The values assigned to symbols.

Note - symbols whose values are computed by an expression which involves a reference to a previous value of the same symbol may not have correct result displayed in the link map. This is because the linker discards intermediate results and only retains the final value of an expression. Under such circumstances the linker will display the final value enclosed by square brackets. Thus for example a linker script containing:

```
foo = 1
foo = foo * 4
foo = foo + 8
```

will produce the following output in the link map if the ‘-M’ option is used:

```
0x00000001          foo = 0x1
[0x0000000c]       foo = (foo * 0x4)
```



```
[0x0000000c]                foo = (foo + 0x8)
```

See [Section 3.10 \[Expressions\]](#), page 69 for more information about expressions in linker scripts.

-n

--nmagic Turn off page alignment of sections, and disable linking against shared libraries. If the output format supports Unix style magic numbers, mark the output as NMAGIC.

-N

--omagic Set the text and data sections to be readable and writable. Also, do not page-align the data segment, and disable linking against shared libraries. If the output format supports Unix style magic numbers, mark the output as OMAGIC. Note: Although a writable text section is allowed for PE-COFF targets, it does not conform to the format specification published by Microsoft.

--no-omagic

This option negates most of the effects of the ‘-N’ option. It sets the text section to be read-only, and forces the data segment to be page-aligned. Note - this option does not enable linking against shared libraries. Use ‘-Bdynamic’ for this.

-o *output*

--output=*output*

Use *output* as the name for the program produced by ld; if this option is not specified, the name ‘a.out’ is used by default. The script command OUTPUT can also specify the output file name.

-O *level* If *level* is a numeric values greater than zero ld optimizes the output. This might take significantly longer and therefore probably should only be enabled for the final binary. At the moment this option only affects ELF shared library generation. Future releases of the linker may make more use of this option. Also currently there is no difference in the linker’s behaviour for different non-zero values of this option. Again this may change with future releases.

-q

--emit-relocs

Leave relocation sections and contents in fully linked executables. Post link analysis and optimization tools may need this information in order to perform correct modifications of executables. This results in larger executables.

This option is currently only supported on ELF platforms.

--force-dynamic

Force the output file to have dynamic sections. This option is specific to Vx-Works targets.

-r

--relocatable

Generate relocatable output—i.e., generate an output file that can in turn serve as input to ld. This is often called *partial linking*. As a side effect, in environments that support standard Unix magic numbers, this option also sets the

output file's magic number to `OMAGIC`. If this option is not specified, an absolute file is produced. When linking C++ programs, this option *will not* resolve references to constructors; to do that, use `'-Ur'`.

When an input file does not have the same format as the output file, partial linking is only supported if that input file does not contain any relocations. Different output formats can have further restrictions; for example some `a.out`-based formats do not support partial linking with input files in other formats at all.

This option does the same thing as `'-i'`.

`-R filename`

`--just-symbols=filename`

Read symbol names and their addresses from *filename*, but do not relocate it or include it in the output. This allows your output file to refer symbolically to absolute locations of memory defined in other programs. You may use this option more than once.

For compatibility with other ELF linkers, if the `'-R'` option is followed by a directory name, rather than a file name, it is treated as the `'-rpath'` option.

`-s`

`--strip-all`

Omit all symbol information from the output file.

`-S`

`--strip-debug`

Omit debugger symbol information (but not all symbols) from the output file.

`-t`

`--trace` Print the names of the input files as `ld` processes them.

`-T scriptfile`

`--script=scriptfile`

Use *scriptfile* as the linker script. This script replaces `ld`'s default linker script (rather than adding to it), so *commandfile* must specify everything necessary to describe the output file. See [Chapter 3 \[Scripts\], page 39](#). If *scriptfile* does not exist in the current directory, `ld` looks for it in the directories specified by any preceding `'-L'` options. Multiple `'-T'` options accumulate.

`-dT scriptfile`

`--default-script=scriptfile`

Use *scriptfile* as the default linker script. See [Chapter 3 \[Scripts\], page 39](#).

This option is similar to the `'--script'` option except that processing of the script is delayed until after the rest of the command line has been processed. This allows options placed after the `'--default-script'` option on the command line to affect the behaviour of the linker script, which can be important when the linker command line cannot be directly controlled by the user. (eg because the command line is being constructed by another tool, such as `'gcc'`).

-u *symbol*

--undefined=*symbol*

Force *symbol* to be entered in the output file as an undefined symbol. Doing this may, for example, trigger linking of additional modules from standard libraries. ‘-u’ may be repeated with different option arguments to enter additional undefined symbols. This option is equivalent to the **EXTERN** linker script command.

-Ur For anything other than C++ programs, this option is equivalent to ‘-r’: it generates relocatable output—i.e., an output file that can in turn serve as input to **ld**. When linking C++ programs, ‘-Ur’ *does* resolve references to constructors, unlike ‘-r’. It does not work to use ‘-Ur’ on files that were themselves linked with ‘-Ur’; once the constructor table has been built, it cannot be added to. Use ‘-Ur’ only for the last partial link, and ‘-r’ for the others.

--unique[=*SECTION*]

Creates a separate output section for every input section matching *SECTION*, or if the optional wildcard *SECTION* argument is missing, for every orphan input section. An orphan section is one not specifically mentioned in a linker script. You may use this option multiple times on the command line; It prevents the normal merging of input sections with the same name, overriding output section assignments in a linker script.

-v

--version

-V Display the version number for **ld**. The ‘-V’ option also lists the supported emulations.

-x

--discard-all

Delete all local symbols.

-X

--discard-locals

Delete all temporary local symbols. (These symbols start with system-specific local label prefixes, typically ‘.L’ for ELF systems or ‘L’ for traditional a.out systems.)

-y *symbol*

--trace-symbol=*symbol*

Print the name of each linked file in which *symbol* appears. This option may be given any number of times. On many systems it is necessary to prepend an underscore.

This option is useful when you have an undefined symbol in your link but don’t know where the reference is coming from.

-Y *path* Add *path* to the default library search path. This option exists for Solaris compatibility.

-z *keyword*

The recognized keywords are:

<code>'combreloc'</code>	Combines multiple reloc sections and sorts them to make dynamic symbol lookup caching possible.
<code>'defs'</code>	Disallows undefined symbols in object files. Undefined symbols in shared libraries are still allowed.
<code>'execstack'</code>	Marks the object as requiring executable stack.
<code>'initfirst'</code>	This option is only meaningful when building a shared object. It marks the object so that its runtime initialization will occur before the runtime initialization of any other objects brought into the process at the same time. Similarly the runtime finalization of the object will occur after the runtime finalization of any other objects.
<code>'interpose'</code>	Marks the object that its symbol table interposes before all symbols but the primary executable.
<code>'lazy'</code>	When generating an executable or shared library, mark it to tell the dynamic linker to defer function call resolution to the point when the function is called (lazy binding), rather than at load time. Lazy binding is the default.
<code>'loadfltr'</code>	Marks the object that its filters be processed immediately at runtime.
<code>'muldefs'</code>	Allows multiple definitions.
<code>'nocombreloc'</code>	Disables multiple reloc sections combining.
<code>'nocopyreloc'</code>	Disables production of copy relocations.
<code>'nodefaultlib'</code>	Marks the object that the search for dependencies of this object will ignore any default library search paths.
<code>'nodelete'</code>	Marks the object shouldn't be unloaded at runtime.
<code>'nodlopen'</code>	Marks the object not available to <code>dlopen</code> .
<code>'nodump'</code>	Marks the object can not be dumped by <code>dldump</code> .
<code>'noexecstack'</code>	Marks the object as not requiring executable stack.
<code>'norelro'</code>	Don't create an ELF <code>PT_GNU_RELRO</code> segment header in the object.

- ‘now’** When generating an executable or shared library, mark it to tell the dynamic linker to resolve all symbols when the program is started, or when the shared library is linked to using `dlopen`, instead of deferring function call resolution to the point when the function is first called.
- ‘origin’** Marks the object may contain `$ORIGIN`.
- ‘relro’** Create an ELF `PT_GNU_RELRO` segment header in the object.
- ‘max-page-size=value’**
Set the emulation maximum page size to *value*.
- ‘common-page-size=value’**
Set the emulation common page size to *value*.

Other keywords are ignored for Solaris compatibility.

-(archives -)

--start-group archives --end-group

The *archives* should be a list of archive files. They may be either explicit file names, or ‘-l’ options.

The specified archives are searched repeatedly until no new undefined references are created. Normally, an archive is searched only once in the order that it is specified on the command line. If a symbol in that archive is needed to resolve an undefined symbol referred to by an object in an archive that appears later on the command line, the linker would not be able to resolve that reference. By grouping the archives, they all be searched repeatedly until all possible references are resolved.

Using this option has a significant performance cost. It is best to use it only when there are unavoidable circular references between two or more archives.

--accept-unknown-input-arch

--no-accept-unknown-input-arch

Tells the linker to accept input files whose architecture cannot be recognised. The assumption is that the user knows what they are doing and deliberately wants to link in these unknown input files. This was the default behaviour of the linker, before release 2.14. The default behaviour from release 2.14 onwards is to reject such input files, and so the ‘**--accept-unknown-input-arch**’ option has been added to restore the old behaviour.

--as-needed

--no-as-needed

This option affects ELF `DT_NEEDED` tags for dynamic libraries mentioned on the command line after the ‘**--as-needed**’ option. Normally the linker will add a `DT_NEEDED` tag for each dynamic library mentioned on the command line, regardless of whether the library is actually needed or not. ‘**--as-needed**’ causes a `DT_NEEDED` tag to only be emitted for a library that satisfies an undefined symbol reference from a regular object file or, if the library is not found in the `DT_NEEDED` lists of other libraries linked up to that point, an undefined symbol reference from another dynamic library. ‘**--no-as-needed**’ restores the default behaviour.

--add-needed

--no-add-needed

These two options have been deprecated because of the similarity of their names to the '**--as-needed**' and '**--no-as-needed**' options. They have been replaced by '**--copy-dt-needed-entries**' and '**--no-copy-dt-needed-entries**'.

-assert keyword

This option is ignored for SunOS compatibility.

-Bdynamic

-dy

-call_shared

Link against dynamic libraries. This is only meaningful on platforms for which shared libraries are supported. This option is normally the default on such platforms. The different variants of this option are for compatibility with various systems. You may use this option multiple times on the command line: it affects library searching for '**-l**' options which follow it.

-Bgroup Set the `DF_1_GROUP` flag in the `DT_FLAGS_1` entry in the dynamic section. This causes the runtime linker to handle lookups in this object and its dependencies to be performed only inside the group. '**--unresolved-symbols=report-all**' is implied. This option is only meaningful on ELF platforms which support shared libraries.

-Bstatic

-dn

-non_shared

-static Do not link against shared libraries. This is only meaningful on platforms for which shared libraries are supported. The different variants of this option are for compatibility with various systems. You may use this option multiple times on the command line: it affects library searching for '**-l**' options which follow it. This option also implies '**--unresolved-symbols=report-all**'. This option can be used with '**-shared**'. Doing so means that a shared library is being created but that all of the library's external references must be resolved by pulling in entries from static libraries.

-Bsymbolic

When creating a shared library, bind references to global symbols to the definition within the shared library, if any. Normally, it is possible for a program linked against a shared library to override the definition within the shared library. This option is only meaningful on ELF platforms which support shared libraries.

-Bsymbolic-functions

When creating a shared library, bind references to global function symbols to the definition within the shared library, if any. This option is only meaningful on ELF platforms which support shared libraries.

--dynamic-list=dynamic-list-file

Specify the name of a dynamic list file to the linker. This is typically used when creating shared libraries to specify a list of global symbols whose references

shouldn't be bound to the definition within the shared library, or creating dynamically linked executables to specify a list of symbols which should be added to the symbol table in the executable. This option is only meaningful on ELF platforms which support shared libraries.

The format of the dynamic list is the same as the version node without scope and node name. See [Section 3.9 \[VERSION\]](#), [page 66](#) for more information.

--dynamic-list-data

Include all global data symbols to the dynamic list.

--dynamic-list-cpp-new

Provide the builtin dynamic list for C++ operator new and delete. It is mainly useful for building shared libstdc++.

--dynamic-list-cpp-typeinfo

Provide the builtin dynamic list for C++ runtime type identification.

--check-sections

--no-check-sections

Asks the linker *not* to check section addresses after they have been assigned to see if there are any overlaps. Normally the linker will perform this check, and if it finds any overlaps it will produce suitable error messages. The linker does know about, and does make allowances for sections in overlays. The default behaviour can be restored by using the command line switch '**--check-sections**'. Section overlap is not usually checked for relocatable links. You can force checking in that case by using the '**--check-sections**' option.

--copy-dt-needed-entries

--no-copy-dt-needed-entries

This option affects the treatment of dynamic libraries referred to by DT_NEEDED tags *inside* ELF dynamic libraries mentioned on the command line. Normally the linker won't add a DT_NEEDED tag to the output binary for each library mentioned in a DT_NEEDED tag in an input dynamic library. With '**--copy-dt-needed-entries**' specified on the command line however any dynamic libraries that follow it will have their DT_NEEDED entries added. The default behaviour can be restored with '**--no-copy-dt-needed-entries**'. This option also has an effect on the resolution of symbols in dynamic libraries. With '**--copy-dt-needed-entries**' dynamic libraries mentioned on the command line will be recursively searched, following their DT_NEEDED tags to other libraries, in order to resolve symbols required by the output binary. With the default setting however the searching of dynamic libraries that follow it will stop with the dynamic library itself. No DT_NEEDED links will be traversed to resolve symbols.

--cref

Output a cross reference table. If a linker map file is being generated, the cross reference table is printed to the map file. Otherwise, it is printed on the standard output.

The format of the table is intentionally simple, so that it may be easily processed by a script if necessary. The symbols are printed out, sorted by name. For each symbol, a list of file names is given. If the symbol is defined, the first file listed

is the location of the definition. The remaining files contain references to the symbol.

`--no-define-common`

This option inhibits the assignment of addresses to common symbols. The script command `INHIBIT_COMMON_ALLOCATION` has the same effect. See [Section 3.4.5 \[Miscellaneous Commands\]](#), page 46.

The ‘`--no-define-common`’ option allows decoupling the decision to assign addresses to Common symbols from the choice of the output file type; otherwise a non-Relocatable output type forces assigning addresses to Common symbols. Using ‘`--no-define-common`’ allows Common symbols that are referenced from a shared library to be assigned addresses only in the main program. This eliminates the unused duplicate space in the shared library, and also prevents any possible confusion over resolving to the wrong duplicate when there are many dynamic modules with specialized search paths for runtime symbol resolution.

`--defsym=symbol=expression`

Create a global symbol in the output file, containing the absolute address given by *expression*. You may use this option as many times as necessary to define multiple symbols in the command line. A limited form of arithmetic is supported for the *expression* in this context: you may give a hexadecimal constant or the name of an existing symbol, or use `+` and `-` to add or subtract hexadecimal constants or symbols. If you need more elaborate expressions, consider using the linker command language from a script (see [Section 3.5 \[Assignment: Symbol Definitions\]](#), page 47). *Note:* there should be no white space between *symbol*, the equals sign (`=`), and *expression*.

`--demangle[=style]`

`--no-demangle`

These options control whether to demangle symbol names in error messages and other output. When the linker is told to demangle, it tries to present symbol names in a readable fashion: it strips leading underscores if they are used by the object file format, and converts C++ mangled symbol names into user readable names. Different compilers have different mangling styles. The optional demangling style argument can be used to choose an appropriate demangling style for your compiler. The linker will demangle by default unless the environment variable ‘`COLLECT_NO_DEMANGLE`’ is set. These options may be used to override the default.

`-Ifile`

`--dynamic-linker=file`

Set the name of the dynamic linker. This is only meaningful when generating dynamically linked ELF executables. The default dynamic linker is normally correct; don’t use this unless you know what you are doing.

`--fatal-warnings`

`--no-fatal-warnings`

Treat all warnings as errors. The default behaviour can be restored with the option ‘`--no-fatal-warnings`’.

--force-exe-suffix

Make sure that an output file has a `.exe` suffix.

If a successfully built fully linked output file does not have a `.exe` or `.dll` suffix, this option forces the linker to copy the output file to one of the same name with a `.exe` suffix. This option is useful when using unmodified Unix makefiles on a Microsoft Windows host, since some versions of Windows won't run an image unless it ends in a `.exe` suffix.

--gc-sections**--no-gc-sections**

Enable garbage collection of unused input sections. It is ignored on targets that do not support this option. The default behaviour (of not performing this garbage collection) can be restored by specifying `--no-gc-sections` on the command line.

`--gc-sections` decides which input sections are used by examining symbols and relocations. The section containing the entry symbol and all sections containing symbols undefined on the command-line will be kept, as will sections containing symbols referenced by dynamic objects. Note that when building shared libraries, the linker must assume that any visible symbol is referenced. Once this initial set of sections has been determined, the linker recursively marks as used any section referenced by their relocations. See `--entry` and `--undefined`.

This option can be set when doing a partial link (enabled with option `-r`). In this case the root of symbols kept must be explicitly specified either by an `--entry` or `--undefined` option or by a `ENTRY` command in the linker script.

--print-gc-sections**--no-print-gc-sections**

List all sections removed by garbage collection. The listing is printed on stderr. This option is only effective if garbage collection has been enabled via the `--gc-sections` option. The default behaviour (of not listing the sections that are removed) can be restored by specifying `--no-print-gc-sections` on the command line.

--print-output-format

Print the name of the default output format (perhaps influenced by other command-line options). This is the string that would appear in an `OUTPUT_FORMAT` linker script command (see [Section 3.4.2 \[File Commands\]](#), page 41).

--help Print a summary of the command-line options on the standard output and exit.

--target-help

Print a summary of all target specific options on the standard output and exit.

-Map=mapfile

Print a link map to the file *mapfile*. See the description of the `-M` option, above.

--no-keep-memory

`ld` normally optimizes for speed over memory usage by caching the symbol tables of input files in memory. This option tells `ld` to instead optimize for

memory usage, by rereading the symbol tables as necessary. This may be required if `ld` runs out of memory space while linking a large executable.

`--no-undefined`

`-z defs` Report unresolved symbol references from regular object files. This is done even if the linker is creating a non-symbolic shared library. The switch ‘`--[no-]allow-shlib-undefined`’ controls the behaviour for reporting unresolved references found in shared libraries being linked in.

`--allow-multiple-definition`

`-z muldefs`

Normally when a symbol is defined multiple times, the linker will report a fatal error. These options allow multiple definitions and the first definition will be used.

`--allow-shlib-undefined`

`--no-allow-shlib-undefined`

Allows or disallows undefined symbols in shared libraries. This switch is similar to ‘`--no-undefined`’ except that it determines the behaviour when the undefined symbols are in a shared library rather than a regular object file. It does not affect how undefined symbols in regular object files are handled.

The default behaviour is to report errors for any undefined symbols referenced in shared libraries if the linker is being used to create an executable, but to allow them if the linker is being used to create a shared library.

The reasons for allowing undefined symbol references in shared libraries specified at link time are that:

- A shared library specified at link time may not be the same as the one that is available at load time, so the symbol might actually be resolvable at load time.
- There are some operating systems, eg BeOS and HPPA, where undefined symbols in shared libraries are normal.

The BeOS kernel for example patches shared libraries at load time to select whichever function is most appropriate for the current architecture. This is used, for example, to dynamically select an appropriate `memset` function.

`--no-undefined-version`

Normally when a symbol has an undefined version, the linker will ignore it. This option disallows symbols with undefined version and a fatal error will be issued instead.

`--default-symver`

Create and use a default symbol version (the soname) for unversioned exported symbols.

`--default-imported-symver`

Create and use a default symbol version (the soname) for unversioned imported symbols.

`--no-warn-mismatch`

Normally `ld` will give an error if you try to link together input files that are mismatched for some reason, perhaps because they have been compiled for

different processors or for different endiannesses. This option tells `ld` that it should silently permit such possible errors. This option should only be used with care, in cases when you have taken some special action that ensures that the linker errors are inappropriate.

--no-warn-search-mismatch

Normally `ld` will give a warning if it finds an incompatible library during a library search. This option silences the warning.

--no-whole-archive

Turn off the effect of the ‘`--whole-archive`’ option for subsequent archive files.

--noinhibit-exec

Retain the executable output file whenever it is still usable. Normally, the linker will not produce an output file if it encounters errors during the link process; it exits without writing an output file when it issues any error whatsoever.

-nostdlib

Only search library directories explicitly specified on the command line. Library directories specified in linker scripts (including linker scripts specified on the command line) are ignored.

--oformat=*output-format*

`ld` may be configured to support more than one kind of object file. If your `ld` is configured this way, you can use the ‘`--oformat`’ option to specify the binary format for the output object file. Even when `ld` is configured to support alternative object formats, you don’t usually need to specify this, as `ld` should be configured to produce as a default output format the most usual format on each machine. *output-format* is a text string, the name of a particular format supported by the BFD libraries. (You can list the available binary formats with ‘`objdump -i`’.) The script command `OUTPUT_FORMAT` can also specify the output format, but this option overrides it. See [Chapter 5 \[BFD\]](#), [page 97](#).

-pie

--pic-executable

Create a position independent executable. This is currently only supported on ELF platforms. Position independent executables are similar to shared libraries in that they are relocated by the dynamic linker to the virtual address the OS chooses for them (which can vary between invocations). Like normal dynamically linked executables they can be executed and symbols defined in the executable cannot be overridden by shared libraries.

-qmagic This option is ignored for Linux compatibility.

-Qy This option is ignored for SVR4 compatibility.

--relax

--no-relax

An option with machine dependent effects. This option is only supported on a few targets. See [Section 4.1 \[ld and the H8/300\]](#), [page 79](#). See [Section 4.2 \[ld and the Intel 960 family\]](#), [page 79](#). See [Section 4.14 \[ld and Xtensa Processors\]](#),

page 96. See Section 4.3 [ld and the 68HC11 and 68HC12], page 80. See Section 4.9 [ld and PowerPC 32-bit ELF Support], page 84.

On some platforms the ‘`--relax`’ option performs target specific, global optimizations that become possible when the linker resolves addressing in the program, such as relaxing address modes, synthesizing new instructions, selecting shorter version of current instructions, and combining constant values.

On some platforms these link time global optimizations may make symbolic debugging of the resulting executable impossible. This is known to be the case for the Matsushita MN10200 and MN10300 family of processors.

On platforms where this is not supported, ‘`--relax`’ is accepted, but ignored.

On platforms where ‘`--relax`’ is accepted the option ‘`--no-relax`’ can be used to disable the feature.

`--retain-symbols-file=filename`

Retain *only* the symbols listed in the file *filename*, discarding all others. *filename* is simply a flat file, with one symbol name per line. This option is especially useful in environments (such as VxWorks) where a large global symbol table is accumulated gradually, to conserve run-time memory.

‘`--retain-symbols-file`’ does *not* discard undefined symbols, or symbols needed for relocations.

You may only specify ‘`--retain-symbols-file`’ once in the command line. It overrides ‘`-s`’ and ‘`-S`’.

`-rpath=dir`

Add a directory to the runtime library search path. This is used when linking an ELF executable with shared objects. All ‘`-rpath`’ arguments are concatenated and passed to the runtime linker, which uses them to locate shared objects at runtime. The ‘`-rpath`’ option is also used when locating shared objects which are needed by shared objects explicitly included in the link; see the description of the ‘`-rpath-link`’ option. If ‘`-rpath`’ is not used when linking an ELF executable, the contents of the environment variable `LD_RUN_PATH` will be used if it is defined.

The ‘`-rpath`’ option may also be used on SunOS. By default, on SunOS, the linker will form a runtime search patch out of all the ‘`-L`’ options it is given. If a ‘`-rpath`’ option is used, the runtime search path will be formed exclusively using the ‘`-rpath`’ options, ignoring the ‘`-L`’ options. This can be useful when using gcc, which adds many ‘`-L`’ options which may be on NFS mounted file systems.

For compatibility with other ELF linkers, if the ‘`-R`’ option is followed by a directory name, rather than a file name, it is treated as the ‘`-rpath`’ option.

`-rpath-link=dir`

When using ELF or SunOS, one shared library may require another. This happens when an `ld -shared` link includes a shared library as one of the input files.

When the linker encounters such a dependency when doing a non-shared, non-relocatable link, it will automatically try to locate the required shared library

and include it in the link, if it is not included explicitly. In such a case, the ‘`-rpath-link`’ option specifies the first set of directories to search. The ‘`-rpath-link`’ option may specify a sequence of directory names either by specifying a list of names separated by colons, or by appearing multiple times.

This option should be used with caution as it overrides the search path that may have been hard compiled into a shared library. In such a case it is possible to use unintentionally a different search path than the runtime linker would do.

The linker uses the following search paths to locate required shared libraries:

1. Any directories specified by ‘`-rpath-link`’ options.
2. Any directories specified by ‘`-rpath`’ options. The difference between ‘`-rpath`’ and ‘`-rpath-link`’ is that directories specified by ‘`-rpath`’ options are included in the executable and used at runtime, whereas the ‘`-rpath-link`’ option is only effective at link time. Searching ‘`-rpath`’ in this way is only supported by native linkers and cross linkers which have been configured with the ‘`--with-sysroot`’ option.
3. On an ELF system, for native linkers, if the ‘`-rpath`’ and ‘`-rpath-link`’ options were not used, search the contents of the environment variable `LD_RUN_PATH`.
4. On SunOS, if the ‘`-rpath`’ option was not used, search any directories specified using ‘`-L`’ options.
5. For a native linker, the search the contents of the environment variable `LD_LIBRARY_PATH`.
6. For a native ELF linker, the directories in `DT_RUNPATH` or `DT_RPATH` of a shared library are searched for shared libraries needed by it. The `DT_RPATH` entries are ignored if `DT_RUNPATH` entries exist.
7. The default directories, normally ‘`/lib`’ and ‘`/usr/lib`’.
8. For a native linker on an ELF system, if the file ‘`/etc/ld.so.conf`’ exists, the list of directories found in that file.

If the required shared library is not found, the linker will issue a warning and continue with the link.

`-shared`

`-Bshareable`

Create a shared library. This is currently only supported on ELF, XCOFF and SunOS platforms. On SunOS, the linker will automatically create a shared library if the ‘`-e`’ option is not used and there are undefined symbols in the link.

`--sort-common`

`--sort-common=ascending`

`--sort-common=descending`

This option tells `ld` to sort the common symbols by alignment in ascending or descending order when it places them in the appropriate output sections. The symbol alignments considered are sixteen-byte or larger, eight-byte, four-byte, two-byte, and one-byte. This is to prevent gaps between symbols due to

alignment constraints. If no sorting order is specified, then descending order is assumed.

--sort-section=name

This option will apply `SORT_BY_NAME` to all wildcard section patterns in the linker script.

--sort-section=alignment

This option will apply `SORT_BY_ALIGNMENT` to all wildcard section patterns in the linker script.

--split-by-file[=size]

Similar to ‘**--split-by-reloc**’ but creates a new output section for each input file when *size* is reached. *size* defaults to a size of 1 if not given.

--split-by-reloc[=count]

Tries to create extra sections in the output file so that no single output section in the file contains more than *count* relocations. This is useful when generating huge relocatable files for downloading into certain real time kernels with the COFF object file format; since COFF cannot represent more than 65535 relocations in a single section. Note that this will fail to work with object file formats which do not support arbitrary sections. The linker will not split up individual input sections for redistribution, so if a single input section contains more than *count* relocations one output section will contain that many relocations. *count* defaults to a value of 32768.

--stats Compute and display statistics about the operation of the linker, such as execution time and memory usage.

--sysroot=directory

Use *directory* as the location of the sysroot, overriding the configure-time default. This option is only supported by linkers that were configured using ‘**--with-sysroot**’.

--traditional-format

For some targets, the output of `ld` is different in some ways from the output of some existing linker. This switch requests `ld` to use the traditional format instead.

For example, on SunOS, `ld` combines duplicate entries in the symbol string table. This can reduce the size of an output file with full debugging information by over 30 percent. Unfortunately, the SunOS `dbx` program can not read the resulting program (`gdb` has no trouble). The ‘**--traditional-format**’ switch tells `ld` to not combine duplicate entries.

--section-start=sectionname=org

Locate a section in the output file at the absolute address given by *org*. You may use this option as many times as necessary to locate multiple sections in the command line. *org* must be a single hexadecimal integer; for compatibility with other linkers, you may omit the leading ‘0x’ usually associated with hexadecimal values. *Note:* there should be no white space between *sectionname*, the equals sign (“=”), and *org*.

`-Tbss=org`
`-Tdata=org`
`-Ttext=org`
 Same as ‘`--section-start`’, with `.bss`, `.data` or `.text` as the *sectionname*.

`-Ttext-segment=org`
 When creating an ELF executable or shared object, it will set the address of the first byte of the text segment.

`-Trodata-segment=org`
 When creating an ELF executable or shared object for a target where the read-only data is in its own segment separate from the executable text, it will set the address of the first byte of the read-only data segment.

`--unresolved-symbols=method`
 Determine how to handle unresolved symbols. There are four possible values for ‘`method`’:

- ‘`ignore-all`’
 Do not report any unresolved symbols.
- ‘`report-all`’
 Report all unresolved symbols. This is the default.
- ‘`ignore-in-object-files`’
 Report unresolved symbols that are contained in shared libraries, but ignore them if they come from regular object files.
- ‘`ignore-in-shared-libs`’
 Report unresolved symbols that come from regular object files, but ignore them if they come from shared libraries. This can be useful when creating a dynamic binary and it is known that all the shared libraries that it should be referencing are included on the linker’s command line.

The behaviour for shared libraries on their own can also be controlled by the ‘`--[no-]allow-shlib-undefined`’ option.

Normally the linker will generate an error message for each reported unresolved symbol but the option ‘`--warn-unresolved-symbols`’ can change this to a warning.

`--dll-verbose`
`--verbose[=NUMBER]`
 Display the version number for `ld` and list the linker emulations supported. Display which input files can and cannot be opened. Display the linker script being used by the linker. If the optional *NUMBER* argument > 1, plugin symbol status will also be displayed.

`--version-script=version-scriptfile`
 Specify the name of a version script to the linker. This is typically used when creating shared libraries to specify additional information about the version hierarchy for the library being created. This option is only fully supported

on ELF platforms which support shared libraries; see [Section 3.9 \[VERSION\]](#), [page 66](#). It is partially supported on PE platforms, which can use version scripts to filter symbol visibility in auto-export mode: any symbols marked ‘local’ in the version script will not be exported. See [Section 4.13 \[WIN32\]](#), [page 88](#).

`--warn-common`

Warn when a common symbol is combined with another common symbol or with a symbol definition. Unix linkers allow this somewhat sloppy practise, but linkers on some other operating systems do not. This option allows you to find potential problems from combining global symbols. Unfortunately, some C libraries use this practise, so you may get some warnings about symbols in the libraries as well as in your programs.

There are three kinds of global symbols, illustrated here by C examples:

`‘int i = 1;’`

A definition, which goes in the initialized data section of the output file.

`‘extern int i;’`

An undefined reference, which does not allocate space. There must be either a definition or a common symbol for the variable somewhere.

`‘int i;’`

A common symbol. If there are only (one or more) common symbols for a variable, it goes in the uninitialized data area of the output file. The linker merges multiple common symbols for the same variable into a single symbol. If they are of different sizes, it picks the largest size. The linker turns a common symbol into a declaration, if there is a definition of the same variable.

The ‘`--warn-common`’ option can produce five kinds of warnings. Each warning consists of a pair of lines: the first describes the symbol just encountered, and the second describes the previous symbol encountered with the same name. One or both of the two symbols will be a common symbol.

1. Turning a common symbol into a reference, because there is already a definition for the symbol.

```
file(section): warning: common of ‘symbol’
                overridden by definition
file(section): warning: defined here
```

2. Turning a common symbol into a reference, because a later definition for the symbol is encountered. This is the same as the previous case, except that the symbols are encountered in a different order.

```
file(section): warning: definition of ‘symbol’
                overriding common
file(section): warning: common is here
```

3. Merging a common symbol with a previous same-sized common symbol.

```
file(section): warning: multiple common
                of ‘symbol’
file(section): warning: previous common is here
```

4. Merging a common symbol with a previous larger common symbol.

```
file(section): warning: common of 'symbol'
overridden by larger common
file(section): warning: larger common is here
```

5. Merging a common symbol with a previous smaller common symbol. This is the same as the previous case, except that the symbols are encountered in a different order.

```
file(section): warning: common of 'symbol'
overriding smaller common
file(section): warning: smaller common is here
```

--warn-constructors

Warn if any global constructors are used. This is only useful for a few object file formats. For formats like COFF or ELF, the linker can not detect the use of global constructors.

--warn-multiple-gp

Warn if multiple global pointer values are required in the output file. This is only meaningful for certain processors, such as the Alpha. Specifically, some processors put large-valued constants in a special section. A special register (the global pointer) points into the middle of this section, so that constants can be loaded efficiently via a base-register relative addressing mode. Since the offset in base-register relative mode is fixed and relatively small (e.g., 16 bits), this limits the maximum size of the constant pool. Thus, in large programs, it is often necessary to use multiple global pointer values in order to be able to address all possible constants. This option causes a warning to be issued whenever this case occurs.

--warn-once

Only warn once for each undefined symbol, rather than once per module which refers to it.

--warn-section-align

Warn if the address of an output section is changed because of alignment. Typically, the alignment will be set by an input section. The address will only be changed if it not explicitly specified; that is, if the **SECTIONS** command does not specify a start address for the section (see [Section 3.6 \[SECTIONS\]](#), [page 50](#)).

--warn-shared-textrel

Warn if the linker adds a `DT_TEXTREL` to a shared object.

--warn-alternate-em

Warn if an object has alternate ELF machine code.

--warn-unresolved-symbols

If the linker is going to report an unresolved symbol (see the option `--unresolved-symbols`) it will normally generate an error. This option makes it generate a warning instead.

--error-unresolved-symbols

This restores the linker's default behaviour of generating errors when it is reporting unresolved symbols.

--whole-archive

For each archive mentioned on the command line after the ‘**--whole-archive**’ option, include every object file in the archive in the link, rather than searching the archive for the required object files. This is normally used to turn an archive file into a shared library, forcing every object to be included in the resulting shared library. This option may be used more than once.

Two notes when using this option from gcc: First, gcc doesn’t know about this option, so you have to use ‘**-Wl,-whole-archive**’. Second, don’t forget to use ‘**-Wl,-no-whole-archive**’ after your list of archives, because gcc will add its own list of archives to your link and you may not want this flag to affect those as well.

--wrap=symbol

Use a wrapper function for *symbol*. Any undefined reference to *symbol* will be resolved to `__wrap_symbol`. Any undefined reference to `__real_symbol` will be resolved to *symbol*.

This can be used to provide a wrapper for a system function. The wrapper function should be called `__wrap_symbol`. If it wishes to call the system function, it should call `__real_symbol`.

Here is a trivial example:

```
void *
__wrap_malloc (size_t c)
{
    printf ("malloc called with %zu\n", c);
    return __real_malloc (c);
}
```

If you link other code with this file using ‘**--wrap malloc**’, then all calls to `malloc` will call the function `__wrap_malloc` instead. The call to `__real_malloc` in `__wrap_malloc` will call the real `malloc` function.

You may wish to provide a `__real_malloc` function as well, so that links without the ‘**--wrap**’ option will succeed. If you do this, you should not put the definition of `__real_malloc` in the same file as `__wrap_malloc`; if you do, the assembler may resolve the call before the linker has a chance to wrap it to `malloc`.

--eh-frame-hdr

Request creation of `.eh_frame_hdr` section and ELF `PT_GNU_EH_FRAME` segment header.

--no-ld-generated-unwind-info

Request creation of `.eh_frame` unwind info for linker generated code sections like PLT. This option is on by default if linker generated unwind info is supported.

--enable-new-dtags**--disable-new-dtags**

This linker can create the new dynamic tags in ELF. But the older ELF systems may not understand them. If you specify ‘**--enable-new-dtags**’, the dynamic tags will be created as needed. If you specify ‘**--disable-new-dtags**’, no new

dynamic tags will be created. By default, the new dynamic tags are not created. Note that those options are only available for ELF systems.

--hash-size=number

Set the default size of the linker's hash tables to a prime number close to *number*. Increasing this value can reduce the length of time it takes the linker to perform its tasks, at the expense of increasing the linker's memory requirements. Similarly reducing this value can reduce the memory requirements at the expense of speed.

--hash-style=style

Set the type of linker's hash table(s). *style* can be either **sysv** for classic ELF **.hash** section, **gnu** for new style GNU **.gnu.hash** section or **both** for both the classic ELF **.hash** and new style GNU **.gnu.hash** hash tables. The default is **sysv**.

--reduce-memory-overheads

This option reduces memory requirements at ld runtime, at the expense of linking speed. This was introduced to select the old $O(n^2)$ algorithm for link map file generation, rather than the new $O(n)$ algorithm which uses about 40% more memory for symbol storage.

Another effect of the switch is to set the default hash table size to 1021, which again saves memory at the cost of lengthening the linker's run time. This is not done however if the '**--hash-size**' switch has been used.

The '**--reduce-memory-overheads**' switch may be also be used to enable other tradeoffs in future versions of the linker.

--build-id

--build-id=style

Request creation of **.note.gnu.build-id** ELF note section. The contents of the note are unique bits identifying this linked file. *style* can be **uuid** to use 128 random bits, **sha1** to use a 160-bit SHA1 hash on the normative parts of the output contents, **md5** to use a 128-bit MD5 hash on the normative parts of the output contents, or **0xhexstring** to use a chosen bit string specified as an even number of hexadecimal digits (- and : characters between digit pairs are ignored). If *style* is omitted, **sha1** is used.

The **md5** and **sha1** styles produces an identifier that is always the same in an identical output file, but will be unique among all nonidentical output files. It is not intended to be compared as a checksum for the file's contents. A linked file may be changed later by other tools, but the build ID bit string identifying the original linked file does not change.

Passing **none** for *style* disables the setting from any **--build-id** options earlier on the command line.

2.1.1 Options Specific to i386 PE Targets

The i386 PE linker supports the '**-shared**' option, which causes the output to be a dynamically linked library (DLL) instead of a normal executable. You should name the output ***.dll** when you use this option. In addition, the linker fully supports the standard ***.def**

files, which may be specified on the linker command line like an object file (in fact, it should precede archives it exports symbols from, to ensure that they get linked in, just like a normal object file).

In addition to the options common to all targets, the i386 PE linker support additional command line options that are specific to the i386 PE target. Options that take values may be separated from their values by either a space or an equals sign.

--add-stdcall-alias

If given, symbols with a stdcall suffix (*@nn*) will be exported as-is and also with the suffix stripped. [This option is specific to the i386 PE targeted port of the linker]

--base-file *file*

Use *file* as the name of a file in which to save the base addresses of all the relocations needed for generating DLLs with ‘*dlltool*’. [This is an i386 PE specific option]

--dll Create a DLL instead of a regular executable. You may also use ‘*-shared*’ or specify a *LIBRARY* in a given *.def* file. [This option is specific to the i386 PE targeted port of the linker]

--enable-long-section-names

--disable-long-section-names

The PE variants of the Coff object format add an extension that permits the use of section names longer than eight characters, the normal limit for Coff. By default, these names are only allowed in object files, as fully-linked executable images do not carry the Coff string table required to support the longer names. As a GNU extension, it is possible to allow their use in executable images as well, or to (probably pointlessly!) disallow it in object files, by using these two options. Executable images generated with these long section names are slightly non-standard, carrying as they do a string table, and may generate confusing output when examined with non-GNU PE-aware tools, such as file viewers and dumpers. However, GDB relies on the use of PE long section names to find Dwarf-2 debug information sections in an executable image at runtime, and so if neither option is specified on the command-line, *ld* will enable long section names, overriding the default and technically correct behaviour, when it finds the presence of debug information while linking an executable image and not stripping symbols. [This option is valid for all PE targeted ports of the linker]

--enable-stdcall-fixup

--disable-stdcall-fixup

If the link finds a symbol that it cannot resolve, it will attempt to do “fuzzy linking” by looking for another defined symbol that differs only in the format of the symbol name (*cdecl* vs *stdcall*) and will resolve that symbol by linking to the match. For example, the undefined symbol *_foo* might be linked to the function *_foo@12*, or the undefined symbol *_bar@16* might be linked to the function *_bar*. When the linker does this, it prints a warning, since it normally should have failed to link, but sometimes import libraries generated from third-party dlls may need this feature to be usable. If you specify

‘`--enable-stdcall-fixup`’, this feature is fully enabled and warnings are not printed. If you specify ‘`--disable-stdcall-fixup`’, this feature is disabled and such mismatches are considered to be errors. [This option is specific to the i386 PE targeted port of the linker]

`--leading-underscore`

`--no-leading-underscore`

For most targets default symbol-prefix is an underscore and is defined in target’s description. By this option it is possible to disable/enable the default underscore symbol-prefix.

`--export-all-symbols`

If given, all global symbols in the objects used to build a DLL will be exported by the DLL. Note that this is the default if there otherwise wouldn’t be any exported symbols. When symbols are explicitly exported via DEF files or implicitly exported via function attributes, the default is to not export anything else unless this option is given. Note that the symbols `DllMain@12`, `DllEntryPoint@0`, `DllMainCRTStartup@12`, and `impure_ptr` will not be automatically exported. Also, symbols imported from other DLLs will not be re-exported, nor will symbols specifying the DLL’s internal layout such as those beginning with `_head_` or ending with `_iname`. In addition, no symbols from `libgcc`, `libstd++`, `libmingw32`, or `crtX.o` will be exported. Symbols whose names begin with `__rtti_` or `__builtin_` will not be exported, to help with C++ DLLs. Finally, there is an extensive list of cygwin-private symbols that are not exported (obviously, this applies on when building DLLs for cygwin targets). These cygwin-excludes are: `_cygwin_dll_entry@12`, `_cygwin_crt0_common@8`, `_cygwin_noncygwin_dll_entry@12`, `_fmode`, `_impure_ptr`, `cygwin_attach_dll`, `cygwin_premain0`, `cygwin_premain1`, `cygwin_premain2`, `cygwin_premain3`, and `environ`. [This option is specific to the i386 PE targeted port of the linker]

`--exclude-symbols symbol,symbol,...`

Specifies a list of symbols which should not be automatically exported. The symbol names may be delimited by commas or colons. [This option is specific to the i386 PE targeted port of the linker]

`--exclude-all-symbols`

Specifies no symbols should be automatically exported. [This option is specific to the i386 PE targeted port of the linker]

`--file-alignment`

Specify the file alignment. Sections in the file will always begin at file offsets which are multiples of this number. This defaults to 512. [This option is specific to the i386 PE targeted port of the linker]

`--heap reserve`

`--heap reserve,commit`

Specify the number of bytes of memory to reserve (and optionally commit) to be used as heap for this program. The default is 1Mb reserved, 4K committed. [This option is specific to the i386 PE targeted port of the linker]

--image-base *value*

Use *value* as the base address of your program or dll. This is the lowest memory location that will be used when your program or dll is loaded. To reduce the need to relocate and improve performance of your dlls, each should have a unique base address and not overlap any other dlls. The default is 0x400000 for executables, and 0x10000000 for dlls. [This option is specific to the i386 PE targeted port of the linker]

--kill-at

If given, the stdcall suffixes (*@nn*) will be stripped from symbols before they are exported. [This option is specific to the i386 PE targeted port of the linker]

--large-address-aware

If given, the appropriate bit in the “Characteristics” field of the COFF header is set to indicate that this executable supports virtual addresses greater than 2 gigabytes. This should be used in conjunction with the /3GB or /USERVA=*value* megabytes switch in the “[operating systems]” section of the BOOT.INI. Otherwise, this bit has no effect. [This option is specific to PE targeted ports of the linker]

--major-image-version *value*

Sets the major number of the “image version”. Defaults to 1. [This option is specific to the i386 PE targeted port of the linker]

--major-os-version *value*

Sets the major number of the “os version”. Defaults to 4. [This option is specific to the i386 PE targeted port of the linker]

--major-subsystem-version *value*

Sets the major number of the “subsystem version”. Defaults to 4. [This option is specific to the i386 PE targeted port of the linker]

--minor-image-version *value*

Sets the minor number of the “image version”. Defaults to 0. [This option is specific to the i386 PE targeted port of the linker]

--minor-os-version *value*

Sets the minor number of the “os version”. Defaults to 0. [This option is specific to the i386 PE targeted port of the linker]

--minor-subsystem-version *value*

Sets the minor number of the “subsystem version”. Defaults to 0. [This option is specific to the i386 PE targeted port of the linker]

--output-def *file*

The linker will create the file *file* which will contain a DEF file corresponding to the DLL the linker is generating. This DEF file (which should be called **.def*) may be used to create an import library with *dlltool* or may be used as a reference to automatically or implicitly exported symbols. [This option is specific to the i386 PE targeted port of the linker]

--out-implib *file*

The linker will create the file *file* which will contain an import lib corresponding to the DLL the linker is generating. This import lib (which should be called **.dll.a* or **.a* may be used to link clients against the generated DLL; this behaviour makes it possible to skip a separate `dlltool` import library creation step. [This option is specific to the i386 PE targeted port of the linker]

--enable-auto-image-base

Automatically choose the image base for DLLs, unless one is specified using the **--image-base** argument. By using a hash generated from the `dllname` to create unique image bases for each DLL, in-memory collisions and relocations which can delay program execution are avoided. [This option is specific to the i386 PE targeted port of the linker]

--disable-auto-image-base

Do not automatically generate a unique image base. If there is no user-specified image base (**--image-base**) then use the platform default. [This option is specific to the i386 PE targeted port of the linker]

--dll-search-prefix *string*

When linking dynamically to a dll without an import library, search for `<string><basename>.dll` in preference to `lib<basename>.dll`. This behaviour allows easy distinction between DLLs built for the various "subplatforms": native, cygwin, uwin, pw, etc. For instance, cygwin DLLs typically use **--dll-search-prefix=cyg**. [This option is specific to the i386 PE targeted port of the linker]

--enable-auto-import

Do sophisticated linking of `_symbol` to `__imp__symbol` for DATA imports from DLLs, and create the necessary thunking symbols when building the import libraries with those DATA exports. Note: Use of the 'auto-import' extension will cause the text section of the image file to be made writable. This does not conform to the PE-COFF format specification published by Microsoft.

Note - use of the 'auto-import' extension will also cause read only data which would normally be placed into the `.rdata` section to be placed into the `.data` section instead. This is in order to work around a problem with consts that is described here: <http://www.cygwin.com/ml/cygwin/2004-09/msg01101.html>

Using 'auto-import' generally will 'just work' – but sometimes you may see this message:

"variable '<var>' can't be auto-imported. Please read the documentation for ld's **--enable-auto-import** for details."

This message occurs when some (sub)expression accesses an address ultimately given by the sum of two constants (Win32 import tables only allow one). Instances where this may occur include accesses to member fields of struct variables imported from a DLL, as well as using a constant index into an array variable imported from a DLL. Any multiword variable (arrays, structs, long long, etc) may trigger this error condition. However, regardless of the exact data type of the offending exported variable, ld will always detect it, issue the warning, and exit.

There are several ways to address this difficulty, regardless of the data type of the exported variable:

One way is to use `-enable-runtime-pseudo-reloc` switch. This leaves the task of adjusting references in your client code for runtime environment, so this method works only when runtime environment supports this feature.

A second solution is to force one of the 'constants' to be a variable – that is, unknown and un-optimizable at compile time. For arrays, there are two possibilities: a) make the indexee (the array's address) a variable, or b) make the 'constant' index a variable. Thus:

```
extern type extern_array[];
extern_array[1] -->
{ volatile type *t=extern_array; t[1] }
```

or

```
extern type extern_array[];
extern_array[1] -->
{ volatile int t=1; extern_array[t] }
```

For structs (and most other multiword data types) the only option is to make the struct itself (or the long long, or the ...) variable:

```
extern struct s extern_struct;
extern_struct.field -->
{ volatile struct s *t=&extern_struct; t->field }
```

or

```
extern long long extern_ll;
extern_ll -->
{ volatile long long * local_ll=&extern_ll; *local_ll }
```

A third method of dealing with this difficulty is to abandon 'auto-import' for the offending symbol and mark it with `__declspec(dllimport)`. However, in practise that requires using compile-time `#defines` to indicate whether you are building a DLL, building client code that will link to the DLL, or merely building/linking to a static library. In making the choice between the various methods of resolving the 'direct address with constant offset' problem, you should consider typical real-world usage:

Original:

```
--foo.h
extern int arr[];
--foo.c
#include "foo.h"
void main(int argc, char **argv){
    printf("%d\n",arr[1]);
}
```

Solution 1:

```
--foo.h
extern int arr[];
--foo.c
```

```
#include "foo.h"
void main(int argc, char **argv){
    /* This workaround is for win32 and cygwin; do not "optimize" */
    volatile int *parr = arr;
    printf("%d\n",parr[1]);
}
```

Solution 2:

```
--foo.h
/* Note: auto-export is assumed (no __declspec(dllexport)) */
#if (defined(_WIN32) || defined(__CYGWIN__)) && \
    !(defined(FOO_BUILD_DLL) || defined(FOO_STATIC))
#define FOO_IMPORT __declspec(dllimport)
#else
#define FOO_IMPORT
#endif
extern FOO_IMPORT int arr[];
--foo.c
#include "foo.h"
void main(int argc, char **argv){
    printf("%d\n",arr[1]);
}
```

A fourth way to avoid this problem is to re-code your library to use a functional interface rather than a data interface for the offending variables (e.g. `set_foo()` and `get_foo()` accessor functions). [This option is specific to the i386 PE targeted port of the linker]

`--disable-auto-import`

Do not attempt to do sophisticated linking of `_symbol` to `__imp__symbol` for DATA imports from DLLs. [This option is specific to the i386 PE targeted port of the linker]

`--enable-runtime-pseudo-reloc`

If your code contains expressions described in `--enable-auto-import` section, that is, DATA imports from DLL with non-zero offset, this switch will create a vector of 'runtime pseudo relocations' which can be used by runtime environment to adjust references to such data in your client code. [This option is specific to the i386 PE targeted port of the linker]

`--disable-runtime-pseudo-reloc`

Do not create pseudo relocations for non-zero offset DATA imports from DLLs. This is the default. [This option is specific to the i386 PE targeted port of the linker]

`--enable-extra-pe-debug`

Show additional debug info related to auto-import symbol thunking. [This option is specific to the i386 PE targeted port of the linker]

--section-alignment
 Sets the section alignment. Sections in memory will always begin at addresses which are a multiple of this number. Defaults to 0x1000. [This option is specific to the i386 PE targeted port of the linker]

--stack reserve
--stack reserve,commit
 Specify the number of bytes of memory to reserve (and optionally commit) to be used as stack for this program. The default is 2Mb reserved, 4K committed. [This option is specific to the i386 PE targeted port of the linker]

--subsystem which
--subsystem which:major
--subsystem which:major.minor
 Specifies the subsystem under which your program will execute. The legal values for *which* are *native*, *windows*, *console*, *posix*, and *xbox*. You may optionally set the subsystem version also. Numeric values are also accepted for *which*. [This option is specific to the i386 PE targeted port of the linker]

The following options set flags in the `DllCharacteristics` field of the PE file header: [These options are specific to PE targeted ports of the linker]

--dynamicbase
 The image base address may be relocated using address space layout randomization (ASLR). This feature was introduced with MS Windows Vista for i386 PE targets.

--forceinteg
 Code integrity checks are enforced.

--nxcompat
 The image is compatible with the Data Execution Prevention. This feature was introduced with MS Windows XP SP2 for i386 PE targets.

--no-isolation
 Although the image understands isolation, do not isolate the image.

--no-seh The image does not use SEH. No SE handler may be called from this image.

--no-bind
 Do not bind this image.

--wdmdriver
 The driver uses the MS Windows Driver Model.

--tsaware
 The image is Terminal Server aware.

2.1.2 Options specific to C6X uClinux targets

The C6X uClinux target uses a binary format called DSBT to support shared libraries. Each shared library in the system needs to have a unique index; all executables use an index of 0.

--dsbt-size *size*

This option sets the number of entries in the DSBT of the current executable or shared library to *size*. The default is to create a table with 64 entries.

--dsbt-index *index*

This option sets the DSBT index of the current executable or shared library to *index*. The default is 0, which is appropriate for generating executables. If a shared library is generated with a DSBT index of 0, the `R_C6000_DSBT_INDEX` relocs are copied into the output file.

The ‘`--no-merge-exidx-entries`’ switch disables the merging of adjacent `exidx` entries in frame unwind info.

2.1.3 Options specific to Motorola 68HC11 and 68HC12 targets

The 68HC11 and 68HC12 linkers support specific options to control the memory bank switching mapping and trampoline code generation.

--no-trampoline

This option disables the generation of trampoline. By default a trampoline is generated for each far function which is called using a `jsr` instruction (this happens when a pointer to a far function is taken).

--bank-window *name*

This option indicates to the linker the name of the memory region in the ‘`MEMORY`’ specification that describes the memory bank window. The definition of such region is then used by the linker to compute paging and addresses within the memory window.

2.1.4 Options specific to Motorola 68K target

The following options are supported to control handling of GOT generation when linking for 68K targets.

--got=*type*

This option tells the linker which GOT generation scheme to use. *type* should be one of ‘`single`’, ‘`negative`’, ‘`multigot`’ or ‘`target`’. For more information refer to the Info entry for ‘`ld`’.

2.2 Environment Variables

You can change the behaviour of `ld` with the environment variables `GNUTARGET`, `LDEMULATION` and `COLLECT_NO_DEMANGLE`.

`GNUTARGET` determines the input-file object format if you don’t use ‘`-b`’ (or its synonym ‘`--format`’). Its value should be one of the BFD names for an input format (see [Chapter 5 \[BFD\], page 97](#)). If there is no `GNUTARGET` in the environment, `ld` uses the natural format of the target. If `GNUTARGET` is set to `default` then BFD attempts to discover the input format by examining binary input files; this method often succeeds, but there are potential ambiguities, since there is no method of ensuring that the magic number used to specify object-file formats is unique. However, the configuration procedure for BFD on each system places the conventional format for that system first in the search-list, so ambiguities are resolved in favor of convention.

`LDEMULATION` determines the default emulation if you don't use the `'-m'` option. The emulation can affect various aspects of linker behaviour, particularly the default linker script. You can list the available emulations with the `'--verbose'` or `'-V'` options. If the `'-m'` option is not used, and the `LDEMULATION` environment variable is not defined, the default emulation depends upon how the linker was configured.

Normally, the linker will default to demangling symbols. However, if `COLLECT_NO_DEMANGLE` is set in the environment, then it will default to not demangling symbols. This environment variable is used in a similar fashion by the `gcc` linker wrapper program. The default may be overridden by the `'--demangle'` and `'--no-demangle'` options.

3 Linker Scripts

Every link is controlled by a *linker script*. This script is written in the linker command language.

The main purpose of the linker script is to describe how the sections in the input files should be mapped into the output file, and to control the memory layout of the output file. Most linker scripts do nothing more than this. However, when necessary, the linker script can also direct the linker to perform many other operations, using the commands described below.

The linker always uses a linker script. If you do not supply one yourself, the linker will use a default script that is compiled into the linker executable. You can use the ‘`--verbose`’ command line option to display the default linker script. Certain command line options, such as ‘`-r`’ or ‘`-N`’, will affect the default linker script.

You may supply your own linker script by using the ‘`-T`’ command line option. When you do this, your linker script will replace the default linker script.

You may also use linker scripts implicitly by naming them as input files to the linker, as though they were files to be linked. See [Section 3.11 \[Implicit Linker Scripts\]](#), page 78.

3.1 Basic Linker Script Concepts

We need to define some basic concepts and vocabulary in order to describe the linker script language.

The linker combines input files into a single output file. The output file and each input file are in a special data format known as an *object file format*. Each file is called an *object file*. The output file is often called an *executable*, but for our purposes we will also call it an object file. Each object file has, among other things, a list of *sections*. We sometimes refer to a section in an input file as an *input section*; similarly, a section in the output file is an *output section*.

Each section in an object file has a name and a size. Most sections also have an associated block of data, known as the *section contents*. A section may be marked as *loadable*, which means that the contents should be loaded into memory when the output file is run. A section with no contents may be *allocatable*, which means that an area in memory should be set aside, but nothing in particular should be loaded there (in some cases this memory must be zeroed out). A section which is neither loadable nor allocatable typically contains some sort of debugging information.

Every loadable or allocatable output section has two addresses. The first is the *VMA*, or virtual memory address. This is the address the section will have when the output file is run. The second is the *LMA*, or load memory address. This is the address at which the section will be loaded. In most cases the two addresses will be the same. An example of when they might be different is when a data section is loaded into ROM, and then copied into RAM when the program starts up (this technique is often used to initialize global variables in a ROM based system). In this case the ROM address would be the LMA, and the RAM address would be the VMA.

You can see the sections in an object file by using the `objdump` program with the ‘`-h`’ option.

Every object file also has a list of *symbols*, known as the *symbol table*. A symbol may be defined or undefined. Each symbol has a name, and each defined symbol has an address,

among other information. If you compile a C or C++ program into an object file, you will get a defined symbol for every defined function and global or static variable. Every undefined function or global variable which is referenced in the input file will become an undefined symbol.

You can see the symbols in an object file by using the `nm` program, or by using the `objdump` program with the `‘-t’` option.

3.2 Linker Script Format

Linker scripts are text files.

You write a linker script as a series of commands. Each command is either a keyword, possibly followed by arguments, or an assignment to a symbol. You may separate commands using semicolons. Whitespace is generally ignored.

Strings such as file or format names can normally be entered directly. If the file name contains a character such as a comma which would otherwise serve to separate file names, you may put the file name in double quotes. There is no way to use a double quote character in a file name.

You may include comments in linker scripts just as in C, delimited by `‘/*’` and `‘*/’`. As in C, comments are syntactically equivalent to whitespace.

3.3 Simple Linker Script Example

Many linker scripts are fairly simple.

The simplest possible linker script has just one command: `‘SECTIONS’`. You use the `‘SECTIONS’` command to describe the memory layout of the output file.

The `‘SECTIONS’` command is a powerful command. Here we will describe a simple use of it. Let’s assume your program consists only of code, initialized data, and uninitialized data. These will be in the `‘.text’`, `‘.data’`, and `‘.bss’` sections, respectively. Let’s assume further that these are the only sections which appear in your input files.

For this example, let’s say that the code should be loaded at address 0x10000, and that the data should start at address 0x8000000. Here is a linker script which will do that:

```
SECTIONS
{
    . = 0x10000;
    .text : { *(.text) }
    . = 0x8000000;
    .data : { *(.data) }
    .bss : { *(.bss) }
}
```

You write the `‘SECTIONS’` command as the keyword `‘SECTIONS’`, followed by a series of symbol assignments and output section descriptions enclosed in curly braces.

The first line inside the `‘SECTIONS’` command of the above example sets the value of the special symbol `‘.’`, which is the location counter. If you do not specify the address of an output section in some other way (other ways are described later), the address is set from the current value of the location counter. The location counter is then incremented by the size of the output section. At the start of the `‘SECTIONS’` command, the location counter has the value `‘0’`.

The second line defines an output section, `‘.text’`. The colon is required syntax which may be ignored for now. Within the curly braces after the output section name, you list the names of the input sections which should be placed into this output section. The `‘*’` is a wildcard which matches any file name. The expression `‘*(.text)’` means all `‘.text’` input sections in all input files.

Since the location counter is `‘0x10000’` when the output section `‘.text’` is defined, the linker will set the address of the `‘.text’` section in the output file to be `‘0x10000’`.

The remaining lines define the `‘.data’` and `‘.bss’` sections in the output file. The linker will place the `‘.data’` output section at address `‘0x8000000’`. After the linker places the `‘.data’` output section, the value of the location counter will be `‘0x8000000’` plus the size of the `‘.data’` output section. The effect is that the linker will place the `‘.bss’` output section immediately after the `‘.data’` output section in memory.

The linker will ensure that each output section has the required alignment, by increasing the location counter if necessary. In this example, the specified addresses for the `‘.text’` and `‘.data’` sections will probably satisfy any alignment constraints, but the linker may have to create a small gap between the `‘.data’` and `‘.bss’` sections.

That’s it! That’s a simple and complete linker script.

3.4 Simple Linker Script Commands

In this section we describe the simple linker script commands.

3.4.1 Setting the Entry Point

The first instruction to execute in a program is called the *entry point*. You can use the `ENTRY` linker script command to set the entry point. The argument is a symbol name:

```
ENTRY(symbol)
```

There are several ways to set the entry point. The linker will set the entry point by trying each of the following methods in order, and stopping when one of them succeeds:

- the `‘-e’` *entry* command-line option;
- the `ENTRY(symbol)` command in a linker script;
- the value of a target specific symbol, if it is defined; For many targets this is `start`, but PE and BeOS based systems for example check a list of possible entry symbols, matching the first one found.
- the address of the first byte of the `‘.text’` section, if present;
- The address 0.

3.4.2 Commands Dealing with Files

Several linker script commands deal with files.

```
INCLUDE filename
```

Include the linker script *filename* at this point. The file will be searched for in the current directory, and in any directory specified with the `‘-L’` option. You can nest calls to `INCLUDE` up to 10 levels deep.

You can place `INCLUDE` directives at the top level, in `MEMORY` or `SECTIONS` commands, or in output section descriptions.

```
INPUT(file, file, ...)
INPUT(file file ...)
```

The `INPUT` command directs the linker to include the named files in the link, as though they were named on the command line.

For example, if you always want to include ‘`subr.o`’ any time you do a link, but you can’t be bothered to put it on every link command line, then you can put ‘`INPUT (subr.o)`’ in your linker script.

In fact, if you like, you can list all of your input files in the linker script, and then invoke the linker with nothing but a ‘`-T`’ option.

In case a *sysroot prefix* is configured, and the filename starts with the ‘`/`’ character, and the script being processed was located inside the *sysroot prefix*, the filename will be looked for in the *sysroot prefix*. Otherwise, the linker will try to open the file in the current directory. If it is not found, the linker will search through the archive library search path. See the description of ‘`-L`’ in [Section 2.1 \[Command Line Options\], page 3](#).

If you use ‘`INPUT (-lfile)`’, `ld` will transform the name to `libfile.a`, as with the command line argument ‘`-l`’.

When you use the `INPUT` command in an implicit linker script, the files will be included in the link at the point at which the linker script file is included. This can affect archive searching.

```
GROUP(file, file, ...)
GROUP(file file ...)
```

The `GROUP` command is like `INPUT`, except that the named files should all be archives, and they are searched repeatedly until no new undefined references are created. See the description of ‘`-`’ in [Section 2.1 \[Command Line Options\], page 3](#).

```
AS_NEEDED(file, file, ...)
AS_NEEDED(file file ...)
```

This construct can appear only inside of the `INPUT` or `GROUP` commands, among other filenames. The files listed will be handled as if they appear directly in the `INPUT` or `GROUP` commands, with the exception of ELF shared libraries, that will be added only when they are actually needed. This construct essentially enables ‘`--as-needed`’ option for all the files listed inside of it and restores previous ‘`--as-needed`’ resp. ‘`--no-as-needed`’ setting afterwards.

```
OUTPUT(filename)
```

The `OUTPUT` command names the output file. Using `OUTPUT(filename)` in the linker script is exactly like using ‘`-o filename`’ on the command line (see [Section 2.1 \[Command Line Options\], page 3](#)). If both are used, the command line option takes precedence.

You can use the `OUTPUT` command to define a default name for the output file other than the usual default of ‘`a.out`’.

```
SEARCH_DIR(path)
```

The `SEARCH_DIR` command adds *path* to the list of paths where `ld` looks for archive libraries. Using `SEARCH_DIR(path)` is exactly like using ‘`-L path`’ on

the command line (see [Section 2.1 \[Command Line Options\]](#), page 3). If both are used, then the linker will search both paths. Paths specified using the command line option are searched first.

STARTUP(*filename*)

The **STARTUP** command is just like the **INPUT** command, except that *filename* will become the first input file to be linked, as though it were specified first on the command line. This may be useful when using a system in which the entry point is always the start of the first file.

3.4.3 Commands Dealing with Object File Formats

A couple of linker script commands deal with object file formats.

OUTPUT_FORMAT(*bfdname*)

OUTPUT_FORMAT(*default*, *big*, *little*)

The **OUTPUT_FORMAT** command names the BFD format to use for the output file (see [Chapter 5 \[BFD\]](#), page 97). Using **OUTPUT_FORMAT(*bfdname*)** is exactly like using ‘**--oformat *bfdname***’ on the command line (see [Section 2.1 \[Command Line Options\]](#), page 3). If both are used, the command line option takes precedence.

You can use **OUTPUT_FORMAT** with three arguments to use different formats based on the ‘**-EB**’ and ‘**-EL**’ command line options. This permits the linker script to set the output format based on the desired endianness.

If neither ‘**-EB**’ nor ‘**-EL**’ are used, then the output format will be the first argument, *default*. If ‘**-EB**’ is used, the output format will be the second argument, *big*. If ‘**-EL**’ is used, the output format will be the third argument, *little*.

For example, the default linker script for the MIPS ELF target uses this command:

```
OUTPUT_FORMAT(elf32-bigmips, elf32-bigmips, elf32-littlemips)
```

This says that the default format for the output file is ‘**elf32-bigmips**’, but if the user uses the ‘**-EL**’ command line option, the output file will be created in the ‘**elf32-littlemips**’ format.

TARGET(*bfdname*)

The **TARGET** command names the BFD format to use when reading input files. It affects subsequent **INPUT** and **GROUP** commands. This command is like using ‘**-b *bfdname***’ on the command line (see [Section 2.1 \[Command Line Options\]](#), page 3). If the **TARGET** command is used but **OUTPUT_FORMAT** is not, then the last **TARGET** command is also used to set the format for the output file. See [Chapter 5 \[BFD\]](#), page 97.

3.4.4 Assign alias names to memory regions

Alias names can be added to existing memory regions created with the [Section 3.7 \[MEMORY\]](#), page 63 command. Each name corresponds to at most one memory region.

REGION_ALIAS(*alias*, *region*)

The **REGION_ALIAS** function creates an alias name *alias* for the memory region *region*. This allows a flexible mapping of output sections to memory regions. An example follows.

Suppose we have an application for embedded systems which come with various memory storage devices. All have a general purpose, volatile memory **RAM** that allows code execution or data storage. Some may have a read-only, non-volatile memory **ROM** that allows code execution and read-only data access. The last variant is a read-only, non-volatile memory **ROM2** with read-only data access and no code execution capability. We have four output sections:

- **.text** program code;
- **.rodata** read-only data;
- **.data** read-write initialized data;
- **.bss** read-write zero initialized data.

The goal is to provide a linker command file that contains a system independent part defining the output sections and a system dependent part mapping the output sections to the memory regions available on the system. Our embedded systems come with three different memory setups **A**, **B** and **C**:

Section	Variant A	Variant B	Variant C
.text	RAM	ROM	ROM
.rodata	RAM	ROM	ROM2
.data	RAM	RAM/ROM	RAM/ROM2
.bss	RAM	RAM	RAM

The notation **RAM/ROM** or **RAM/ROM2** means that this section is loaded into region **ROM** or **ROM2** respectively. Please note that the load address of the **.data** section starts in all three variants at the end of the **.rodata** section.

The base linker script that deals with the output sections follows. It includes the system dependent **linkcmds.memory** file that describes the memory layout:

```
INCLUDE linkcmds.memory

SECTIONS
{
    .text :
    {
        *(.text)
    } > REGION_TEXT
    .rodata :
    {
        *(.rodata)
        rodata_end = .;
    } > REGION_RODATA
    .data : AT (rodata_end)
    {
        data_start = .;
        *(.data)
    } > REGION_DATA
    data_size = SIZEOF(.data);
    data_load_start = LOADADDR(.data);
    .bss :
    {
        *(.bss)
    } > REGION_BSS
}
```

Now we need three different `linkcmds.memory` files to define memory regions and alias names. The content of `linkcmds.memory` for the three variants A, B and C:

A Here everything goes into the RAM.

```
MEMORY
{
    RAM : ORIGIN = 0, LENGTH = 4M
}

REGION_ALIAS("REGION_TEXT", RAM);
REGION_ALIAS("REGION_RODATA", RAM);
REGION_ALIAS("REGION_DATA", RAM);
REGION_ALIAS("REGION_BSS", RAM);
```

B Program code and read-only data go into the ROM. Read-write data goes into the RAM. An image of the initialized data is loaded into the ROM and will be copied during system start into the RAM.

```
MEMORY
{
    ROM : ORIGIN = 0, LENGTH = 3M
    RAM : ORIGIN = 0x10000000, LENGTH = 1M
}

REGION_ALIAS("REGION_TEXT", ROM);
REGION_ALIAS("REGION_RODATA", ROM);
REGION_ALIAS("REGION_DATA", RAM);
REGION_ALIAS("REGION_BSS", RAM);
```

C Program code goes into the ROM. Read-only data goes into the ROM2. Read-write data goes into the RAM. An image of the initialized data is loaded into the ROM2 and will be copied during system start into the RAM.

```
MEMORY
{
    ROM : ORIGIN = 0, LENGTH = 2M
    ROM2 : ORIGIN = 0x10000000, LENGTH = 1M
    RAM : ORIGIN = 0x20000000, LENGTH = 1M
}

REGION_ALIAS("REGION_TEXT", ROM);
REGION_ALIAS("REGION_RODATA", ROM2);
REGION_ALIAS("REGION_DATA", RAM);
REGION_ALIAS("REGION_BSS", RAM);
```

It is possible to write a common system initialization routine to copy the `.data` section from ROM or ROM2 into the RAM if necessary:

```
#include <string.h>

extern char data_start [];
extern char data_size [];
extern char data_load_start [];

void copy_data(void)
{
    if (data_start != data_load_start)
    {
        memcpy(data_start, data_load_start, (size_t) data_size);
    }
}
```

```
}
```

3.4.5 Other Linker Script Commands

There are a few other linker scripts commands.

ASSERT(*exp*, *message*)

Ensure that *exp* is non-zero. If it is zero, then exit the linker with an error code, and print *message*.

EXTERN(*symbol symbol ...*)

Force *symbol* to be entered in the output file as an undefined symbol. Doing this may, for example, trigger linking of additional modules from standard libraries. You may list several *symbols* for each **EXTERN**, and you may use **EXTERN** multiple times. This command has the same effect as the ‘-u’ command-line option.

FORCE_COMMON_ALLOCATION

This command has the same effect as the ‘-d’ command-line option: to make **ld** assign space to common symbols even if a relocatable output file is specified (‘-r’).

INHIBIT_COMMON_ALLOCATION

This command has the same effect as the ‘--no-define-common’ command-line option: to make **ld** omit the assignment of addresses to common symbols even for a non-relocatable output file.

INSERT [AFTER | BEFORE] *output_section*

This command is typically used in a script specified by ‘-T’ to augment the default **SECTIONS** with, for example, overlays. It inserts all prior linker script statements after (or before) *output_section*, and also causes ‘-T’ to not override the default linker script. The exact insertion point is as for orphan sections. See [Section 3.10.5 \[Location Counter\]](#), page 70. The insertion happens after the linker has mapped input sections to output sections. Prior to the insertion, since ‘-T’ scripts are parsed before the default linker script, statements in the ‘-T’ script occur before the default linker script statements in the internal linker representation of the script. In particular, input section assignments will be made to ‘-T’ output sections before those in the default script. Here is an example of how a ‘-T’ script using **INSERT** might look:

```
SECTIONS
{
  OVERLAY :
  {
    .ov1 { ov1*(.text) }
    .ov2 { ov2*(.text) }
  }
}
INSERT AFTER .text;
```

NOCROSSREFS(*section section ...*)

This command may be used to tell **ld** to issue an error about any references among certain output sections.

In certain types of programs, particularly on embedded systems when using overlays, when one section is loaded into memory, another section will not be.

Any direct references between the two sections would be errors. For example, it would be an error if code in one section called a function defined in the other section.

The `NOCROSSREFS` command takes a list of output section names. If `ld` detects any cross references between the sections, it reports an error and returns a non-zero exit status. Note that the `NOCROSSREFS` command uses output section names, not input section names.

`OUTPUT_ARCH(bfdarch)`

Specify a particular output machine architecture. The argument is one of the names used by the BFD library (see [Chapter 5 \[BFD\]](#), page 97). You can see the architecture of an object file by using the `objdump` program with the `‘-f’` option.

`LD_FEATURE(string)`

This command may be used to modify `ld` behavior. If *string* is `"SANE_EXPR"` then absolute symbols and numbers in a script are simply treated as numbers everywhere. See [Section 3.10.8 \[Expression Section\]](#), page 73.

3.5 Assigning Values to Symbols

You may assign a value to a symbol in a linker script. This will define the symbol and place it into the symbol table with a global scope.

3.5.1 Simple Assignments

You may assign to a symbol using any of the C assignment operators:

```
symbol = expression ;
symbol += expression ;
symbol -= expression ;
symbol *= expression ;
symbol /= expression ;
symbol <<= expression ;
symbol >>= expression ;
symbol &= expression ;
symbol |= expression ;
```

The first case will define *symbol* to the value of *expression*. In the other cases, *symbol* must already be defined, and the value will be adjusted accordingly.

The special symbol name `‘.’` indicates the location counter. You may only use this within a `SECTIONS` command. See [Section 3.10.5 \[Location Counter\]](#), page 70.

The semicolon after *expression* is required.

Expressions are defined below; see [Section 3.10 \[Expressions\]](#), page 69.

You may write symbol assignments as commands in their own right, or as statements within a `SECTIONS` command, or as part of an output section description in a `SECTIONS` command.

The section of the symbol will be set from the section of the expression; for more information, see [Section 3.10.8 \[Expression Section\]](#), page 73.

Here is an example showing the three different places that symbol assignments may be used:

```
floating_point = 0;
SECTIONS
{
    .text :
    {
        *(.text)
        _etext = .;
    }
    _bdata = (. + 3) & ~ 3;
    .data : { *(.data) }
}
```

In this example, the symbol ‘floating_point’ will be defined as zero. The symbol ‘_etext’ will be defined as the address following the last ‘.text’ input section. The symbol ‘_bdata’ will be defined as the address following the ‘.text’ output section aligned upward to a 4 byte boundary.

3.5.2 HIDDEN

For ELF targeted ports, define a symbol that will be hidden and won’t be exported. The syntax is `HIDDEN(symbol = expression)`.

Here is the example from [Section 3.5.1 \[Simple Assignments\]](#), [page 47](#), rewritten to use `HIDDEN`:

```
HIDDEN(floating_point = 0);
SECTIONS
{
    .text :
    {
        *(.text)
        HIDDEN(_etext = .);
    }
    HIDDEN(_bdata = (. + 3) & ~ 3);
    .data : { *(.data) }
}
```

In this case none of the three symbols will be visible outside this module.

3.5.3 PROVIDE

In some cases, it is desirable for a linker script to define a symbol only if it is referenced and is not defined by any object included in the link. For example, traditional linkers defined the symbol ‘etext’. However, ANSI C requires that the user be able to use ‘etext’ as a function name without encountering an error. The `PROVIDE` keyword may be used to define a symbol, such as ‘etext’, only if it is referenced but not defined. The syntax is `PROVIDE(symbol = expression)`.

Here is an example of using `PROVIDE` to define ‘etext’:

```
SECTIONS
{
    .text :
    {
        *(.text)
        _etext = .;
        PROVIDE(etext = .);
    }
}
```

In this example, if the program defines ‘`_etext`’ (with a leading underscore), the linker will give a multiple definition error. If, on the other hand, the program defines ‘`etext`’ (with no leading underscore), the linker will silently use the definition in the program. If the program references ‘`etext`’ but does not define it, the linker will use the definition in the linker script.

3.5.4 PROVIDE_HIDDEN

Similar to `PROVIDE`. For ELF targeted ports, the symbol will be hidden and won’t be exported.

3.5.5 Source Code Reference

Accessing a linker script defined variable from source code is not intuitive. In particular a linker script symbol is not equivalent to a variable declaration in a high level language, it is instead a symbol that does not have a value.

Before going further, it is important to note that compilers often transform names in the source code into different names when they are stored in the symbol table. For example, Fortran compilers commonly prepend or append an underscore, and C++ performs extensive ‘*name mangling*’. Therefore there might be a discrepancy between the name of a variable as it is used in source code and the name of the same variable as it is defined in a linker script. For example in C a linker script variable might be referred to as:

```
extern int foo;
```

But in the linker script it might be defined as:

```
_foo = 1000;
```

In the remaining examples however it is assumed that no name transformation has taken place.

When a symbol is declared in a high level language such as C, two things happen. The first is that the compiler reserves enough space in the program’s memory to hold the *value* of the symbol. The second is that the compiler creates an entry in the program’s symbol table which holds the symbol’s *address*. ie the symbol table contains the address of the block of memory holding the symbol’s value. So for example the following C declaration, at file scope:

```
int foo = 1000;
```

creates a entry called ‘`foo`’ in the symbol table. This entry holds the address of an ‘`int`’ sized block of memory where the number 1000 is initially stored.

When a program references a symbol the compiler generates code that first accesses the symbol table to find the address of the symbol’s memory block and then code to read the value from that memory block. So:

```
foo = 1;
```

looks up the symbol ‘`foo`’ in the symbol table, gets the address associated with this symbol and then writes the value 1 into that address. Whereas:

```
int * a = &foo;
```

looks up the symbol ‘`foo`’ in the symbol table, gets it address and then copies this address into the block of memory associated with the variable ‘`a`’.

Linker scripts symbol declarations, by contrast, create an entry in the symbol table but do not assign any memory to them. Thus they are an address without a value. So for example the linker script definition:

```
foo = 1000;
```

creates an entry in the symbol table called ‘foo’ which holds the address of memory location 1000, but nothing special is stored at address 1000. This means that you cannot access the *value* of a linker script defined symbol - it has no value - all you can do is access the *address* of a linker script defined symbol.

Hence when you are using a linker script defined symbol in source code you should always take the address of the symbol, and never attempt to use its value. For example suppose you want to copy the contents of a section of memory called .ROM into a section called .FLASH and the linker script contains these declarations:

```
start_of_ROM    = .ROM;
end_of_ROM      = .ROM + sizeof (.ROM) - 1;
start_of_FLASH  = .FLASH;
```

Then the C source code to perform the copy would be:

```
extern char start_of_ROM, end_of_ROM, start_of_FLASH;

memcpy (& start_of_FLASH, & start_of_ROM, & end_of_ROM - & start_of_ROM);
```

Note the use of the ‘&’ operators. These are correct.

3.6 SECTIONS Command

The **SECTIONS** command tells the linker how to map input sections into output sections, and how to place the output sections in memory.

The format of the **SECTIONS** command is:

```
SECTIONS
{
    sections-command
    sections-command
    ...
}
```

Each *sections-command* may be one of the following:

- an **ENTRY** command (see [Section 3.4.1 \[Entry command\]](#), page 41)
- a symbol assignment (see [Section 3.5 \[Assignments\]](#), page 47)
- an output section description
- an overlay description

The **ENTRY** command and symbol assignments are permitted inside the **SECTIONS** command for convenience in using the location counter in those commands. This can also make the linker script easier to understand because you can use those commands at meaningful points in the layout of the output file.

Output section descriptions and overlay descriptions are described below.

If you do not use a **SECTIONS** command in your linker script, the linker will place each input section into an identically named output section in the order that the sections are first encountered in the input files. If all input sections are present in the first file, for example, the order of sections in the output file will match the order in the first input file. The first section will be at address zero.

3.6.1 Output Section Description

The full description of an output section looks like this:

```
section [address] [(type)] :
    [AT(lma)]
    [ALIGN(section_align)]
    [SUBALIGN(subsection_align)]
    [constraint]
    {
        output-section-command
        output-section-command
        ...
    } [>region] [AT>lma_region] [:phdr :phdr ...] [=fillexp]
```

Most output sections do not use most of the optional section attributes.

The whitespace around *section* is required, so that the section name is unambiguous. The colon and the curly braces are also required. The line breaks and other white space are optional.

Each *output-section-command* may be one of the following:

- a symbol assignment (see [Section 3.5 \[Assignments\]](#), page 47)
- an input section description (see [Section 3.6.4 \[Input Section\]](#), page 52)
- data values to include directly (see [Section 3.6.5 \[Output Section Data\]](#), page 56)
- a special output section keyword (see [Section 3.6.6 \[Output Section Keywords\]](#), page 57)

3.6.2 Output Section Name

The name of the output section is *section*. *section* must meet the constraints of your output format. In formats which only support a limited number of sections, such as `a.out`, the name must be one of the names supported by the format (`a.out`, for example, allows only `.text`, `.data` or `.bss`). If the output format supports any number of sections, but with numbers and not names (as is the case for Oasys), the name should be supplied as a quoted numeric string. A section name may consist of any sequence of characters, but a name which contains any unusual characters such as commas must be quoted.

The output section name `/DISCARD/` is special; [Section 3.6.7 \[Output Section Discarding\]](#), page 58.

3.6.3 Output Section Address

The *address* is an expression for the VMA (the virtual memory address) of the output section. This address is optional, but if it is provided then the output address will be set exactly as specified.

If the output address is not specified then one will be chosen for the section, based on the heuristic below. This address will be adjusted to fit the alignment requirement of the output section. The alignment requirement is the strictest alignment of any input section contained within the output section.

The output section address heuristic is as follows:

- If an output memory *region* is set for the section then it is added to this region and its address will be the next free address in that region.
- If the MEMORY command has been used to create a list of memory regions then the first region which has attributes compatible with the section is selected to contain it.

The section's output address will be the next free address in that region; [Section 3.7 \[MEMORY\]](#), page 63.

- If no memory regions were specified, or none match the section then the output address will be based on the current value of the location counter.

For example:

```
.text : { *(.text) }
```

and

```
.text : { *(.text) }
```

are subtly different. The first will set the address of the `.text` output section to the current value of the location counter. The second will set it to the current value of the location counter aligned to the strictest alignment of any of the `.text` input sections.

The *address* may be an arbitrary expression; [Section 3.10 \[Expressions\]](#), page 69. For example, if you want to align the section on a 0x10 byte boundary, so that the lowest four bits of the section address are zero, you could do something like this:

```
.text ALIGN(0x10) : { *(.text) }
```

This works because `ALIGN` returns the current location counter aligned upward to the specified value.

Specifying *address* for a section will change the value of the location counter, provided that the section is non-empty. (Empty sections are ignored).

3.6.4 Input Section Description

The most common output section command is an input section description.

The input section description is the most basic linker script operation. You use output sections to tell the linker how to lay out your program in memory. You use input section descriptions to tell the linker how to map the input files into your memory layout.

3.6.4.1 Input Section Basics

An input section description consists of a file name optionally followed by a list of section names in parentheses.

The file name and the section name may be wildcard patterns, which we describe further below (see [Section 3.6.4.2 \[Input Section Wildcards\]](#), page 54).

The most common input section description is to include all input sections with a particular name in the output section. For example, to include all input `.text` sections, you would write:

```
*(.text)
```

Here the `*` is a wildcard which matches any file name. To exclude a list of files from matching the file name wildcard, `EXCLUDE_FILE` may be used to match all files except the ones specified in the `EXCLUDE_FILE` list. For example:

```
*(EXCLUDE_FILE (*crtend.o *otherfile.o) .ctors)
```

will cause all `.ctors` sections from all files except `crtend.o` and `otherfile.o` to be included.

There are two ways to include more than one section:

```
*(.text .rdata)
*(.text) *(.rdata)
```

The difference between these is the order in which the `‘.text’` and `‘.rdata’` input sections will appear in the output section. In the first example, they will be intermingled, appearing in the same order as they are found in the linker input. In the second example, all `‘.text’` input sections will appear first, followed by all `‘.rdata’` input sections.

You can specify a file name to include sections from a particular file. You would do this if one or more of your files contain special data that needs to be at a particular location in memory. For example:

```
data.o(.data)
```

To refine the sections that are included based on the section flags of an input section, `INPUT_SECTION_FLAGS` may be used.

Here is a simple example for using Section header flags for ELF sections:

```
SECTIONS {
    .text : { INPUT_SECTION_FLAGS (SHF_MERGE & SHF_STRINGS) *(.text) }
    .text2 : { INPUT_SECTION_FLAGS (!SHF_WRITE) *(.text) }
}
```

In this example, the output section `‘.text’` will be comprised of any input section matching the name `*(.text)` whose section header flags `SHF_MERGE` and `SHF_STRINGS` are set. The output section `‘.text2’` will be comprised of any input section matching the name `*(.text)` whose section header flag `SHF_WRITE` is clear.

You can also specify files within archives by writing a pattern matching the archive, a colon, then the pattern matching the file, with no whitespace around the colon.

```
‘archive:file’    matches file within archive
‘archive:’        matches the whole archive
‘:file’           matches file but not one in an archive
```

Either one or both of `‘archive’` and `‘file’` can contain shell wildcards. On DOS based file systems, the linker will assume that a single letter followed by a colon is a drive specifier, so `‘c:myfile.o’` is a simple file specification, not `‘myfile.o’` within an archive called `‘c’`. `‘archive:file’` filespecs may also be used within an `EXCLUDE_FILE` list, but may not appear in other linker script contexts. For instance, you cannot extract a file from an archive by using `‘archive:file’` in an `INPUT` command.

If you use a file name without a list of sections, then all sections in the input file will be included in the output section. This is not commonly done, but it may be useful on occasion. For example:

```
data.o
```

When you use a file name which is not an `‘archive:file’` specifier and does not contain any wild card characters, the linker will first see if you also specified the file name on the linker command line or in an `INPUT` command. If you did not, the linker will attempt to open the file as an input file, as though it appeared on the command line. Note that this differs from an `INPUT` command, because the linker will not search for the file in the archive search path.

3.6.4.2 Input Section Wildcard Patterns

In an input section description, either the file name or the section name or both may be wildcard patterns.

The file name of ‘*’ seen in many examples is a simple wildcard pattern for the file name. The wildcard patterns are like those used by the Unix shell.

- ‘*’ matches any number of characters
- ‘?’ matches any single character
- ‘[chars]’ matches a single instance of any of the *chars*; the ‘-’ character may be used to specify a range of characters, as in ‘[a-z]’ to match any lower case letter
- ‘\’ quotes the following character

When a file name is matched with a wildcard, the wildcard characters will not match a ‘/’ character (used to separate directory names on Unix). A pattern consisting of a single ‘*’ character is an exception; it will always match any file name, whether it contains a ‘/’ or not. In a section name, the wildcard characters will match a ‘/’ character.

File name wildcard patterns only match files which are explicitly specified on the command line or in an INPUT command. The linker does not search directories to expand wildcards.

If a file name matches more than one wildcard pattern, or if a file name appears explicitly and is also matched by a wildcard pattern, the linker will use the first match in the linker script. For example, this sequence of input section descriptions is probably in error, because the ‘data.o’ rule will not be used:

```
.data : { *(.data) }
.data1 : { data.o(.data) }
```

Normally, the linker will place files and sections matched by wildcards in the order in which they are seen during the link. You can change this by using the `SORT_BY_NAME` keyword, which appears before a wildcard pattern in parentheses (e.g., `SORT_BY_NAME(.text*)`). When the `SORT_BY_NAME` keyword is used, the linker will sort the files or sections into ascending order by name before placing them in the output file.

`SORT_BY_ALIGNMENT` is very similar to `SORT_BY_NAME`. The difference is `SORT_BY_ALIGNMENT` will sort sections into ascending order by alignment before placing them in the output file.

`SORT_BY_INIT_PRIORITY` is very similar to `SORT_BY_NAME`. The difference is `SORT_BY_INIT_PRIORITY` will sort sections into ascending order by numerical value of the GCC `init_priority` attribute encoded in the section name before placing them in the output file.

`SORT` is an alias for `SORT_BY_NAME`.

When there are nested section sorting commands in linker script, there can be at most 1 level of nesting for section sorting commands.

1. `SORT_BY_NAME (SORT_BY_ALIGNMENT (wildcard section pattern))`. It will sort the input sections by name first, then by alignment if 2 sections have the same name.
2. `SORT_BY_ALIGNMENT (SORT_BY_NAME (wildcard section pattern))`. It will sort the input sections by alignment first, then by name if 2 sections have the same alignment.
3. `SORT_BY_NAME (SORT_BY_NAME (wildcard section pattern))` is treated the same as `SORT_BY_NAME (wildcard section pattern)`.

4. `SORT_BY_ALIGNMENT (SORT_BY_ALIGNMENT (wildcard section pattern))` is treated the same as `SORT_BY_ALIGNMENT (wildcard section pattern)`.
5. All other nested section sorting commands are invalid.

When both command line section sorting option and linker script section sorting command are used, section sorting command always takes precedence over the command line option. If the section sorting command in linker script isn't nested, the command line option will make the section sorting command to be treated as nested sorting command.

1. `SORT_BY_NAME (wildcard section pattern)` with `'--sort-sections alignment'` is equivalent to `SORT_BY_NAME (SORT_BY_ALIGNMENT (wildcard section pattern))`.
2. `SORT_BY_ALIGNMENT (wildcard section pattern)` with `'--sort-section name'` is equivalent to `SORT_BY_ALIGNMENT (SORT_BY_NAME (wildcard section pattern))`.

If the section sorting command in linker script is nested, the command line option will be ignored.

`SORT_NONE` disables section sorting by ignoring the command line section sorting option.

If you ever get confused about where input sections are going, use the `'-M'` linker option to generate a map file. The map file shows precisely how input sections are mapped to output sections.

This example shows how wildcard patterns might be used to partition files. This linker script directs the linker to place all `'.text'` sections in `'.text'` and all `'.bss'` sections in `'.bss'`. The linker will place the `'.data'` section from all files beginning with an upper case character in `'.DATA'`; for all other files, the linker will place the `'.data'` section in `'.data'`.

```
SECTIONS {
    .text : { *(.text) }
    .DATA : { [A-Z]*(.data) }
    .data : { *(.data) }
    .bss : { *(.bss) }
}
```

3.6.4.3 Input Section for Common Symbols

A special notation is needed for common symbols, because in many object file formats common symbols do not have a particular input section. The linker treats common symbols as though they are in an input section named `'COMMON'`.

You may use file names with the `'COMMON'` section just as with any other input sections. You can use this to place common symbols from a particular input file in one section while common symbols from other input files are placed in another section.

In most cases, common symbols in input files will be placed in the `'.bss'` section in the output file. For example:

```
.bss { *(.bss) *(COMMON) }
```

Some object file formats have more than one type of common symbol. For example, the MIPS ELF object file format distinguishes standard common symbols and small common symbols. In this case, the linker will use a different special section name for other types of common symbols. In the case of MIPS ELF, the linker uses `'COMMON'` for standard common symbols and `'.scommon'` for small common symbols. This permits you to map the different types of common symbols into memory at different locations.

You will sometimes see ‘[COMMON]’ in old linker scripts. This notation is now considered obsolete. It is equivalent to ‘*(COMMON)’.

3.6.4.4 Input Section and Garbage Collection

When link-time garbage collection is in use (‘--gc-sections’), it is often useful to mark sections that should not be eliminated. This is accomplished by surrounding an input section’s wildcard entry with `KEEP()`, as in `KEEP(*(.init))` or `KEEP(SORT_BY_NAME(*)(.ctors))`.

3.6.4.5 Input Section Example

The following example is a complete linker script. It tells the linker to read all of the sections from file ‘all.o’ and place them at the start of output section ‘outputa’ which starts at location ‘0x10000’. All of section ‘.input1’ from file ‘foo.o’ follows immediately, in the same output section. All of section ‘.input2’ from ‘foo.o’ goes into output section ‘outputb’, followed by section ‘.input1’ from ‘foo1.o’. All of the remaining ‘.input1’ and ‘.input2’ sections from any files are written to output section ‘outputc’.

```
SECTIONS {
    outputa 0x10000 :
    {
        all.o
        foo.o (.input1)
    }
    outputb :
    {
        foo.o (.input2)
        foo1.o (.input1)
    }
    outputc :
    {
        *(.input1)
        *(.input2)
    }
}
```

3.6.5 Output Section Data

You can include explicit bytes of data in an output section by using `BYTE`, `SHORT`, `LONG`, `QUAD`, or `SQUAD` as an output section command. Each keyword is followed by an expression in parentheses providing the value to store (see [Section 3.10 \[Expressions\]](#), page 69). The value of the expression is stored at the current value of the location counter.

The `BYTE`, `SHORT`, `LONG`, and `QUAD` commands store one, two, four, and eight bytes (respectively). After storing the bytes, the location counter is incremented by the number of bytes stored.

For example, this will store the byte 1 followed by the four byte value of the symbol ‘addr’:

```
BYTE(1)
LONG(addr)
```

When using a 64 bit host or target, `QUAD` and `SQUAD` are the same; they both store an 8 byte, or 64 bit, value. When both host and target are 32 bits, an expression is computed as 32 bits. In this case `QUAD` stores a 32 bit value zero extended to 64 bits, and `SQUAD` stores a 32 bit value sign extended to 64 bits.

If the object file format of the output file has an explicit endianness, which is the normal case, the value will be stored in that endianness. When the object file format does not have an explicit endianness, as is true of, for example, S-records, the value will be stored in the endianness of the first input object file.

Note—these commands only work inside a section description and not between them, so the following will produce an error from the linker:

```
SECTIONS { .text : { *(.text) } LONG(1) .data : { *(.data) } }
```

whereas this will work:

```
SECTIONS { .text : { *(.text) ; LONG(1) } .data : { *(.data) } }
```

You may use the `FILL` command to set the fill pattern for the current section. It is followed by an expression in parentheses. Any otherwise unspecified regions of memory within the section (for example, gaps left due to the required alignment of input sections) are filled with the value of the expression, repeated as necessary. A `FILL` statement covers memory locations after the point at which it occurs in the section definition; by including more than one `FILL` statement, you can have different fill patterns in different parts of an output section.

This example shows how to fill unspecified regions of memory with the value ‘0x90’:

```
FILL(0x90909090)
```

The `FILL` command is similar to the ‘=*fillexp*’ output section attribute, but it only affects the part of the section following the `FILL` command, rather than the entire section. If both are used, the `FILL` command takes precedence. See [Section 3.6.8.8 \[Output Section Fill\]](#), [page 61](#), for details on the fill expression.

3.6.6 Output Section Keywords

There are a couple of keywords which can appear as output section commands.

CREATE_OBJECT_SYMBOLS

The command tells the linker to create a symbol for each input file. The name of each symbol will be the name of the corresponding input file. The section of each symbol will be the output section in which the `CREATE_OBJECT_SYMBOLS` command appears.

This is conventional for the a.out object file format. It is not normally used for any other object file format.

CONSTRUCTORS

When linking using the a.out object file format, the linker uses an unusual set construct to support C++ global constructors and destructors. When linking object file formats which do not support arbitrary sections, such as ECOFF and XCOFF, the linker will automatically recognize C++ global constructors and destructors by name. For these object file formats, the `CONSTRUCTORS` command tells the linker to place constructor information in the output section where the `CONSTRUCTORS` command appears. The `CONSTRUCTORS` command is ignored for other object file formats.

The symbol `__CTOR_LIST__` marks the start of the global constructors, and the symbol `__CTOR_END__` marks the end. Similarly, `__DTOR_LIST__` and `__DTOR_END__` mark the start and end of the global destructors. The first

word in the list is the number of entries, followed by the address of each constructor or destructor, followed by a zero word. The compiler must arrange to actually run the code. For these object file formats GNU C++ normally calls constructors from a subroutine `__main`; a call to `__main` is automatically inserted into the startup code for `main`. GNU C++ normally runs destructors either by using `atexit`, or directly from the function `exit`.

For object file formats such as COFF or ELF which support arbitrary section names, GNU C++ will normally arrange to put the addresses of global constructors and destructors into the `.ctors` and `.dtors` sections. Placing the following sequence into your linker script will build the sort of table which the GNU C++ runtime code expects to see.

```
__CTOR_LIST__ = .;
LONG((__CTOR_END__ - __CTOR_LIST__) / 4 - 2)
*(.ctors)
LONG(0)
__CTOR_END__ = .;
__DTOR_LIST__ = .;
LONG((__DTOR_END__ - __DTOR_LIST__) / 4 - 2)
*(.dtors)
LONG(0)
__DTOR_END__ = .;
```

If you are using the GNU C++ support for initialization priority, which provides some control over the order in which global constructors are run, you must sort the constructors at link time to ensure that they are executed in the correct order. When using the `CONSTRUCTORS` command, use `'SORT_BY_NAME(CONSTRUCTORS)'` instead. When using the `.ctors` and `.dtors` sections, use `'*(SORT_BY_NAME(.ctors))'` and `'*(SORT_BY_NAME(.dtors))'` instead of just `'*(.ctors)'` and `'*(.dtors)'`.

Normally the compiler and linker will handle these issues automatically, and you will not need to concern yourself with them. However, you may need to consider this if you are using C++ and writing your own linker scripts.

3.6.7 Output Section Discarding

The linker will not create output sections with no contents. This is for convenience when referring to input sections that may or may not be present in any of the input files. For example:

```
.foo : { *(.foo) }
```

will only create a `.foo` section in the output file if there is a `.foo` section in at least one input file, and if the input sections are not all empty. Other link script directives that allocate space in an output section will also create the output section.

The linker will ignore address assignments (see [Section 3.6.3 \[Output Section Address\]](#), [page 51](#)) on discarded output sections, except when the linker script defines symbols in the output section. In that case the linker will obey the address assignments, possibly advancing dot even though the section is discarded.

The special output section name `"/DISCARD/"` may be used to discard input sections. Any input sections which are assigned to an output section named `"/DISCARD/"` are not included in the output file.

3.6.8 Output Section Attributes

We showed above that the full description of an output section looked like this:

```
section [address] [(type)] :
    [AT(lma)]
    [ALIGN(section_align)]
    [SUBALIGN(subsection_align)]
    [constraint]
    {
        output-section-command
        output-section-command
        ...
    } [>region] [AT>lma_region] [:phdr :phdr ...] [=fillexp]
```

We’ve already described *section*, *address*, and *output-section-command*. In this section we will describe the remaining section attributes.

3.6.8.1 Output Section Type

Each output section may have a type. The type is a keyword in parentheses. The following types are defined:

NOLOAD	The section should be marked as not loadable, so that it will not be loaded into memory when the program is run.
DSECT	
COPY	
INFO	
OVERLAY	These type names are supported for backward compatibility, and are rarely used. They all have the same effect: the section should be marked as not allocatable, so that no memory is allocated for the section when the program is run.

The linker normally sets the attributes of an output section based on the input sections which map into it. You can override this by using the section type. For example, in the script sample below, the ‘ROM’ section is addressed at memory location ‘0’ and does not need to be loaded when the program is run.

```
SECTIONS {
    ROM 0 (NOLOAD) : { ... }
    ...
}
```

3.6.8.2 Output Section LMA

Every section has a virtual address (VMA) and a load address (LMA); see [Section 3.1 \[Basic Script Concepts\]](#), page 39. The virtual address is specified by the see [Section 3.6.3 \[Output Section Address\]](#), page 51 described earlier. The load address is specified by the AT or AT> keywords. Specifying a load address is optional.

The AT keyword takes an expression as an argument. This specifies the exact load address of the section. The AT> keyword takes the name of a memory region as an argument. See [Section 3.7 \[MEMORY\]](#), page 63. The load address of the section is set to the next free address in the region, aligned to the section’s alignment requirements.

If neither AT nor AT> is specified for an allocatable section, the linker will use the following heuristic to determine the load address:

- If the section has a specific VMA address, then this is used as the LMA address as well.
- If the section is not allocatable then its LMA is set to its VMA.
- Otherwise if a memory region can be found that is compatible with the current section, and this region contains at least one section, then the LMA is set so the difference between the VMA and LMA is the same as the difference between the VMA and LMA of the last section in the located region.
- If no memory regions have been declared then a default region that covers the entire address space is used in the previous step.
- If no suitable region could be found, or there was no previous section then the LMA is set equal to the VMA.

This feature is designed to make it easy to build a ROM image. For example, the following linker script creates three output sections: one called `‘.text’`, which starts at `0x1000`, one called `‘.mdata’`, which is loaded at the end of the `‘.text’` section even though its VMA is `0x2000`, and one called `‘.bss’` to hold uninitialized data at address `0x3000`. The symbol `_data` is defined with the value `0x2000`, which shows that the location counter holds the VMA value, not the LMA value.

```
SECTIONS
{
    .text 0x1000 : { *(.text) _etext = . ; }
    .mdata 0x2000 :
        AT ( ADDR (.text) + SIZEOF (.text) )
        { _data = . ; *(.data); _edata = . ; }
    .bss 0x3000 :
        { _bstart = . ; *(.bss) *(COMMON) ; _bend = . ;}
}
```

The run-time initialization code for use with a program generated with this linker script would include something like the following, to copy the initialized data from the ROM image to its runtime address. Notice how this code takes advantage of the symbols defined by the linker script.

```
extern char _etext, _data, _edata, _bstart, _bend;
char *src = &_etext;
char *dst = &_data;

/* ROM has data at end of text; copy it. */
while (dst < &_edata)
    *dst++ = *src++;

/* Zero bss. */
for (dst = &_bstart; dst < &_bend; dst++)
    *dst = 0;
```

3.6.8.3 Forced Output Alignment

You can increase an output section’s alignment by using `ALIGN`.

3.6.8.4 Forced Input Alignment

You can force input section alignment within an output section by using `SUBALIGN`. The value specified overrides any alignment given by input sections, whether larger or smaller.

3.6.8.5 Output Section Constraint

You can specify that an output section should only be created if all of its input sections are read-only or all of its input sections are read-write by using the keyword `ONLY_IF_RO` and `ONLY_IF_RW` respectively.

3.6.8.6 Output Section Region

You can assign a section to a previously defined region of memory by using `>region`. See [Section 3.7 \[MEMORY\]](#), page 63.

Here is a simple example:

```
MEMORY { rom : ORIGIN = 0x1000, LENGTH = 0x1000 }
SECTIONS { ROM : { *(.text) } >rom }
```

3.6.8.7 Output Section Phdr

You can assign a section to a previously defined program segment by using `:phdr`. See [Section 3.8 \[PHDRS\]](#), page 64. If a section is assigned to one or more segments, then all subsequent allocated sections will be assigned to those segments as well, unless they use an explicitly `:phdr` modifier. You can use `:NONE` to tell the linker to not put the section in any segment at all.

Here is a simple example:

```
PHDRS { text PT_LOAD ; }
SECTIONS { .text : { *(.text) } :text }
```

3.6.8.8 Output Section Fill

You can set the fill pattern for an entire section by using `=fillexp`. *fillexp* is an expression (see [Section 3.10 \[Expressions\]](#), page 69). Any otherwise unspecified regions of memory within the output section (for example, gaps left due to the required alignment of input sections) will be filled with the value, repeated as necessary. If the fill expression is a simple hex number, ie. a string of hex digit starting with `0x` and without a trailing `k` or `M`, then an arbitrarily long sequence of hex digits can be used to specify the fill pattern; Leading zeros become part of the pattern too. For all other cases, including extra parentheses or a unary `+`, the fill pattern is the four least significant bytes of the value of the expression. In all cases, the number is big-endian.

You can also change the fill value with a `FILL` command in the output section commands; (see [Section 3.6.5 \[Output Section Data\]](#), page 56).

Here is a simple example:

```
SECTIONS { .text : { *(.text) } =0x90909090 }
```

3.6.9 Overlay Description

An overlay description provides an easy way to describe sections which are to be loaded as part of a single memory image but are to be run at the same memory address. At run time, some sort of overlay manager will copy the overlaid sections in and out of the runtime memory address as required, perhaps by simply manipulating addressing bits. This approach can be useful, for example, when a certain region of memory is faster than another.

Overlays are described using the `OVERLAY` command. The `OVERLAY` command is used within a `SECTIONS` command, like an output section description. The full syntax of the `OVERLAY` command is as follows:

```

OVERLAY [start] : [NOCROSSREFS] [AT ( ldaddr )]
{
    secname1
    {
        output-section-command
        output-section-command
        ...
    } [:phdr...] [=fill]
    secname2
    {
        output-section-command
        output-section-command
        ...
    } [:phdr...] [=fill]
    ...
} [>region] [:phdr...] [=fill]

```

Everything is optional except **OVERLAY** (a keyword), and each section must have a name (*secname1* and *secname2* above). The section definitions within the **OVERLAY** construct are identical to those within the general **SECTIONS** construct (see [Section 3.6 \[SECTIONS\]](#), [page 50](#)), except that no addresses and no memory regions may be defined for sections within an **OVERLAY**.

The sections are all defined with the same starting address. The load addresses of the sections are arranged such that they are consecutive in memory starting at the load address used for the **OVERLAY** as a whole (as with normal section definitions, the load address is optional, and defaults to the start address; the start address is also optional, and defaults to the current value of the location counter).

If the **NOCROSSREFS** keyword is used, and there any references among the sections, the linker will report an error. Since the sections all run at the same address, it normally does not make sense for one section to refer directly to another. See [Section 3.4.5 \[Miscellaneous Commands\]](#), [page 46](#).

For each section within the **OVERLAY**, the linker automatically provides two symbols. The symbol `__load_start_secname` is defined as the starting load address of the section. The symbol `__load_stop_secname` is defined as the final load address of the section. Any characters within *secname* which are not legal within C identifiers are removed. C (or assembler) code may use these symbols to move the overlaid sections around as necessary.

At the end of the overlay, the value of the location counter is set to the start address of the overlay plus the size of the largest section.

Here is an example. Remember that this would appear inside a **SECTIONS** construct.

```

OVERLAY 0x1000 : AT (0x4000)
{
    .text0 { o1/*.o(.text) }
    .text1 { o2/*.o(.text) }
}

```

This will define both `.text0` and `.text1` to start at address 0x1000. `.text0` will be loaded at address 0x4000, and `.text1` will be loaded immediately after `.text0`. The following symbols will be defined if referenced: `__load_start_text0`, `__load_stop_text0`, `__load_start_text1`, `__load_stop_text1`.

C code to copy overlay `.text1` into the overlay area might look like the following.

```
extern char __load_start_text1, __load_stop_text1;
memcpy ((char *) 0x1000, &__load_start_text1,
        &__load_stop_text1 - &__load_start_text1);
```

Note that the **OVERLAY** command is just syntactic sugar, since everything it does can be done using the more basic commands. The above example could have been written identically as follows.

```
.text0 0x1000 : AT (0x4000) { o1/*.o(.text) }
PROVIDE (__load_start_text0 = LOADADDR (.text0));
PROVIDE (__load_stop_text0 = LOADADDR (.text0) + SIZEOF (.text0));
.text1 0x1000 : AT (0x4000 + SIZEOF (.text0)) { o2/*.o(.text) }
PROVIDE (__load_start_text1 = LOADADDR (.text1));
PROVIDE (__load_stop_text1 = LOADADDR (.text1) + SIZEOF (.text1));
. = 0x1000 + MAX (SIZEOF (.text0), SIZEOF (.text1));
```

3.7 MEMORY Command

The linker's default configuration permits allocation of all available memory. You can override this by using the **MEMORY** command.

The **MEMORY** command describes the location and size of blocks of memory in the target. You can use it to describe which memory regions may be used by the linker, and which memory regions it must avoid. You can then assign sections to particular memory regions. The linker will set section addresses based on the memory regions, and will warn about regions that become too full. The linker will not shuffle sections around to fit into the available regions.

A linker script may contain at most one use of the **MEMORY** command. However, you can define as many blocks of memory within it as you wish. The syntax is:

```
MEMORY
{
    name [(attr)] : ORIGIN = origin, LENGTH = len
    ...
}
```

The *name* is a name used in the linker script to refer to the region. The region name has no meaning outside of the linker script. Region names are stored in a separate name space, and will not conflict with symbol names, file names, or section names. Each memory region must have a distinct name within the **MEMORY** command. However you can add later alias names to existing memory regions with the [Section 3.4.4 \[REGION_ALIAS\], page 43](#) command.

The *attr* string is an optional list of attributes that specify whether to use a particular memory region for an input section which is not explicitly mapped in the linker script. As described in [Section 3.6 \[SECTIONS\], page 50](#), if you do not specify an output section for some input section, the linker will create an output section with the same name as the input section. If you define region attributes, the linker will use them to select the memory region for the output section that it creates.

The *attr* string must consist only of the following characters:

'R'	Read-only section
'W'	Read/write section
'X'	Executable section

'A'	Allocatable section
'I'	Initialized section
'L'	Same as 'I'
'!'	Invert the sense of any of the attributes that follow

If a unmapped section matches any of the listed attributes other than '!', it will be placed in the memory region. The '!' attribute reverses this test, so that an unmapped section will be placed in the memory region only if it does not match any of the listed attributes.

The *origin* is an numerical expression for the start address of the memory region. The expression must evaluate to a constant and it cannot involve any symbols. The keyword `ORIGIN` may be abbreviated to `org` or `o` (but not, for example, `ORG`).

The *len* is an expression for the size in bytes of the memory region. As with the *origin* expression, the expression must be numerical only and must evaluate to a constant. The keyword `LENGTH` may be abbreviated to `len` or `l`.

In the following example, we specify that there are two memory regions available for allocation: one starting at '0' for 256 kilobytes, and the other starting at '0x40000000' for four megabytes. The linker will place into the 'rom' memory region every section which is not explicitly mapped into a memory region, and is either read-only or executable. The linker will place other sections which are not explicitly mapped into a memory region into the 'ram' memory region.

```
MEMORY
{
    rom (rx)  : ORIGIN = 0, LENGTH = 256K
    ram (!rx) : org = 0x40000000, l = 4M
}
```

Once you define a memory region, you can direct the linker to place specific output sections into that memory region by using the '>*region*' output section attribute. For example, if you have a memory region named 'mem', you would use '>mem' in the output section definition. See [Section 3.6.8.6 \[Output Section Region\], page 61](#). If no address was specified for the output section, the linker will set the address to the next available address within the memory region. If the combined output sections directed to a memory region are too large for the region, the linker will issue an error message.

It is possible to access the origin and length of a memory in an expression via the `ORIGIN(memory)` and `LENGTH(memory)` functions:

```
_fstack = ORIGIN(ram) + LENGTH(ram) - 4;
```

3.8 PHDRS Command

The ELF object file format uses *program headers*, also known as *segments*. The program headers describe how the program should be loaded into memory. You can print them out by using the `objdump` program with the '-p' option.

When you run an ELF program on a native ELF system, the system loader reads the program headers in order to figure out how to load the program. This will only work if the program headers are set correctly. This manual does not describe the details of how the system loader interprets program headers; for more information, see the ELF ABI.

The linker will create reasonable program headers by default. However, in some cases, you may need to specify the program headers more precisely. You may use the `PHDRS` command for this purpose. When the linker sees the `PHDRS` command in the linker script, it will not create any program headers other than the ones specified.

The linker only pays attention to the `PHDRS` command when generating an ELF output file. In other cases, the linker will simply ignore `PHDRS`.

This is the syntax of the `PHDRS` command. The words `PHDRS`, `FILEHDR`, `AT`, and `FLAGS` are keywords.

```
PHDRS
{
    name type [ FILEHDR ] [ PHDRS ] [ AT ( address ) ]
           [ FLAGS ( flags ) ] ;
}
```

The *name* is used only for reference in the `SECTIONS` command of the linker script. It is not put into the output file. Program header names are stored in a separate name space, and will not conflict with symbol names, file names, or section names. Each program header must have a distinct name. The headers are processed in order and it is usual for them to map to sections in ascending load address order.

Certain program header types describe segments of memory which the system loader will load from the file. In the linker script, you specify the contents of these segments by placing allocatable output sections in the segments. You use the ‘`:phdr`’ output section attribute to place a section in a particular segment. See [Section 3.6.8.7 \[Output Section Phdr\]](#), page 61.

It is normal to put certain sections in more than one segment. This merely implies that one segment of memory contains another. You may repeat ‘`:phdr`’, using it once for each segment which should contain the section.

If you place a section in one or more segments using ‘`:phdr`’, then the linker will place all subsequent allocatable sections which do not specify ‘`:phdr`’ in the same segments. This is for convenience, since generally a whole set of contiguous sections will be placed in a single segment. You can use `:NONE` to override the default segment and tell the linker to not put the section in any segment at all.

You may use the `FILEHDR` and `PHDRS` keywords after the program header type to further describe the contents of the segment. The `FILEHDR` keyword means that the segment should include the ELF file header. The `PHDRS` keyword means that the segment should include the ELF program headers themselves. If applied to a loadable segment (`PT_LOAD`), all prior loadable segments must have one of these keywords.

The *type* may be one of the following. The numbers indicate the value of the keyword.

`PT_NULL` (0)

Indicates an unused program header.

`PT_LOAD` (1)

Indicates that this program header describes a segment to be loaded from the file.

`PT_DYNAMIC` (2)

Indicates a segment where dynamic linking information can be found.

`PT_INTERP` (3)

Indicates a segment where the name of the program interpreter may be found.

PT_NOTE (4)

Indicates a segment holding note information.

PT_SHLIB (5)

A reserved program header type, defined but not specified by the ELF ABI.

PT_PHDR (6)

Indicates a segment where the program headers may be found.

expression An expression giving the numeric type of the program header. This may be used for types not defined above.

You can specify that a segment should be loaded at a particular address in memory by using an AT expression. This is identical to the AT command used as an output section attribute (see [Section 3.6.8.2 \[Output Section LMA\], page 59](#)). The AT command for a program header overrides the output section attribute.

The linker will normally set the segment flags based on the sections which comprise the segment. You may use the FLAGS keyword to explicitly specify the segment flags. The value of *flags* must be an integer. It is used to set the `p_flags` field of the program header.

Here is an example of PHDRS. This shows a typical set of program headers used on a native ELF system.

```
PHDRS
{
    headers PT_PHDR PHDRS ;
    interp PT_INTERP ;
    text PT_LOAD FILEHDR PHDRS ;
    data PT_LOAD ;
    dynamic PT_DYNAMIC ;
}

SECTIONS
{
    . = SIZEOF_HEADERS;
    .interp : { *(.interp) } :text :interp
    .text : { *(.text) } :text
    .rodata : { *(.rodata) } /* defaults to :text */
    ...
    . = . + 0x1000; /* move to a new page in memory */
    .data : { *(.data) } :data
    .dynamic : { *(.dynamic) } :data :dynamic
    ...
}
```

3.9 VERSION Command

The linker supports symbol versions when using ELF. Symbol versions are only useful when using shared libraries. The dynamic linker can use symbol versions to select a specific version of a function when it runs a program that may have been linked against an earlier version of the shared library.

You can include a version script directly in the main linker script, or you can supply the version script as an implicit linker script. You can also use the ‘`--version-script`’ linker option.

The syntax of the `VERSION` command is simply

```
VERSION { version-script-commands }
```

The format of the version script commands is identical to that used by Sun’s linker in Solaris 2.5. The version script defines a tree of version nodes. You specify the node names and interdependencies in the version script. You can specify which symbols are bound to which version nodes, and you can reduce a specified set of symbols to local scope so that they are not globally visible outside of the shared library.

The easiest way to demonstrate the version script language is with a few examples.

```
VERS_1.1 {
  global:
  foo1;
  local:
  old*;
  original*;
  new*;
};

VERS_1.2 {
  foo2;
} VERS_1.1;

VERS_2.0 {
  bar1; bar2;
  extern "C++" {
  ns::*;
  "f(int, double)";
  };
} VERS_1.2;
```

This example version script defines three version nodes. The first version node defined is ‘`VERS_1.1`’; it has no other dependencies. The script binds the symbol ‘`foo1`’ to ‘`VERS_1.1`’. It reduces a number of symbols to local scope so that they are not visible outside of the shared library; this is done using wildcard patterns, so that any symbol whose name begins with ‘`old`’, ‘`original`’, or ‘`new`’ is matched. The wildcard patterns available are the same as those used in the shell when matching filenames (also known as “globbing”). However, if you specify the symbol name inside double quotes, then the name is treated as literal, rather than as a glob pattern.

Next, the version script defines node ‘`VERS_1.2`’. This node depends upon ‘`VERS_1.1`’. The script binds the symbol ‘`foo2`’ to the version node ‘`VERS_1.2`’.

Finally, the version script defines node ‘`VERS_2.0`’. This node depends upon ‘`VERS_1.2`’. The scripts binds the symbols ‘`bar1`’ and ‘`bar2`’ are bound to the version node ‘`VERS_2.0`’.

When the linker finds a symbol defined in a library which is not specifically bound to a version node, it will effectively bind it to an unspecified base version of the library. You can bind all otherwise unspecified symbols to a given version node by using ‘`global: *;`’ somewhere in the version script. Note that it’s slightly crazy to use wildcards in a global spec except on the last version node. Global wildcards elsewhere run the risk of accidentally

adding symbols to the set exported for an old version. That's wrong since older versions ought to have a fixed set of symbols.

The names of the version nodes have no specific meaning other than what they might suggest to the person reading them. The '2.0' version could just as well have appeared in between '1.1' and '1.2'. However, this would be a confusing way to write a version script.

Node name can be omitted, provided it is the only version node in the version script. Such version script doesn't assign any versions to symbols, only selects which symbols will be globally visible out and which won't.

```
{ global: foo; bar; local: *; };
```

When you link an application against a shared library that has versioned symbols, the application itself knows which version of each symbol it requires, and it also knows which version nodes it needs from each shared library it is linked against. Thus at runtime, the dynamic loader can make a quick check to make sure that the libraries you have linked against do in fact supply all of the version nodes that the application will need to resolve all of the dynamic symbols. In this way it is possible for the dynamic linker to know with certainty that all external symbols that it needs will be resolvable without having to search for each symbol reference.

The symbol versioning is in effect a much more sophisticated way of doing minor version checking that SunOS does. The fundamental problem that is being addressed here is that typically references to external functions are bound on an as-needed basis, and are not all bound when the application starts up. If a shared library is out of date, a required interface may be missing; when the application tries to use that interface, it may suddenly and unexpectedly fail. With symbol versioning, the user will get a warning when they start their program if the libraries being used with the application are too old.

There are several GNU extensions to Sun's versioning approach. The first of these is the ability to bind a symbol to a version node in the source file where the symbol is defined instead of in the versioning script. This was done mainly to reduce the burden on the library maintainer. You can do this by putting something like:

```
__asm__(".symver original_foo,foo@VERS_1.1");
```

in the C source file. This renames the function 'original_foo' to be an alias for 'foo' bound to the version node 'VERS_1.1'. The 'local:' directive can be used to prevent the symbol 'original_foo' from being exported. A '.symver' directive takes precedence over a version script.

The second GNU extension is to allow multiple versions of the same function to appear in a given shared library. In this way you can make an incompatible change to an interface without increasing the major version number of the shared library, while still allowing applications linked against the old interface to continue to function.

To do this, you must use multiple '.symver' directives in the source file. Here is an example:

```
__asm__(".symver original_foo,foo@");
__asm__(".symver old_foo,foo@VERS_1.1");
__asm__(".symver old_fool,foo@VERS_1.2");
__asm__(".symver new_foo,foo@VERS_2.0");
```

In this example, 'foo@' represents the symbol 'foo' bound to the unspecified base version of the symbol. The source file that contains this example would define 4 C functions: 'original_foo', 'old_foo', 'old_fool', and 'new_foo'.

When you have multiple definitions of a given symbol, there needs to be some way to specify a default version to which external references to this symbol will be bound. You can do this with the `'foo@@VERS_2.0'` type of `'symver'` directive. You can only declare one version of a symbol as the default in this manner; otherwise you would effectively have multiple definitions of the same symbol.

If you wish to bind a reference to a specific version of the symbol within the shared library, you can use the aliases of convenience (i.e., `'old_foo'`), or you can use the `'symver'` directive to specifically bind to an external version of the function in question.

You can also specify the language in the version script:

```
VERSION extern "lang" { version-script-commands }
```

The supported `'lang'`s are `'C'`, `'C++'`, and `'Java'`. The linker will iterate over the list of symbols at the link time and demangle them according to `'lang'` before matching them to the patterns specified in `'version-script-commands'`. The default `'lang'` is `'C'`.

Demangled names may contain spaces and other special characters. As described above, you can use a glob pattern to match demangled names, or you can use a double-quoted string to match the string exactly. In the latter case, be aware that minor differences (such as differing whitespace) between the version script and the demangler output will cause a mismatch. As the exact string generated by the demangler might change in the future, even if the mangled name does not, you should check that all of your version directives are behaving as you expect when you upgrade.

3.10 Expressions in Linker Scripts

The syntax for expressions in the linker script language is identical to that of C expressions. All expressions are evaluated as integers. All expressions are evaluated in the same size, which is 32 bits if both the host and target are 32 bits, and is otherwise 64 bits.

You can use and set symbol values in expressions.

The linker defines several special purpose builtin functions for use in expressions.

3.10.1 Constants

All constants are integers.

As in C, the linker considers an integer beginning with `'0'` to be octal, and an integer beginning with `'0x'` or `'0X'` to be hexadecimal. Alternatively the linker accepts suffixes of `'h'` or `'H'` for hexadecimal, `'o'` or `'O'` for octal, `'b'` or `'B'` for binary and `'d'` or `'D'` for decimal. Any integer value without a prefix or a suffix is considered to be decimal.

In addition, you can use the suffixes `K` and `M` to scale a constant by 1024 or 1024^2 respectively. For example, the following all refer to the same quantity:

```
_fourk_1 = 4K;
_fourk_2 = 4096;
_fourk_3 = 0x1000;
_fourk_4 = 10000o;
```

Note - the `K` and `M` suffixes cannot be used in conjunction with the base suffixes mentioned above.

3.10.2 Symbolic Constants

It is possible to refer to target specific constants via the use of the `CONSTANT(name)` operator, where *name* is one of:

`MAXPAGESIZE`

The target's maximum page size.

`COMMONPAGESIZE`

The target's default page size.

So for example:

```
.text ALIGN (CONSTANT (MAXPAGESIZE)) : { *(.text) }
```

will create a text section aligned to the largest page boundary supported by the target.

3.10.3 Symbol Names

Unless quoted, symbol names start with a letter, underscore, or period and may include letters, digits, underscores, periods, and hyphens. Unquoted symbol names must not conflict with any keywords. You can specify a symbol which contains odd characters or has the same name as a keyword by surrounding the symbol name in double quotes:

```
"SECTION" = 9;
"with a space" = "also with a space" + 10;
```

Since symbols can contain many non-alphabetic characters, it is safest to delimit symbols with spaces. For example, 'A-B' is one symbol, whereas 'A - B' is an expression involving subtraction.

3.10.4 Orphan Sections

Orphan sections are sections present in the input files which are not explicitly placed into the output file by the linker script. The linker will still copy these sections into the output file, but it has to guess as to where they should be placed. The linker uses a simple heuristic to do this. It attempts to place orphan sections after non-orphan sections of the same attribute, such as code vs data, loadable vs non-loadable, etc. If there is not enough room to do this then it places at the end of the file.

For ELF targets, the attribute of the section includes section type as well as section flag.

If an orphaned section's name is representable as a C identifier then the linker will automatically see [Section 3.5.3 \[PROVIDE\], page 48](#) two symbols: `__start_SECNAME` and `__stop_SECNAME`, where SECNAME is the name of the section. These indicate the start address and end address of the orphaned section respectively. Note: most section names are not representable as C identifiers because they contain a '.' character.

3.10.5 The Location Counter

The special linker variable *dot* '.' always contains the current output location counter. Since the . always refers to a location in an output section, it may only appear in an expression within a `SECTIONS` command. The . symbol may appear anywhere that an ordinary symbol is allowed in an expression.

Assigning a value to . will cause the location counter to be moved. This may be used to create holes in the output section. The location counter may not be moved backwards inside an output section, and may not be moved backwards outside of an output section if so doing creates areas with overlapping LMAs.

```
SECTIONS
{
    output :
    {
        file1(.text)
        . = . + 1000;
        file2(.text)
        . += 1000;
        file3(.text)
    } = 0x12345678;
}
```

In the previous example, the `.text` section from `file1` is located at the beginning of the output section `output`. It is followed by a 1000 byte gap. Then the `.text` section from `file2` appears, also with a 1000 byte gap following before the `.text` section from `file3`. The notation `= 0x12345678` specifies what data to write in the gaps (see [Section 3.6.8.8 \[Output Section Fill\]](#), page 61).

Note: `.` actually refers to the byte offset from the start of the current containing object. Normally this is the `SECTIONS` statement, whose start address is 0, hence `.` can be used as an absolute address. If `.` is used inside a section description however, it refers to the byte offset from the start of that section, not an absolute address. Thus in a script like this:

```
SECTIONS
{
    . = 0x100
    .text: {
        *(.text)
        . = 0x200
    }
    . = 0x500
    .data: {
        *(.data)
        . += 0x600
    }
}
```

The `.text` section will be assigned a starting address of 0x100 and a size of exactly 0x200 bytes, even if there is not enough data in the `.text` input sections to fill this area. (If there is too much data, an error will be produced because this would be an attempt to move `.` backwards). The `.data` section will start at 0x500 and it will have an extra 0x600 bytes worth of space after the end of the values from the `.data` input sections and before the end of the `.data` output section itself.

Setting symbols to the value of the location counter outside of an output section statement can result in unexpected values if the linker needs to place orphan sections. For example, given the following:

```
SECTIONS
{
    start_of_text = . ;
    .text: { *(.text) }
    end_of_text = . ;

    start_of_data = . ;
    .data: { *(.data) }
    end_of_data = . ;
}
```

If the linker needs to place some input section, e.g. `.rodata`, not mentioned in the script, it might choose to place that section between `.text` and `.data`. You might think the linker should place `.rodata` on the blank line in the above script, but blank lines are of no particular significance to the linker. As well, the linker doesn't associate the above symbol names with their sections. Instead, it assumes that all assignments or other statements belong to the previous output section, except for the special case of an assignment to `..`. I.e., the linker will place the orphan `.rodata` section as if the script was written as follows:

```
SECTIONS
{
    start_of_text = . ;
    .text: { *(.text) }
    end_of_text = . ;

    start_of_data = . ;
    .rodata: { *(.rodata) }
    .data: { *(.data) }
    end_of_data = . ;
}
```

This may or may not be the script author's intention for the value of `start_of_data`. One way to influence the orphan section placement is to assign the location counter to itself, as the linker assumes that an assignment to `.` is setting the start address of a following output section and thus should be grouped with that section. So you could write:

```
SECTIONS
{
    start_of_text = . ;
    .text: { *(.text) }
    end_of_text = . ;

    . = . ;
    start_of_data = . ;
    .data: { *(.data) }
    end_of_data = . ;
}
```

Now, the orphan `.rodata` section will be placed between `end_of_text` and `start_of_data`.

3.10.6 Operators

The linker recognizes the standard C set of arithmetic operators, with the standard bindings and precedence levels:

Precedence	Associativity	Operators
highest		
1	left	- ~ ! †
2	left	* / %
3	left	+ -
4	left	>> <<
5	left	== != > < <= >=
6	left	&
7	left	
8	left	&&
9	left	
10	right	? :
11	right	&= += -= *= /= ‡
lowest		

† Prefix operators.

‡ See [Section 3.5 \[Assignments\]](#), page 47.

3.10.7 Evaluation

The linker evaluates expressions lazily. It only computes the value of an expression when absolutely necessary.

The linker needs some information, such as the value of the start address of the first section, and the origins and lengths of memory regions, in order to do any linking at all. These values are computed as soon as possible when the linker reads in the linker script.

However, other values (such as symbol values) are not known or needed until after storage allocation. Such values are evaluated later, when other information (such as the sizes of output sections) is available for use in the symbol assignment expression.

The sizes of sections cannot be known until after allocation, so assignments dependent upon these are not performed until after allocation.

Some expressions, such as those depending upon the location counter ‘.’, must be evaluated during section allocation.

If the result of an expression is required, but the value is not available, then an error results. For example, a script like the following

```
SECTIONS
{
    .text 9+this_isnt_constant :
    { *(.text) }
}
```

will cause the error message ‘non constant expression for initial address’.

3.10.8 The Section of an Expression

Addresses and symbols may be section relative, or absolute. A section relative symbol is relocatable. If you request relocatable output using the ‘-r’ option, a further link operation may change the value of a section relative symbol. On the other hand, an absolute symbol will retain the same value throughout any further link operations.

Some terms in linker expressions are addresses. This is true of section relative symbols and for builtin functions that return an address, such as `ADDR`, `LOADADDR`, `ORIGIN` and `SEGMENT_START`. Other terms are simply numbers, or are builtin functions that return a non-address

value, such as `LENGTH`. One complication is that unless you set `LD_FEATURE ("SANE_EXPR")` (see [Section 3.4.5 \[Miscellaneous Commands\]](#), page 46), numbers and absolute symbols are treated differently depending on their location, for compatibility with older versions of `ld`. Expressions appearing outside an output section definition treat all numbers as absolute addresses. Expressions appearing inside an output section definition treat absolute symbols as numbers. If `LD_FEATURE ("SANE_EXPR")` is given, then absolute symbols and numbers are simply treated as numbers everywhere.

In the following simple example,

```
SECTIONS
{
    . = 0x100;
    __executable_start = 0x100;
    .data :
    {
        . = 0x10;
        __data_start = 0x10;
        *(.data)
    }
    ...
}
```

both `.` and `__executable_start` are set to the absolute address `0x100` in the first two assignments, then both `.` and `__data_start` are set to `0x10` relative to the `.data` section in the second two assignments.

For expressions involving numbers, relative addresses and absolute addresses, `ld` follows these rules to evaluate terms:

- Unary operations on a relative address, and binary operations on two relative addresses in the same section or between one relative address and a number, apply the operator to the offset part of the address(es).
- Unary operations on an absolute address, and binary operations on one or more absolute addresses or on two relative addresses not in the same section, first convert any non-absolute term to an absolute address before applying the operator.

The result section of each sub-expression is as follows:

- An operation involving only numbers results in a number.
- The result of comparisons, `&&` and `||` is also a number.
- The result of other binary arithmetic and logical operations on two relative addresses in the same section or two absolute addresses (after above conversions) is also a number.
- The result of other operations on relative addresses or one relative address and a number, is a relative address in the same section as the relative operand(s).
- The result of other operations on absolute addresses (after above conversions) is an absolute address.

You can use the builtin function `ABSOLUTE` to force an expression to be absolute when it would otherwise be relative. For example, to create an absolute symbol set to the address of the end of the output section `.data`:

```
SECTIONS
{
    .data : { *(.data) _edata = ABSOLUTE(.); }
```



```
}
```

If ‘ABSOLUTE’ were not used, ‘_edata’ would be relative to the ‘.data’ section.

Using LOADADDR also forces an expression absolute, since this particular builtin function returns an absolute address.

3.10.9 Builtin Functions

The linker script language includes a number of builtin functions for use in linker script expressions.

ABSOLUTE(*exp*)

Return the absolute (non-relocatable, as opposed to non-negative) value of the expression *exp*. Primarily useful to assign an absolute value to a symbol within a section definition, where symbol values are normally section relative. See [Section 3.10.8 \[Expression Section\], page 73](#).

ADDR(*section*)

Return the address (VMA) of the named *section*. Your script must previously have defined the location of that section. In the following example, `start_of_output_1`, `symbol_1` and `symbol_2` are assigned equivalent values, except that `symbol_1` will be relative to the `.output1` section while the other two will be absolute:

```
SECTIONS { ...
    .output1 :
    {
        start_of_output_1 = ABSOLUTE(.);
        ...
    }
    .output :
    {
        symbol_1 = ADDR(.output1);
        symbol_2 = start_of_output_1;
    }
    ... }
```

ALIGN(*align*)

ALIGN(*exp*, *align*)

Return the location counter (.) or arbitrary expression aligned to the next *align* boundary. The single operand `ALIGN` doesn’t change the value of the location counter—it just does arithmetic on it. The two operand `ALIGN` allows an arbitrary expression to be aligned upwards (`ALIGN(align)` is equivalent to `ALIGN(., align)`).

Here is an example which aligns the output `.data` section to the next 0x2000 byte boundary after the preceding section and sets a variable within the section to the next 0x8000 boundary after the input sections:

```
SECTIONS { ...
    .data ALIGN(0x2000): {
        *(.data)
        variable = ALIGN(0x8000);
    }
    ... }
```

The first use of `ALIGN` in this example specifies the location of a section because it is used as the optional *address* attribute of a section definition (see [Section 3.6.3 \[Output Section Address\], page 51](#)). The second use of `ALIGN` is used to defines the value of a symbol.

The builtin function `NEXT` is closely related to `ALIGN`.

`ALIGNOF(section)`

Return the alignment in bytes of the named *section*, if that section has been allocated. If the section has not been allocated when this is evaluated, the linker will report an error. In the following example, the alignment of the `.output` section is stored as the first value in that section.

```
SECTIONS{ ...
.output {
    LONG (ALIGNOF (.output))
    ...
}
... }
```

`BLOCK(exp)`

This is a synonym for `ALIGN`, for compatibility with older linker scripts. It is most often seen when setting the address of an output section.

`DATA_SEGMENT_ALIGN(maxpagesize, commonpagesize)`

This is equivalent to either

```
(ALIGN(maxpagesize) + (. & (maxpagesize - 1)))
```

or

```
(ALIGN(maxpagesize) + (. & (maxpagesize - commonpagesize)))
```

depending on whether the latter uses fewer *commonpagesize* sized pages for the data segment (area between the result of this expression and `DATA_SEGMENT_END`) than the former or not. If the latter form is used, it means *commonpagesize* bytes of runtime memory will be saved at the expense of up to *commonpagesize* wasted bytes in the on-disk file.

This expression can only be used directly in `SECTIONS` commands, not in any output section descriptions and only once in the linker script. *commonpagesize* should be less or equal to *maxpagesize* and should be the system page size the object wants to be optimized for (while still working on system page sizes up to *maxpagesize*).

Example:

```
. = DATA_SEGMENT_ALIGN(0x10000, 0x2000);
```

`DATA_SEGMENT_END(exp)`

This defines the end of data segment for `DATA_SEGMENT_ALIGN` evaluation purposes.

```
. = DATA_SEGMENT_END(.);
```

`DATA_SEGMENT_RELRO_END(offset, exp)`

This defines the end of the `PT_GNU_RELRO` segment when ‘`-z relro`’ option is used. Second argument is returned. When ‘`-z relro`’ option is not present, `DATA_SEGMENT_RELRO_END` does nothing, otherwise `DATA_SEGMENT_ALIGN` is padded so that `exp + offset` is aligned to the most commonly used page

boundary for particular target. If present in the linker script, it must always come in between `DATA_SEGMENT_ALIGN` and `DATA_SEGMENT_END`.

```
. = DATA_SEGMENT_RELRO_END(24, .);
```

DEFINED(*symbol*)

Return 1 if *symbol* is in the linker global symbol table and is defined before the statement using `DEFINED` in the script, otherwise return 0. You can use this function to provide default values for symbols. For example, the following script fragment shows how to set a global symbol ‘begin’ to the first location in the ‘.text’ section—but if a symbol called ‘begin’ already existed, its value is preserved:

```
SECTIONS { ...
    .text : {
        begin = DEFINED(begin) ? begin : . ;
        ...
    }
    ...
}
```

LENGTH(*memory*)

Return the length of the memory region named *memory*.

LOADADDR(*section*)

Return the absolute LMA of the named *section*. (see [Section 3.6.8.2 \[Output Section LMA\]](#), page 59).

MAX(*exp1*, *exp2*)

Returns the maximum of *exp1* and *exp2*.

MIN(*exp1*, *exp2*)

Returns the minimum of *exp1* and *exp2*.

NEXT(*exp*)

Return the next unallocated address that is a multiple of *exp*. This function is closely related to `ALIGN(exp)`; unless you use the `MEMORY` command to define discontinuous memory for the output file, the two functions are equivalent.

ORIGIN(*memory*)

Return the origin of the memory region named *memory*.

SEGMENT_START(*segment*, *default*)

Return the base address of the named *segment*. If an explicit value has been given for this segment (with a command-line ‘-T’ option) that value will be returned; otherwise the value will be *default*. At present, the ‘-T’ command-line option can only be used to set the base address for the “text”, “data”, and “bss” sections, but you can use `SEGMENT_START` with any segment name.

SIZEOF(*section*)

Return the size in bytes of the named *section*, if that section has been allocated. If the section has not been allocated when this is evaluated, the linker will report an error. In the following example, `symbol_1` and `symbol_2` are assigned identical values:

```

SECTIONS{ ...
    .output {
        .start = . ;
        ...
        .end = . ;
    }
    symbol_1 = .end - .start ;
    symbol_2 = SIZEOF(.output);
    ... }

```

SIZEOF_HEADERS

sizeof_headers

Return the size in bytes of the output file's headers. This is information which appears at the start of the output file. You can use this number when setting the start address of the first section, if you choose, to facilitate paging.

When producing an ELF output file, if the linker script uses the **SIZEOF_HEADERS** builtin function, the linker must compute the number of program headers before it has determined all the section addresses and sizes. If the linker later discovers that it needs additional program headers, it will report an error 'not enough room for program headers'. To avoid this error, you must avoid using the **SIZEOF_HEADERS** function, or you must rework your linker script to avoid forcing the linker to use additional program headers, or you must define the program headers yourself using the **PHDRS** command (see [Section 3.8 \[PHDRS\]](#), page 64).

3.11 Implicit Linker Scripts

If you specify a linker input file which the linker can not recognize as an object file or an archive file, it will try to read the file as a linker script. If the file can not be parsed as a linker script, the linker will report an error.

An implicit linker script will not replace the default linker script.

Typically an implicit linker script would contain only symbol assignments, or the **INPUT**, **GROUP**, or **VERSION** commands.

Any input files read because of an implicit linker script will be read at the position in the command line where the implicit linker script was read. This can affect archive searching.

4 Machine Dependent Features

`ld` has additional features on some platforms; the following sections describe them. Machines where `ld` has no additional functionality are not listed.

4.1 `ld` and the H8/300

For the H8/300, `ld` can perform these global optimizations when you specify the ‘`--relax`’ command-line option.

relaxing address modes

`ld` finds all `jsr` and `jmp` instructions whose targets are within eight bits, and turns them into eight-bit program-counter relative `bsr` and `bra` instructions, respectively.

synthesizing instructions

`ld` finds all `mov.b` instructions which use the sixteen-bit absolute address form, but refer to the top page of memory, and changes them to use the eight-bit address form. (That is: the linker turns ‘`mov.b @aa:16`’ into ‘`mov.b @aa:8`’ whenever the address `aa` is in the top page of memory).

bit manipulation instructions

`ld` finds all bit manipulation instructions like `band`, `bclr`, `biand`, `bild`, `bior`, `bist`, `bixor`, `bld`, `bnot`, `bor`, `bset`, `bst`, `btst`, `bxor` which use 32 bit and 16 bit absolute address form, but refer to the top page of memory, and changes them to use the 8 bit address form. (That is: the linker turns ‘`bset #xx:3,@aa:32`’ into ‘`bset #xx:3,@aa:8`’ whenever the address `aa` is in the top page of memory).

system control instructions

`ld` finds all `ldc.w`, `stc.w` instructions which use the 32 bit absolute address form, but refer to the top page of memory, and changes them to use 16 bit address form. (That is: the linker turns ‘`ldc.w @aa:32,ccr`’ into ‘`ldc.w @aa:16,ccr`’ whenever the address `aa` is in the top page of memory).

4.2 `ld` and the Intel 960 Family

You can use the ‘`-Aarchitecture`’ command line option to specify one of the two-letter names identifying members of the 960 family; the option specifies the desired output target, and warns of any incompatible instructions in the input files. It also modifies the linker’s search strategy for archive libraries, to support the use of libraries specific to each particular architecture, by including in the search loop names suffixed with the string identifying the architecture.

For example, if your `ld` command line included ‘`-ACA`’ as well as ‘`-ltry`’, the linker would look (in its built-in search paths, and in any paths you specify with ‘`-L`’) for a library with the names

```
try
libtry.a
tryca
libtryca.a
```

The first two possibilities would be considered in any event; the last two are due to the use of ‘-ACA’.

You can meaningfully use ‘-A’ more than once on a command line, since the 960 architecture family allows combination of target architectures; each use will add another pair of name variants to search for when ‘-l’ specifies a library.

`ld` supports the ‘--relax’ option for the i960 family. If you specify ‘--relax’, `ld` finds all `balx` and `calx` instructions whose targets are within 24 bits, and turns them into 24-bit program-counter relative `bal` and `cal` instructions, respectively. `ld` also turns `cal` instructions into `bal` instructions when it determines that the target subroutine is a leaf routine (that is, the target subroutine does not itself call any subroutines).

The ‘--fix-cortex-a8’ switch enables a link-time workaround for an erratum in certain Cortex-A8 processors. The workaround is enabled by default if you are targeting the ARM v7-A architecture profile. It can be enabled otherwise by specifying ‘--fix-cortex-a8’, or disabled unconditionally by specifying ‘--no-fix-cortex-a8’.

The erratum only affects Thumb-2 code. Please contact ARM for further details.

The ‘--no-merge-exidx-entries’ switch disables the merging of adjacent exidx entries in debuginfo.

4.3 `ld` and the Motorola 68HC11 and 68HC12 families

4.3.1 Linker Relaxation

For the Motorola 68HC11, `ld` can perform these global optimizations when you specify the ‘--relax’ command-line option.

relaxing address modes

`ld` finds all `jsr` and `jmp` instructions whose targets are within eight bits, and turns them into eight-bit program-counter relative `bsr` and `bra` instructions, respectively.

`ld` also looks at all 16-bit extended addressing modes and transforms them in a direct addressing mode when the address is in page 0 (between 0 and 0x0ff).

relaxing gcc instruction group

When `gcc` is called with ‘-mrelax’, it can emit group of instructions that the linker can optimize to use a 68HC11 direct addressing mode. These instructions consists of `bclr` or `bset` instructions.

4.3.2 Trampoline Generation

For 68HC11 and 68HC12, `ld` can generate trampoline code to call a far function using a normal `jsr` instruction. The linker will also change the relocation to some far function to use the trampoline address instead of the function address. This is typically the case when a pointer to a function is taken. The pointer will in fact point to the function trampoline.

4.4 `ld` and the ARM family

For the ARM, `ld` will generate code stubs to allow functions calls between ARM and Thumb code. These stubs only work with code that has been compiled and assembled with the

‘**-mthumb-interwork**’ command line option. If it is necessary to link with old ARM object files or libraries, which have not been compiled with the **-mthumb-interwork** option then the ‘**--support-old-code**’ command line switch should be given to the linker. This will make it generate larger stub functions which will work with non-interworking aware ARM code. Note, however, the linker does not support generating stubs for function calls to non-interworking aware Thumb code.

The ‘**--thumb-entry**’ switch is a duplicate of the generic ‘**--entry**’ switch, in that it sets the program’s starting address. But it also sets the bottom bit of the address, so that it can be branched to using a BX instruction, and the program will start executing in Thumb mode straight away.

The ‘**--use-nul-prefixed-import-tables**’ switch is specifying, that the import tables `idata4` and `idata5` have to be generated with a zero element prefix for import libraries. This is the old style to generate import tables. By default this option is turned off.

The ‘**--be8**’ switch instructs `ld` to generate BE8 format executables. This option is only valid when linking big-endian objects. The resulting image will contain big-endian data and little-endian code.

The ‘**R_ARM_TARGET1**’ relocation is typically used for entries in the ‘`.init_array`’ section. It is interpreted as either ‘**R_ARM_REL32**’ or ‘**R_ARM_ABS32**’, depending on the target. The ‘**--target1-rel**’ and ‘**--target1-abs**’ switches override the default.

The ‘**--target2=type**’ switch overrides the default definition of the ‘**R_ARM_TARGET2**’ relocation. Valid values for ‘**type**’, their meanings, and target defaults are as follows:

```
‘rel’      ‘R_ARM_REL32’ (arm*-*-elf, arm*-*-eabi)
‘abs’      ‘R_ARM_ABS32’ (arm*-*-symbianelf)
‘got-rel’  ‘R_ARM_GOT_PREL’ (arm*-*-linux, arm*-*-bsd)
```

The ‘**R_ARM_V4BX**’ relocation (defined by the ARM AAELF specification) enables objects compiled for the ARMv4 architecture to be interworking-safe when linked with other objects compiled for ARMv4t, but also allows pure ARMv4 binaries to be built from the same ARMv4 objects.

In the latter case, the switch ‘**--fix-v4bx**’ must be passed to the linker, which causes v4t BX rM instructions to be rewritten as MOV PC,rM, since v4 processors do not have a BX instruction.

In the former case, the switch should not be used, and ‘**R_ARM_V4BX**’ relocations are ignored. Replace BX rM instructions identified by ‘**R_ARM_V4BX**’ relocations with a branch to the following veneer:

```
TST rM, #1
MOVEQ PC, rM
BX Rn
```

This allows generation of libraries/applications that work on ARMv4 cores and are still interworking safe. Note that the above veneer clobbers the condition flags, so may cause incorrect program behavior in rare cases.

The ‘**--use-blx**’ switch enables the linker to use ARM/Thumb BLX instructions (available on ARMv5t and above) in various situations. Currently it is used to perform calls via the PLT from Thumb code using BLX rather than using BX and a mode-switching stub before each PLT entry. This should lead to such calls executing slightly faster.

This option is enabled implicitly for SymbianOS, so there is no need to specify it if you are using that target.

The `--vfp11-denorm-fix` switch enables a link-time workaround for a bug in certain VFP11 coprocessor hardware, which sometimes allows instructions with denorm operands (which must be handled by support code) to have those operands overwritten by subsequent instructions before the support code can read the intended values.

The bug may be avoided in scalar mode if you allow at least one intervening instruction between a VFP11 instruction which uses a register and another instruction which writes to the same register, or at least two intervening instructions if vector mode is in use. The bug only affects full-compliance floating-point mode: you do not need this workaround if you are using "runfast" mode. Please contact ARM for further details.

If you know you are using buggy VFP11 hardware, you can enable this workaround by specifying the linker option `--vfp-denorm-fix=scalar` if you are using the VFP11 scalar mode only, or `--vfp-denorm-fix=vector` if you are using vector mode (the latter also works for scalar code). The default is `--vfp-denorm-fix=none`.

If the workaround is enabled, instructions are scanned for potentially-troublesome sequences, and a veneer is created for each such sequence which may trigger the erratum. The veneer consists of the first instruction of the sequence and a branch back to the subsequent instruction. The original instruction is then replaced with a branch to the veneer. The extra cycles required to call and return from the veneer are sufficient to avoid the erratum in both the scalar and vector cases.

The `--fix-arm1176` switch enables a link-time workaround for an erratum in certain ARM1176 processors. The workaround is enabled by default if you are targetting ARM v6 (excluding ARM v6T2) or earlier. It can be disabled unconditionally by specifying `--no-fix-arm1176`.

Further information is available in the "ARM1176JZ-S and ARM1176JZF-S Programmer Advice Notice" available on the ARM documentaion website at: <http://infocenter.arm.com/>.

The `--no-enum-size-warning` switch prevents the linker from warning when linking object files that specify incompatible EABI enumeration size attributes. For example, with this switch enabled, linking of an object file using 32-bit enumeration values with another using enumeration values fitted into the smallest possible space will not be diagnosed.

The `--no-wchar-size-warning` switch prevents the linker from warning when linking object files that specify incompatible EABI `wchar_t` size attributes. For example, with this switch enabled, linking of an object file using 32-bit `wchar_t` values with another using 16-bit `wchar_t` values will not be diagnosed.

The `--pic-veneer` switch makes the linker use PIC sequences for ARM/Thumb inter-working veneers, even if the rest of the binary is not PIC. This avoids problems on uClinux targets where `--emit-relocs` is used to generate relocatable binaries.

The linker will automatically generate and insert small sequences of code into a linked ARM ELF executable whenever an attempt is made to perform a function call to a symbol that is too far away. The placement of these sequences of instructions - called stubs - is controlled by the command line option `--stub-group-size=N`. The placement is important because a poor choice can create a need for duplicate stubs, increasing the code sizw. The linker

will try to group stubs together in order to reduce interruptions to the flow of code, but it needs guidance as to how big these groups should be and where they should be placed.

The value of ‘N’, the parameter to the ‘`--stub-group-size=`’ option controls where the stub groups are placed. If it is negative then all stubs are placed after the first branch that needs them. If it is positive then the stubs can be placed either before or after the branches that need them. If the value of ‘N’ is 1 (either +1 or -1) then the linker will choose exactly where to place groups of stubs, using its built in heuristics. A value of ‘N’ greater than 1 (or smaller than -1) tells the linker that a single group of stubs can service at most ‘N’ bytes from the input sections.

The default, if ‘`--stub-group-size=`’ is not specified, is ‘N = +1’.

Farcalls stubs insertion is fully supported for the ARM-EABI target only, because it relies on object files properties not present otherwise.

4.5 ld and HPPA 32-bit ELF Support

When generating a shared library, `ld` will by default generate import stubs suitable for use with a single sub-space application. The ‘`--multi-subspace`’ switch causes `ld` to generate export stubs, and different (larger) import stubs suitable for use with multiple sub-spaces.

Long branch stubs and import/export stubs are placed by `ld` in stub sections located between groups of input sections. ‘`--stub-group-size`’ specifies the maximum size of a group of input sections handled by one stub section. Since branch offsets are signed, a stub section may serve two groups of input sections, one group before the stub section, and one group after it. However, when using conditional branches that require stubs, it may be better (for branch prediction) that stub sections only serve one group of input sections. A negative value for ‘N’ chooses this scheme, ensuring that branches to stubs always use a negative offset. Two special values of ‘N’ are recognized, ‘1’ and ‘-1’. These both instruct `ld` to automatically size input section groups for the branch types detected, with the same behaviour regarding stub placement as other positive or negative values of ‘N’ respectively.

Note that ‘`--stub-group-size`’ does not split input sections. A single input section larger than the group size specified will of course create a larger group (of one section). If input sections are too large, it may not be possible for a branch to reach its stub.

4.6 ld and the Motorola 68K family

The ‘`--got=type`’ option lets you choose the GOT generation scheme. The choices are ‘`single`’, ‘`negative`’, ‘`multigot`’ and ‘`target`’. When ‘`target`’ is selected the linker chooses the default GOT generation scheme for the current target. ‘`single`’ tells the linker to generate a single GOT with entries only at non-negative offsets. ‘`negative`’ instructs the linker to generate a single GOT with entries at both negative and positive offsets. Not all environments support such GOTs. ‘`multigot`’ allows the linker to generate several GOTs in the output file. All GOT references from a single input object file access the same GOT, but references from different input object files might access different GOTs. Not all environments support such GOTs.

4.7 ld and MMIX

For MMIX, there is a choice of generating ELF object files or mmo object files when linking. The simulator `mmix` understands the mmo format. The binutils `objcopy` utility can translate between the two formats.

There is one special section, the `‘.MMIX.reg_contents’` section. Contents in this section is assumed to correspond to that of global registers, and symbols referring to it are translated to special symbols, equal to registers. In a final link, the start address of the `‘.MMIX.reg_contents’` section corresponds to the first allocated global register multiplied by 8. Register \$255 is not included in this section; it is always set to the program entry, which is at the symbol `Main` for mmo files.

Global symbols with the prefix `__MMIX.start.`, for example `__MMIX.start..text` and `__MMIX.start..data` are special. The default linker script uses these to set the default start address of a section.

Initial and trailing multiples of zero-valued 32-bit words in a section, are left out from an mmo file.

4.8 ld and MSP430

For the MSP430 it is possible to select the MPU architecture. The flag `‘-m [mpu type]’` will select an appropriate linker script for selected MPU type. (To get a list of known MPUs just pass `‘-m help’` option to the linker).

The linker will recognize some extra sections which are MSP430 specific:

`‘.vectors’`

Defines a portion of ROM where interrupt vectors located.

`‘.bootloader’`

Defines the bootloader portion of the ROM (if applicable). Any code in this section will be uploaded to the MPU.

`‘.infomem’`

Defines an information memory section (if applicable). Any code in this section will be uploaded to the MPU.

`‘.infomemnobits’`

This is the same as the `‘.infomem’` section except that any code in this section will not be uploaded to the MPU.

`‘.noinit’`

Denotes a portion of RAM located above `‘.bss’` section.

The last two sections are used by gcc.

4.9 ld and PowerPC 32-bit ELF Support

Branches on PowerPC processors are limited to a signed 26-bit displacement, which may result in ld giving `‘relocation truncated to fit’` errors with very large programs. `‘--relax’` enables the generation of trampolines that can access the entire 32-bit address space. These trampolines are inserted at section boundaries, so may not themselves be reachable if an input section exceeds 33M in size. You may combine `‘-r’` and `‘--relax’`

to add trampolines in a partial link. In that case both branches to undefined symbols and inter-section branches are also considered potentially out of range, and trampolines inserted.

`--bss-plt`

Current PowerPC GCC accepts a `--msecure-plt` option that generates code capable of using a newer PLT and GOT layout that has the security advantage of no executable section ever needing to be writable and no writable section ever being executable. PowerPC `ld` will generate this layout, including stubs to access the PLT, if all input files (including startup and static libraries) were compiled with `--msecure-plt`. `--bss-plt` forces the old BSS PLT (and GOT layout) which can give slightly better performance.

`--secure-plt`

`ld` will use the new PLT and GOT layout if it is linking new `--fpic` or `--fPIC` code, but does not do so automatically when linking non-PIC code. This option requests the new PLT and GOT layout. A warning will be given if some object file requires the old style BSS PLT.

`--sdata-got`

The new secure PLT and GOT are placed differently relative to other sections compared to older BSS PLT and GOT placement. The location of `.plt` must change because the new secure PLT is an initialized section while the old PLT is uninitialized. The reason for the `.got` change is more subtle: The new placement allows `.got` to be read-only in applications linked with `--z relro -z now`. However, this placement means that `.sdata` cannot always be used in shared libraries, because the PowerPC ABI accesses `.sdata` in shared libraries from the GOT pointer. `--sdata-got` forces the old GOT placement. PowerPC GCC doesn't use `.sdata` in shared libraries, so this option is really only useful for other compilers that may do so.

`--emit-stub-syms`

This option causes `ld` to label linker stubs with a local symbol that encodes the stub type and destination.

`--no-tls-optimize`

PowerPC `ld` normally performs some optimization of code sequences used to access Thread-Local Storage. Use this option to disable the optimization.

4.10 `ld` and PowerPC64 64-bit ELF Support

`--stub-group-size`

Long branch stubs, PLT call stubs and TOC adjusting stubs are placed by `ld` in stub sections located between groups of input sections. `--stub-group-size` specifies the maximum size of a group of input sections handled by one stub section. Since branch offsets are signed, a stub section may serve two groups of input sections, one group before the stub section, and one group after it. However, when using conditional branches that require stubs, it may be better (for branch prediction) that stub sections only serve one group of input sections. A negative value for 'N' chooses this scheme, ensuring that branches to stubs

always use a negative offset. Two special values of ‘N’ are recognized, ‘1’ and ‘-1’. These both instruct `ld` to automatically size input section groups for the branch types detected, with the same behaviour regarding stub placement as other positive or negative values of ‘N’ respectively.

Note that ‘`--stub-group-size`’ does not split input sections. A single input section larger than the group size specified will of course create a larger group (of one section). If input sections are too large, it may not be possible for a branch to reach its stub.

‘`--emit-stub-syms`’

This option causes `ld` to label linker stubs with a local symbol that encodes the stub type and destination.

‘`--dotsyms`, ‘`--no-dotsyms`’

These two options control how `ld` interprets version patterns in a version script. Older PowerPC64 compilers emitted both a function descriptor symbol with the same name as the function, and a code entry symbol with the name prefixed by a dot (‘.’). To properly version a function ‘foo’, the version script thus needs to control both ‘foo’ and ‘.foo’. The option ‘`--dotsyms`’, on by default, automatically adds the required dot-prefixed patterns. Use ‘`--no-dotsyms`’ to disable this feature.

‘`--no-tls-optimize`’

PowerPC64 `ld` normally performs some optimization of code sequences used to access Thread-Local Storage. Use this option to disable the optimization.

‘`--no-opd-optimize`’

PowerPC64 `ld` normally removes `.opd` section entries corresponding to deleted link-once functions, or functions removed by the action of ‘`--gc-sections`’ or linker script `/DISCARD/`. Use this option to disable `.opd` optimization.

‘`--non-overlapping-opd`’

Some PowerPC64 compilers have an option to generate compressed `.opd` entries spaced 16 bytes apart, overlapping the third word, the static chain pointer (unused in C) with the first word of the next entry. This option expands such entries to the full 24 bytes.

‘`--no-toc-optimize`’

PowerPC64 `ld` normally removes unused `.toc` section entries. Such entries are detected by examining relocations that reference the TOC in code sections. A reloc in a deleted code section marks a TOC word as unneeded, while a reloc in a kept code section marks a TOC word as needed. Since the TOC may reference itself, TOC relocations are also examined. TOC words marked as both needed and unneeded will of course be kept. TOC words without any referencing reloc are assumed to be part of a multi-word entry, and are kept or discarded as per the nearest marked preceding word. This works reliably for compiler generated code, but may be incorrect if assembly code is used to insert TOC entries. Use this option to disable the optimization.

'--no-multi-toc'

If given any toc option besides `-mmodel=medium` or `-mmodel=large`, PowerPC64 GCC generates code for a TOC model where TOC entries are accessed with a 16-bit offset from r2. This limits the total TOC size to 64K. PowerPC64 `ld` extends this limit by grouping code sections such that each group uses less than 64K for its TOC entries, then inserts r2 adjusting stubs between inter-group calls. `ld` does not split apart input sections, so cannot help if a single input file has a `.toc` section that exceeds 64K, most likely from linking multiple files with `ld -r`. Use this option to turn off this feature.

'--no-toc-sort'

By default, `ld` sorts TOC sections so that those whose file happens to have a section called `.init` or `.fini` are placed first, followed by TOC sections referenced by code generated with PowerPC64 gcc's `-mmodel=small`, and lastly TOC sections referenced only by code generated with PowerPC64 gcc's `-mmodel=medium` or `-mmodel=large` options. Doing this results in better TOC grouping for multi-TOC. Use this option to turn off this feature.

'--plt-align'**'--no-plt-align'**

Use these options to control whether individual PLT call stubs are aligned to a 32-byte boundary, or to the specified power of two boundary when using `--plt-align=`. By default PLT call stubs are packed tightly.

'--plt-static-chain'**'--no-plt-static-chain'**

Use these options to control whether PLT call stubs load the static chain pointer (r11). `ld` defaults to not loading the static chain since there is never any need to do so on a PLT call.

'--plt-thread-safe'**'--no-thread-safe'**

With power7's weakly ordered memory model, it is possible when using lazy binding for `ld.so` to update a plt entry in one thread and have another thread see the individual plt entry words update in the wrong order, despite `ld.so` carefully writing in the correct order and using memory write barriers. To avoid this we need some sort of read barrier in the call stub, or use `LD_BIND_NOW=1`. By default, `ld` looks for calls to commonly used functions that create threads, and if seen, adds the necessary barriers. Use these options to change the default behaviour.

4.11 `ld` and SPU ELF Support

'--plugin'

This option marks an executable as a PIC plugin module.

'--no-overlays'

Normally, `ld` recognizes calls to functions within overlay regions, and redirects such calls to an overlay manager via a stub. `ld` also provides a built-in overlay manager. This option turns off all this special overlay handling.

‘--emit-stub-syms’

This option causes `ld` to label overlay stubs with a local symbol that encodes the stub type and destination.

‘--extra-overlay-stubs’

This option causes `ld` to add overlay call stubs on all function calls out of overlay regions. Normally stubs are not added on calls to non-overlay regions.

‘--local-store=lo:hi’

`ld` usually checks that a final executable for SPU fits in the address range 0 to 256k. This option may be used to change the range. Disable the check entirely with ‘--local-store=0:0’.

‘--stack-analysis’

SPU local store space is limited. Over-allocation of stack space unnecessarily limits space available for code and data, while under-allocation results in run-time failures. If given this option, `ld` will provide an estimate of maximum stack usage. `ld` does this by examining symbols in code sections to determine the extents of functions, and looking at function prologues for stack adjusting instructions. A call-graph is created by looking for relocations on branch instructions. The graph is then searched for the maximum stack usage path. Note that this analysis does not find calls made via function pointers, and does not handle recursion and other cycles in the call graph. Stack usage may be under-estimated if your code makes such calls. Also, stack usage for dynamic allocation, e.g. `alloca`, will not be detected. If a link map is requested, detailed information about each function’s stack usage and calls will be given.

‘--emit-stack-syms’

This option, if given along with ‘--stack-analysis’ will result in `ld` emitting stack sizing symbols for each function. These take the form `__stack_<function_name>` for global functions, and `__stack_<number>_<function_name>` for static functions. `<number>` is the section id in hex. The value of such symbols is the stack requirement for the corresponding function. The symbol size will be zero, type `STT_NOTYPE`, binding `STB_LOCAL`, and section `SHN_ABS`.

4.12 `ld`’s Support for Various TI COFF Versions

The ‘--format’ switch allows selection of one of the various TI COFF versions. The latest of this writing is 2; versions 0 and 1 are also supported. The TI COFF versions also vary in header byte-order format; `ld` will read any version or byte order, but the output header format depends on the default specified by the specific target.

4.13 `ld` and WIN32 (cygwin/mingw)

This section describes some of the win32 specific `ld` issues. See [Section 2.1 \[Command Line Options\]](#), [page 3](#) for detailed description of the command line options mentioned here.

import libraries

The standard Windows linker creates and uses so-called import libraries, which contains information for linking to dll’s. They are regular static archives and

are handled as any other static archive. The cygwin and mingw ports of `ld` have specific support for creating such libraries provided with the ‘`--out-implib`’ command line option.

exporting DLL symbols

The cygwin/mingw `ld` has several ways to export symbols for dll’s.

using auto-export functionality

By default `ld` exports symbols with the auto-export functionality, which is controlled by the following command line options:

- `-export-all-symbols` [This is the default]
- `-exclude-symbols`
- `-exclude-libs`
- `-exclude-modules-for-implib`
- `-version-script`

When auto-export is in operation, `ld` will export all the non-local (global and common) symbols it finds in a DLL, with the exception of a few symbols known to belong to the system’s runtime and libraries. As it will often not be desirable to export all of a DLL’s symbols, which may include private functions that are not part of any public interface, the command-line options listed above may be used to filter symbols out from the list for exporting. The ‘`--output-def`’ option can be used in order to see the final list of exported symbols with all exclusions taken into effect.

If ‘`--export-all-symbols`’ is not given explicitly on the command line, then the default auto-export behavior will be *disabled* if either of the following are true:

- A DEF file is used.
- Any symbol in any object file was marked with the `--declspec(dllexport)` attribute.

using a DEF file

Another way of exporting symbols is using a DEF file. A DEF file is an ASCII file containing definitions of symbols which should be exported when a dll is created. Usually it is named ‘`<dll name>.def`’ and is added as any other object file to the linker’s command line. The file’s name must end in ‘`.def`’ or ‘`.DEF`’.

```
gcc -o <output> <objectfiles> <dll name>.def
```

Using a DEF file turns off the normal auto-export behavior, unless the ‘`--export-all-symbols`’ option is also used.

Here is an example of a DEF file for a shared library called ‘`xyz.dll`’:

```
LIBRARY "xyz.dll" BASE=0x20000000
```

```
EXPORTS
```



```

foo
bar
_bar = bar
another_foo = abc.dll.afoo
var1 DATA
doo = foo == foo2
eoo DATA == var1

```

This example defines a DLL with a non-default base address and seven symbols in the export table. The third exported symbol `_bar` is an alias for the second. The fourth symbol, `another_foo` is resolved by "forwarding" to another module and treating it as an alias for `afoo` exported from the DLL `'abc.dll'`. The final symbol `var1` is declared to be a data object. The `'doo'` symbol in export library is an alias of `'foo'`, which gets the string name in export table `'foo2'`. The `'eoo'` symbol is an data export symbol, which gets in export table the name `'var1'`.

The optional `LIBRARY <name>` command indicates the *internal* name of the output DLL. If `'<name>'` does not include a suffix, the default library suffix, `' .DLL'` is appended.

When the `.DEF` file is used to build an application, rather than a library, the `NAME <name>` command should be used instead of `LIBRARY`. If `'<name>'` does not include a suffix, the default executable suffix, `' .EXE'` is appended.

With either `LIBRARY <name>` or `NAME <name>` the optional specification `BASE = <number>` may be used to specify a non-default base address for the image.

If neither `LIBRARY <name>` nor `NAME <name>` is specified, or they specify an empty string, the internal name is the same as the file-name specified on the command line.

The complete specification of an export symbol is:

```

EXPORTS
( ( ( <name1> [ = <name2> ] )
  | ( <name1> = <module-name> . <external-name>))
[ @ <integer> ] [NONAME] [DATA] [CONSTANT] [PRIVATE] [== <name3>]

```

Declares `'<name1>'` as an exported symbol from the DLL, or declares `'<name1>'` as an exported alias for `'<name2>'`; or declares `'<name1>'` as a "forward" alias for the symbol `'<external-name>'` in the DLL `'<module-name>'`. Optionally, the symbol may be exported by the specified ordinal `'<integer>'` alias. The optional `'<name3>'` is the to be used string in import/export table for the symbol.

The optional keywords that follow the declaration indicate:

NONAME: Do not put the symbol name in the DLL's export table. It will still be exported by its ordinal alias (either the value specified by the `.def` specification or, otherwise, the value assigned by the

linker). The symbol name, however, does remain visible in the import library (if any), unless **PRIVATE** is also specified.

DATA: The symbol is a variable or object, rather than a function. The import lib will export only an indirect reference to `foo` as the symbol `_imp__foo` (ie, `foo` must be resolved as `*_imp__foo`).

CONSTANT: Like **DATA**, but put the undecorated `foo` as well as `_imp__foo` into the import library. Both refer to the read-only import address table's pointer to the variable, not to the variable itself. This can be dangerous. If the user code fails to add the `dllimport` attribute and also fails to explicitly add the extra indirection that the use of the attribute enforces, the application will behave unexpectedly.

PRIVATE: Put the symbol in the DLL's export table, but do not put it into the static import library used to resolve imports at link time. The symbol can still be imported using the `LoadLibrary/GetProcAddress` API at runtime or by using the GNU `ld` extension of linking directly to the DLL without an import library.

See `ld/deffile.y` in the `binutils` sources for the full specification of other DEF file statements

While linking a shared dll, `ld` is able to create a DEF file with the `'--output-def <file>'` command line option.

Using decorations

Another way of marking symbols for export is to modify the source code itself, so that when building the DLL each symbol to be exported is declared as:

```
__declspec(dllexport) int a_variable
__declspec(dllexport) void a_function(int with_args)
```

All such symbols will be exported from the DLL. If, however, any of the object files in the DLL contain symbols decorated in this way, then the normal auto-export behavior is disabled, unless the `'--export-all-symbols'` option is also used.

Note that object files that wish to access these symbols must *not* decorate them with `dllexport`. Instead, they should use `dllimport`, instead:

```
__declspec(dllimport) int a_variable
__declspec(dllimport) void a_function(int with_args)
```

This complicates the structure of library header files, because when included by the library itself the header must declare the variables and functions as `dllexport`, but when included by client code the header must declare them as `dllimport`. There are a number of idioms that are typically used to do this; often client code can omit the `__declspec()` declaration completely. See `'--enable-auto-import'` and `'automatic data imports'` for more information.

automatic data imports

The standard Windows dll format supports data imports from dlls only by adding special decorations (dllimport/dllexport), which let the compiler produce specific assembler instructions to deal with this issue. This increases the effort necessary to port existing Un*x code to these platforms, especially for large c++ libraries and applications. The auto-import feature, which was initially provided by Paul Sokolovsky, allows one to omit the decorations to achieve a behavior that conforms to that on POSIX/Un*x platforms. This feature is enabled with the ‘`--enable-auto-import`’ command-line option, although it is enabled by default on cygwin/mingw. The ‘`--enable-auto-import`’ option itself now serves mainly to suppress any warnings that are ordinarily emitted when linked objects trigger the feature’s use.

auto-import of variables does not always work flawlessly without additional assistance. Sometimes, you will see this message

```
"variable '<var>' can't be auto-imported. Please read the documentation for
ld's --enable-auto-import for details."
```

The ‘`--enable-auto-import`’ documentation explains why this error occurs, and several methods that can be used to overcome this difficulty. One of these methods is the *runtime pseudo-relocs* feature, described below.

For complex variables imported from DLLs (such as structs or classes), object files typically contain a base address for the variable and an offset (*addend*) within the variable to specify a particular field or public member, for instance. Unfortunately, the runtime loader used in win32 environments is incapable of fixing these references at runtime without the additional information supplied by dllimport/dllexport decorations. The standard auto-import feature described above is unable to resolve these references.

The ‘`--enable-runtime-pseudo-relocs`’ switch allows these references to be resolved without error, while leaving the task of adjusting the references themselves (with their non-zero addends) to specialized code provided by the runtime environment. Recent versions of the cygwin and mingw environments and compilers provide this runtime support; older versions do not. However, the support is only necessary on the developer’s platform; the compiled result will run without error on an older system.

‘`--enable-runtime-pseudo-relocs`’ is not the default; it must be explicitly enabled as needed.

direct linking to a dll

The cygwin/mingw ports of `ld` support the direct linking, including data symbols, to a dll without the usage of any import libraries. This is much faster and uses much less memory than does the traditional import library method, especially when linking large libraries or applications. When `ld` creates an import lib, each function or variable exported from the dll is stored in its own bfd, even though a single bfd could contain many exports. The overhead involved in storing, loading, and processing so many bfd’s is quite large, and explains the tremendous time, memory, and storage needed to link against particularly large or complex libraries when using import libs.

Linking directly to a dll uses no extra command-line switches other than ‘-L’ and ‘-l’, because ld already searches for a number of names to match each library. All that is needed from the developer’s perspective is an understanding of this search, in order to force ld to select the dll instead of an import library. For instance, when ld is called with the argument ‘-lxxx’ it will attempt to find, in the first directory of its search path,

```
libxxx.dll.a
xxx.dll.a
libxxx.a
xxx.lib
cygxxx.dll (*)
libxxx.dll
xxx.dll
```

before moving on to the next directory in the search path.

(*) Actually, this is not ‘cygxxx.dll’ but in fact is ‘<prefix>xxx.dll’, where ‘<prefix>’ is set by the ld option ‘--dll-search-prefix=<prefix>’. In the case of cygwin, the standard gcc spec file includes ‘--dll-search-prefix=cyg’, so in effect we actually search for ‘cygxxx.dll’.

Other win32-based unix environments, such as mingw or pw32, may use other ‘<prefix>’es, although at present only cygwin makes use of this feature. It was originally intended to help avoid name conflicts among dll’s built for the various win32/un*x environments, so that (for example) two versions of a zlib dll could coexist on the same machine.

The generic cygwin/mingw path layout uses a ‘bin’ directory for applications and dll’s and a ‘lib’ directory for the import libraries (using cygwin nomenclature):

```
bin/
cygxxx.dll
lib/
libxxx.dll.a    (in case of dll’s)
libxxx.a        (in case of static archive)
```

Linking directly to a dll without using the import library can be done two ways:

1. Use the dll directly by adding the ‘bin’ path to the link line

```
gcc -Wl,-verbose -o a.exe -L../bin/ -lxxx
```

However, as the dll’s often have version numbers appended to their names (‘cygncurses-5.dll’) this will often fail, unless one specifies ‘-L../bin -lncurses-5’ to include the version. Import libs are generally not versioned, and do not have this difficulty.

2. Create a symbolic link from the dll to a file in the ‘lib’ directory according to the above mentioned search pattern. This should be used to avoid unwanted changes in the tools needed for making the app/dll.

```
ln -s bin/cygxxx.dll lib/[cyg|lib|]xxx.dll[.a]
```

Then you can link without any make environment changes.

```
gcc -Wl,-verbose -o a.exe -L../lib/ -lxxx
```

This technique also avoids the version number problems, because the following is perfectly legal

```
bin/
cygxxx-5.dll
lib/
libxxx.dll.a -> ../bin/cygxxx-5.dll
```

Linking directly to a dll without using an import lib will work even when auto-import features are exercised, and even when ‘`--enable-runtime-pseudo-relocs`’ is used.

Given the improvements in speed and memory usage, one might justifiably wonder why import libraries are used at all. There are three reasons:

1. Until recently, the link-directly-to-dll functionality did *not* work with auto-imported data.
2. Sometimes it is necessary to include pure static objects within the import library (which otherwise contains only bfd’s for indirection symbols that point to the exports of a dll). Again, the import lib for the cygwin kernel makes use of this ability, and it is not possible to do this without an import lib.
3. Symbol aliases can only be resolved using an import lib. This is critical when linking against OS-supplied dll’s (eg, the win32 API) in which symbols are usually exported as undecorated aliases of their stdcall-decorated assembly names.

So, import libs are not going away. But the ability to replace true import libs with a simple symbolic link to (or a copy of) a dll, in many cases, is a useful addition to the suite of tools binutils makes available to the win32 developer. Given the massive improvements in memory requirements during linking, storage requirements, and linking speed, we expect that many developers will soon begin to use this feature whenever possible.

symbol aliasing

adding additional names

Sometimes, it is useful to export symbols with additional names. A symbol ‘foo’ will be exported as ‘foo’, but it can also be exported as ‘_foo’ by using special directives in the DEF file when creating the dll. This will affect also the optional created import library. Consider the following DEF file:

```
LIBRARY "xyz.dll" BASE=0x61000000

EXPORTS
foo
_foo = foo
```

The line ‘_foo = foo’ maps the symbol ‘foo’ to ‘_foo’.

Another method for creating a symbol alias is to create it in the source code using the “weak” attribute:

```
void foo () { /* Do something. */; }
void _foo () __attribute__((weak, alias ("foo")));
```

See the gcc manual for more information about attributes and weak symbols.

renaming symbols

Sometimes it is useful to rename exports. For instance, the cygwin kernel does this regularly. A symbol ‘_foo’ can be exported as ‘foo’ but not as ‘_foo’ by using special directives in the DEF file. (This will also affect the import library, if it is created). In the following example:

```
LIBRARY "xyz.dll" BASE=0x61000000

EXPORTS
_foo = foo
```

The line ‘_foo = foo’ maps the exported symbol ‘foo’ to ‘_foo’.

Note: using a DEF file disables the default auto-export behavior, unless the ‘--export-all-symbols’ command line option is used. If, however, you are trying to rename symbols, then you should list *all* desired exports in the DEF file, including the symbols that are not being renamed, and do *not* use the ‘--export-all-symbols’ option. If you list only the renamed symbols in the DEF file, and use ‘--export-all-symbols’ to handle the other symbols, then the both the new names *and* the original names for the renamed symbols will be exported. In effect, you’d be aliasing those symbols, not renaming them, which is probably not what you wanted.

weak externals

The Windows object format, PE, specifies a form of weak symbols called weak externals. When a weak symbol is linked and the symbol is not defined, the weak symbol becomes an alias for some other symbol. There are three variants of weak externals:

- Definition is searched for in objects and libraries, historically called lazy externals.
- Definition is searched for only in other objects, not in libraries. This form is not presently implemented.
- No search; the symbol is an alias. This form is not presently implemented.

As a GNU extension, weak symbols that do not specify an alternate symbol are supported. If the symbol is undefined when linking, the symbol uses a default value.

aligned common symbols

As a GNU extension to the PE file format, it is possible to specify the desired alignment for a common symbol. This information is conveyed from the assembler or compiler to the linker by means of GNU-specific commands carried in the object file’s ‘.drectve’ section, which are recognized by ld and respected when laying out the common symbols. Native tools will be able to process ob-

ject files employing this GNU extension, but will fail to respect the alignment instructions, and may issue noisy warnings about unknown linker directives.

4.14 ld and Xtensa Processors

The default `ld` behavior for Xtensa processors is to interpret `SECTIONS` commands so that lists of explicitly named sections in a specification with a wildcard file will be interleaved when necessary to keep literal pools within the range of PC-relative load offsets. For example, with the command:

```
SECTIONS
{
    .text : {
        *(.literal .text)
    }
}
```

`ld` may interleave some of the `.literal` and `.text` sections from different object files to ensure that the literal pools are within the range of PC-relative load offsets. A valid interleaving might place the `.literal` sections from an initial group of files followed by the `.text` sections of that group of files. Then, the `.literal` sections from the rest of the files and the `.text` sections from the rest of the files would follow.

Relaxation is enabled by default for the Xtensa version of `ld` and provides two important link-time optimizations. The first optimization is to combine identical literal values to reduce code size. A redundant literal will be removed and all the L32R instructions that use it will be changed to reference an identical literal, as long as the location of the replacement literal is within the offset range of all the L32R instructions. The second optimization is to remove unnecessary overhead from assembler-generated “longcall” sequences of L32R/CALLXn when the target functions are within range of direct CALLn instructions.

For each of these cases where an indirect call sequence can be optimized to a direct call, the linker will change the CALLXn instruction to a CALLn instruction, remove the L32R instruction, and remove the literal referenced by the L32R instruction if it is not used for anything else. Removing the L32R instruction always reduces code size but can potentially hurt performance by changing the alignment of subsequent branch targets. By default, the linker will always preserve alignments, either by switching some instructions between 24-bit encodings and the equivalent density instructions or by inserting a no-op in place of the L32R instruction that was removed. If code size is more important than performance, the ‘`--size-opt`’ option can be used to prevent the linker from widening density instructions or inserting no-ops, except in a few cases where no-ops are required for correctness.

The following Xtensa-specific command-line options can be used to control the linker:

‘`--size-opt`’

When optimizing indirect calls to direct calls, optimize for code size more than performance. With this option, the linker will not insert no-ops or widen density instructions to preserve branch target alignment. There may still be some cases where no-ops are required to preserve the correctness of the code.

5 BFD

The linker accesses object and archive files using the BFD libraries. These libraries allow the linker to use the same routines to operate on object files whatever the object file format. A different object file format can be supported simply by creating a new BFD back end and adding it to the library. To conserve runtime memory, however, the linker and associated tools are usually configured to support only a subset of the object file formats available. You can use `objdump -i` (see [Section “objdump” in *The GNU Binary Utilities*](#)) to list all the formats available for your configuration.

As with most implementations, BFD is a compromise between several conflicting requirements. The major factor influencing BFD design was efficiency: any time used converting between formats is time which would not have been spent had BFD not been involved. This is partly offset by abstraction payback; since BFD simplifies applications and back ends, more time and care may be spent optimizing algorithms for a greater speed.

One minor artifact of the BFD solution which you should bear in mind is the potential for information loss. There are two places where useful information can be lost using the BFD mechanism: during conversion and during output. See [Section 5.1.1 \[BFD information loss\], page 97](#).

5.1 How It Works: An Outline of BFD

When an object file is opened, BFD subroutines automatically determine the format of the input object file. They then build a descriptor in memory with pointers to routines that will be used to access elements of the object file’s data structures.

As different information from the object files is required, BFD reads from different sections of the file and processes them. For example, a very common operation for the linker is processing symbol tables. Each BFD back end provides a routine for converting between the object file’s representation of symbols and an internal canonical format. When the linker asks for the symbol table of an object file, it calls through a memory pointer to the routine from the relevant BFD back end which reads and converts the table into a canonical form. The linker then operates upon the canonical form. When the link is finished and the linker writes the output file’s symbol table, another BFD back end routine is called to take the newly created symbol table and convert it into the chosen output format.

5.1.1 Information Loss

Information can be lost during output. The output formats supported by BFD do not provide identical facilities, and information which can be described in one form has nowhere to go in another format. One example of this is alignment information in `b.out`. There is nowhere in an `a.out` format file to store alignment information on the contained data, so when a file is linked from `b.out` and an `a.out` image is produced, alignment information will not propagate to the output file. (The linker will still use the alignment information internally, so the link is performed correctly).

Another example is COFF section names. COFF files may contain an unlimited number of sections, each one with a textual section name. If the target of the link is a format which does not have many sections (e.g., `a.out`) or has sections without names (e.g., the Oasys format), the link cannot be done simply. You can circumvent this problem by describing the desired input-to-output section mapping with the linker command language.

Information can be lost during canonicalization. The BFD internal canonical form of the external formats is not exhaustive; there are structures in input formats for which there is no direct representation internally. This means that the BFD back ends cannot maintain all possible data richness through the transformation between external to internal and back to external formats.

This limitation is only a problem when an application reads one format and writes another. Each BFD back end is responsible for maintaining as much data as possible, and the internal BFD canonical form has structures which are opaque to the BFD core, and exported only to the back ends. When a file is read in one format, the canonical form is generated for BFD and the application. At the same time, the back end saves away any information which may otherwise be lost. If the data is then written back in the same format, the back end routine will be able to use the canonical form provided by the BFD core as well as the information it prepared earlier. Since there is a great deal of commonality between back ends, there is no information lost when linking or copying big endian COFF to little endian COFF, or `a.out` to `b.out`. When a mixture of formats is linked, the information is only lost from the files whose format differs from the destination.

5.1.2 The BFD canonical object-file format

The greatest potential for loss of information occurs when there is the least overlap between the information provided by the source format, that stored by the canonical format, and that needed by the destination format. A brief description of the canonical form may help you understand which kinds of data you can count on preserving across conversions.

<i>files</i>	Information stored on a per-file basis includes target machine architecture, particular implementation format type, a demand pageable bit, and a write protected bit. Information like Unix magic numbers is not stored here—only the magic numbers' meaning, so a <code>ZMAGIC</code> file would have both the demand pageable bit and the write protected text bit set. The byte order of the target is stored on a per-file basis, so that big- and little-endian object files may be used with one another.
<i>sections</i>	Each section in the input file contains the name of the section, the section's original address in the object file, size and alignment information, various flags, and pointers into other BFD data structures.
<i>symbols</i>	Each symbol contains a pointer to the information for the object file which originally defined it, its name, its value, and various flag bits. When a BFD back end reads in a symbol table, it relocates all symbols to make them relative to the base of the section where they were defined. Doing this ensures that each symbol points to its containing section. Each symbol also has a varying amount of hidden private data for the BFD back end. Since the symbol points to the original file, the private data format for that symbol is accessible. <code>ld</code> can operate on a collection of symbols of wildly different formats without problems. Normal global and simple local symbols are maintained on output, so an output file (no matter its format) will retain symbols pointing to functions and to global, static, and common variables. Some symbol information is not worth retaining; in <code>a.out</code> , type information is stored in the symbol table as long

symbol names. This information would be useless to most COFF debuggers; the linker has command line switches to allow users to throw it away.

There is one word of type information within the symbol, so if the format supports symbol type information within symbols (for example, COFF, IEEE, Oasys) and the type is simple enough to fit within one word (nearly everything but aggregates), the information will be preserved.

relocation level

Each canonical BFD relocation record contains a pointer to the symbol to relocate to, the offset of the data to relocate, the section the data is in, and a pointer to a relocation type descriptor. Relocation is performed by passing messages through the relocation type descriptor and the symbol pointer. Therefore, relocations can be performed on output data using a relocation method that is only available in one of the input formats. For instance, Oasys provides a byte relocation format. A relocation record requesting this relocation type would point indirectly to a routine to perform this, so the relocation may be performed on a byte being written to a 68k COFF file, even though 68k COFF has no such relocation type.

line numbers

Object formats can contain, for debugging purposes, some form of mapping between symbols, source line numbers, and addresses in the output file. These addresses have to be relocated along with the symbol information. Each symbol with an associated list of line number records points to the first record of the list. The head of a line number list consists of a pointer to the symbol, which allows finding out the address of the function whose line number is being described. The rest of the list is made up of pairs: offsets into the section and line numbers. Any format which can simply derive this information can pass it successfully between formats (COFF, IEEE and Oasys).

6 Reporting Bugs

Your bug reports play an essential role in making `ld` reliable.

Reporting a bug may help you by bringing a solution to your problem, or it may not. But in any case the principal function of a bug report is to help the entire community by making the next version of `ld` work better. Bug reports are your contribution to the maintenance of `ld`.

In order for a bug report to serve its purpose, you must include the information that enables us to fix the bug.

6.1 Have You Found a Bug?

If you are not sure whether you have found a bug, here are some guidelines:

- If the linker gets a fatal signal, for any input whatever, that is a `ld` bug. Reliable linkers never crash.
- If `ld` produces an error message for valid input, that is a bug.
- If `ld` does not produce an error message for invalid input, that may be a bug. In the general case, the linker can not verify that object files are correct.
- If you are an experienced user of linkers, your suggestions for improvement of `ld` are welcome in any case.

6.2 How to Report Bugs

A number of companies and individuals offer support for GNU products. If you obtained `ld` from a support organization, we recommend you contact that organization first.

You can find contact information for many support companies and individuals in the file `etc/SERVICE` in the GNU Emacs distribution.

Otherwise, send bug reports for `ld` to <http://www.sourceware.org/bugzilla/>.

The fundamental principle of reporting bugs usefully is this: **report all the facts**. If you are not sure whether to state a fact or leave it out, state it!

Often people omit facts because they think they know what causes the problem and assume that some details do not matter. Thus, you might assume that the name of a symbol you use in an example does not matter. Well, probably it does not, but one cannot be sure. Perhaps the bug is a stray memory reference which happens to fetch from the location where that name is stored in memory; perhaps, if the name were different, the contents of that location would fool the linker into doing the right thing despite the bug. Play it safe and give a specific, complete example. That is the easiest thing for you to do, and the most helpful.

Keep in mind that the purpose of a bug report is to enable us to fix the bug if it is new to us. Therefore, always write your bug reports on the assumption that the bug has not been reported previously.

Sometimes people give a few sketchy facts and ask, “Does this ring a bell?” This cannot help us fix a bug, so it is basically useless. We respond by asking for enough details to enable us to investigate. You might as well expedite matters by sending them to begin with.

To enable us to fix the bug, you should include all these things:

- The version of `ld`. `ld` announces it if you start it with the ‘`--version`’ argument. Without this, we will not know whether there is any point in looking for the bug in the current version of `ld`.
- Any patches you may have applied to the `ld` source, including any patches made to the BFD library.
- The type of machine you are using, and the operating system name and version number.
- What compiler (and its version) was used to compile `ld`—e.g. “`gcc-2.7`”.
- The command arguments you gave the linker to link your example and observe the bug. To guarantee you will not omit something important, list them all. A copy of the Makefile (or the output from `make`) is sufficient.

If we were to try to guess the arguments, we would probably guess wrong and then we might not encounter the bug.

- A complete input file, or set of input files, that will reproduce the bug. It is generally most helpful to send the actual object files provided that they are reasonably small. Say no more than 10K. For bigger files you can either make them available by FTP or HTTP or else state that you are willing to send the object file(s) to whomever requests them. (Note - your email will be going to a mailing list, so we do not want to clog it up with large attachments). But small attachments are best.

If the source files were assembled using `gas` or compiled using `gcc`, then it may be OK to send the source files rather than the object files. In this case, be sure to say exactly what version of `gas` or `gcc` was used to produce the object files. Also say how `gas` or `gcc` were configured.

- A description of what behavior you observe that you believe is incorrect. For example, “It gets a fatal signal.”

Of course, if the bug is that `ld` gets a fatal signal, then we will certainly notice it. But if the bug is incorrect output, we might not notice unless it is glaringly wrong. You might as well not give us a chance to make a mistake.

Even if the problem you experience is a fatal signal, you should still say so explicitly. Suppose something strange is going on, such as, your copy of `ld` is out of sync, or you have encountered a bug in the C library on your system. (This has happened!) Your copy might crash and ours would not. If you told us to expect a crash, then when ours fails to crash, we would know that the bug was not happening for us. If you had not told us to expect a crash, then we would not be able to draw any conclusion from our observations.

- If you wish to suggest changes to the `ld` source, send us context diffs, as generated by `diff` with the ‘`-u`’, ‘`-c`’, or ‘`-p`’ option. Always send diffs from the old file to the new file. If you even discuss something in the `ld` source, refer to it by context, not by line number.

The line numbers in our development sources will not match those in your sources. Your line numbers would convey no useful information to us.

Here are some things that are not necessary:

- A description of the envelope of the bug.
Often people who encounter a bug spend a lot of time investigating which changes to the input file will make the bug go away and which changes will not affect it.

This is often time consuming and not very useful, because the way we will find the bug is by running a single example under the debugger with breakpoints, not by pure deduction from a series of examples. We recommend that you save your time for something else.

Of course, if you can find a simpler example to report *instead* of the original one, that is a convenience for us. Errors in the output will be easier to spot, running under the debugger will take less time, and so on.

However, simplification is not vital; if you do not want to do this, report the bug anyway and send us the entire test case you used.

- A patch for the bug.

A patch for the bug does help us if it is a good one. But do not omit the necessary information, such as the test case, on the assumption that a patch is all we need. We might see problems with your patch and decide to fix the problem another way, or we might not understand it at all.

Sometimes with a program as complicated as `ld` it is very hard to construct an example that will make the program follow a certain path through the code. If you do not send us the example, we will not be able to construct one, so we will not be able to verify that the bug is fixed.

And if we cannot understand what bug you are trying to fix, or why your patch should be an improvement, we will not install it. A test case will help us to understand.

- A guess about what the bug is or what it depends on.

Such guesses are usually wrong. Even we cannot guess right about such things without first using the debugger to find the facts.

Appendix A MRI Compatible Script Files

To aid users making the transition to GNU `ld` from the MRI linker, `ld` can use MRI compatible linker scripts as an alternative to the more general-purpose linker scripting language described in [Chapter 3 \[Scripts\]](#), [page 39](#). MRI compatible linker scripts have a much simpler command set than the scripting language otherwise used with `ld`. GNU `ld` supports the most commonly used MRI linker commands; these commands are described here.

In general, MRI scripts aren't of much use with the `a.out` object file format, since it only has three sections and MRI scripts lack some features to make use of them.

You can specify a file containing an MRI-compatible script using the `'-c'` command-line option.

Each command in an MRI-compatible script occupies its own line; each command line starts with the keyword that identifies the command (though blank lines are also allowed for punctuation). If a line of an MRI-compatible script begins with an unrecognized keyword, `ld` issues a warning message, but continues processing the script.

Lines beginning with `'*'` are comments.

You can write these commands using all upper-case letters, or all lower case; for example, `'chip'` is the same as `'CHIP'`. The following list shows only the upper-case form of each command.

ABSOLUTE *secname*

ABSOLUTE *secname*, *secname*, ... *secname*

Normally, `ld` includes in the output file all sections from all the input files. However, in an MRI-compatible script, you can use the **ABSOLUTE** command to restrict the sections that will be present in your output program. If the **ABSOLUTE** command is used at all in a script, then only the sections named explicitly in **ABSOLUTE** commands will appear in the linker output. You can still use other input sections (whatever you select on the command line, or using **LOAD**) to resolve addresses in the output file.

ALIAS *out-secname*, *in-secname*

Use this command to place the data from input section *in-secname* in a section called *out-secname* in the linker output file.

in-secname may be an integer.

ALIGN *secname* = *expression*

Align the section called *secname* to *expression*. The *expression* should be a power of two.

BASE *expression*

Use the value of *expression* as the lowest address (other than absolute addresses) in the output file.

CHIP *expression*

CHIP *expression*, *expression*

This command does nothing; it is accepted only for compatibility.

END

This command does nothing whatever; it's only accepted for compatibility.

FORMAT *output-format*

Similar to the `OUTPUT_FORMAT` command in the more general linker language, but restricted to one of these output formats:

1. S-records, if *output-format* is 'S'
2. IEEE, if *output-format* is 'IEEE'
3. COFF (the 'coff-m68k' variant in BFD), if *output-format* is 'COFF'

LIST *anything...*

Print (to the standard output file) a link map, as produced by the `ld` command-line option '-M'.

The keyword `LIST` may be followed by anything on the same line, with no change in its effect.

LOAD *filename***LOAD** *filename, filename, ... filename*

Include one or more object file *filename* in the link; this has the same effect as specifying *filename* directly on the `ld` command line.

NAME *output-name*

output-name is the name for the program produced by `ld`; the MRI-compatible command `NAME` is equivalent to the command-line option '-o' or the general script language command `OUTPUT`.

ORDER *secname, secname, ... secname***ORDER** *secname secname secname*

Normally, `ld` orders the sections in its output file in the order in which they first appear in the input files. In an MRI-compatible script, you can override this ordering with the `ORDER` command. The sections you list with `ORDER` will appear first in your output file, in the order specified.

PUBLIC *name=expression***PUBLIC** *name,expression***PUBLIC** *name expression*

Supply a value (*expression*) for external symbol *name* used in the linker input files.

SECT *secname, expression***SECT** *secname=expression***SECT** *secname expression*

You can use any of these three forms of the `SECT` command to specify the start address (*expression*) for section *secname*. If you have more than one `SECT` statement for the same *secname*, only the *first* sets the start address.

Appendix B GNU Free Documentation License

Version 1.3, 3 November 2008

Copyright © 2000, 2001, 2002, 2007, 2008 Free Software Foundation, Inc.

<http://fsf.org/>

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

0. PREAMBLE

The purpose of this License is to make a manual, textbook, or other functional and useful document *free* in the sense of freedom: to assure everyone the effective freedom to copy and redistribute it, with or without modifying it, either commercially or non-commercially. Secondly, this License preserves for the author and publisher a way to get credit for their work, while not being considered responsible for modifications made by others.

This License is a kind of “copyleft”, which means that derivative works of the document must themselves be free in the same sense. It complements the GNU General Public License, which is a copyleft license designed for free software.

We have designed this License in order to use it for manuals for free software, because free software needs free documentation: a free program should come with manuals providing the same freedoms that the software does. But this License is not limited to software manuals; it can be used for any textual work, regardless of subject matter or whether it is published as a printed book. We recommend this License principally for works whose purpose is instruction or reference.

1. APPLICABILITY AND DEFINITIONS

This License applies to any manual or other work, in any medium, that contains a notice placed by the copyright holder saying it can be distributed under the terms of this License. Such a notice grants a world-wide, royalty-free license, unlimited in duration, to use that work under the conditions stated herein. The “Document”, below, refers to any such manual or work. Any member of the public is a licensee, and is addressed as “you”. You accept the license if you copy, modify or distribute the work in a way requiring permission under copyright law.

A “Modified Version” of the Document means any work containing the Document or a portion of it, either copied verbatim, or with modifications and/or translated into another language.

A “Secondary Section” is a named appendix or a front-matter section of the Document that deals exclusively with the relationship of the publishers or authors of the Document to the Document’s overall subject (or to related matters) and contains nothing that could fall directly within that overall subject. (Thus, if the Document is in part a textbook of mathematics, a Secondary Section may not explain any mathematics.) The relationship could be a matter of historical connection with the subject or with related matters, or of legal, commercial, philosophical, ethical or political position regarding them.

The “Invariant Sections” are certain Secondary Sections whose titles are designated, as being those of Invariant Sections, in the notice that says that the Document is released

under this License. If a section does not fit the above definition of Secondary then it is not allowed to be designated as Invariant. The Document may contain zero Invariant Sections. If the Document does not identify any Invariant Sections then there are none.

The “Cover Texts” are certain short passages of text that are listed, as Front-Cover Texts or Back-Cover Texts, in the notice that says that the Document is released under this License. A Front-Cover Text may be at most 5 words, and a Back-Cover Text may be at most 25 words.

A “Transparent” copy of the Document means a machine-readable copy, represented in a format whose specification is available to the general public, that is suitable for revising the document straightforwardly with generic text editors or (for images composed of pixels) generic paint programs or (for drawings) some widely available drawing editor, and that is suitable for input to text formatters or for automatic translation to a variety of formats suitable for input to text formatters. A copy made in an otherwise Transparent file format whose markup, or absence of markup, has been arranged to thwart or discourage subsequent modification by readers is not Transparent. An image format is not Transparent if used for any substantial amount of text. A copy that is not “Transparent” is called “Opaque”.

Examples of suitable formats for Transparent copies include plain ASCII without markup, Texinfo input format, LaTeX input format, SGML or XML using a publicly available DTD, and standard-conforming simple HTML, PostScript or PDF designed for human modification. Examples of transparent image formats include PNG, XCF and JPG. Opaque formats include proprietary formats that can be read and edited only by proprietary word processors, SGML or XML for which the DTD and/or processing tools are not generally available, and the machine-generated HTML, PostScript or PDF produced by some word processors for output purposes only.

The “Title Page” means, for a printed book, the title page itself, plus such following pages as are needed to hold, legibly, the material this License requires to appear in the title page. For works in formats which do not have any title page as such, “Title Page” means the text near the most prominent appearance of the work’s title, preceding the beginning of the body of the text.

The “publisher” means any person or entity that distributes copies of the Document to the public.

A section “Entitled XYZ” means a named subunit of the Document whose title either is precisely XYZ or contains XYZ in parentheses following text that translates XYZ in another language. (Here XYZ stands for a specific section name mentioned below, such as “Acknowledgements”, “Dedications”, “Endorsements”, or “History”.) To “Preserve the Title” of such a section when you modify the Document means that it remains a section “Entitled XYZ” according to this definition.

The Document may include Warranty Disclaimers next to the notice which states that this License applies to the Document. These Warranty Disclaimers are considered to be included by reference in this License, but only as regards disclaiming warranties: any other implication that these Warranty Disclaimers may have is void and has no effect on the meaning of this License.

2. VERBATIM COPYING

You may copy and distribute the Document in any medium, either commercially or noncommercially, provided that this License, the copyright notices, and the license notice saying this License applies to the Document are reproduced in all copies, and that you add no other conditions whatsoever to those of this License. You may not use technical measures to obstruct or control the reading or further copying of the copies you make or distribute. However, you may accept compensation in exchange for copies. If you distribute a large enough number of copies you must also follow the conditions in section 3.

You may also lend copies, under the same conditions stated above, and you may publicly display copies.

3. COPYING IN QUANTITY

If you publish printed copies (or copies in media that commonly have printed covers) of the Document, numbering more than 100, and the Document's license notice requires Cover Texts, you must enclose the copies in covers that carry, clearly and legibly, all these Cover Texts: Front-Cover Texts on the front cover, and Back-Cover Texts on the back cover. Both covers must also clearly and legibly identify you as the publisher of these copies. The front cover must present the full title with all words of the title equally prominent and visible. You may add other material on the covers in addition. Copying with changes limited to the covers, as long as they preserve the title of the Document and satisfy these conditions, can be treated as verbatim copying in other respects.

If the required texts for either cover are too voluminous to fit legibly, you should put the first ones listed (as many as fit reasonably) on the actual cover, and continue the rest onto adjacent pages.

If you publish or distribute Opaque copies of the Document numbering more than 100, you must either include a machine-readable Transparent copy along with each Opaque copy, or state in or with each Opaque copy a computer-network location from which the general network-using public has access to download using public-standard network protocols a complete Transparent copy of the Document, free of added material. If you use the latter option, you must take reasonably prudent steps, when you begin distribution of Opaque copies in quantity, to ensure that this Transparent copy will remain thus accessible at the stated location until at least one year after the last time you distribute an Opaque copy (directly or through your agents or retailers) of that edition to the public.

It is requested, but not required, that you contact the authors of the Document well before redistributing any large number of copies, to give them a chance to provide you with an updated version of the Document.

4. MODIFICATIONS

You may copy and distribute a Modified Version of the Document under the conditions of sections 2 and 3 above, provided that you release the Modified Version under precisely this License, with the Modified Version filling the role of the Document, thus licensing distribution and modification of the Modified Version to whoever possesses a copy of it. In addition, you must do these things in the Modified Version:

- A. Use in the Title Page (and on the covers, if any) a title distinct from that of the Document, and from those of previous versions (which should, if there were any,

- be listed in the History section of the Document). You may use the same title as a previous version if the original publisher of that version gives permission.
- B. List on the Title Page, as authors, one or more persons or entities responsible for authorship of the modifications in the Modified Version, together with at least five of the principal authors of the Document (all of its principal authors, if it has fewer than five), unless they release you from this requirement.
 - C. State on the Title page the name of the publisher of the Modified Version, as the publisher.
 - D. Preserve all the copyright notices of the Document.
 - E. Add an appropriate copyright notice for your modifications adjacent to the other copyright notices.
 - F. Include, immediately after the copyright notices, a license notice giving the public permission to use the Modified Version under the terms of this License, in the form shown in the Addendum below.
 - G. Preserve in that license notice the full lists of Invariant Sections and required Cover Texts given in the Document's license notice.
 - H. Include an unaltered copy of this License.
 - I. Preserve the section Entitled "History", Preserve its Title, and add to it an item stating at least the title, year, new authors, and publisher of the Modified Version as given on the Title Page. If there is no section Entitled "History" in the Document, create one stating the title, year, authors, and publisher of the Document as given on its Title Page, then add an item describing the Modified Version as stated in the previous sentence.
 - J. Preserve the network location, if any, given in the Document for public access to a Transparent copy of the Document, and likewise the network locations given in the Document for previous versions it was based on. These may be placed in the "History" section. You may omit a network location for a work that was published at least four years before the Document itself, or if the original publisher of the version it refers to gives permission.
 - K. For any section Entitled "Acknowledgements" or "Dedications", Preserve the Title of the section, and preserve in the section all the substance and tone of each of the contributor acknowledgements and/or dedications given therein.
 - L. Preserve all the Invariant Sections of the Document, unaltered in their text and in their titles. Section numbers or the equivalent are not considered part of the section titles.
 - M. Delete any section Entitled "Endorsements". Such a section may not be included in the Modified Version.
 - N. Do not retitle any existing section to be Entitled "Endorsements" or to conflict in title with any Invariant Section.
 - O. Preserve any Warranty Disclaimers.

If the Modified Version includes new front-matter sections or appendices that qualify as Secondary Sections and contain no material copied from the Document, you may at your option designate some or all of these sections as invariant. To do this, add their

titles to the list of Invariant Sections in the Modified Version's license notice. These titles must be distinct from any other section titles.

You may add a section Entitled "Endorsements", provided it contains nothing but endorsements of your Modified Version by various parties—for example, statements of peer review or that the text has been approved by an organization as the authoritative definition of a standard.

You may add a passage of up to five words as a Front-Cover Text, and a passage of up to 25 words as a Back-Cover Text, to the end of the list of Cover Texts in the Modified Version. Only one passage of Front-Cover Text and one of Back-Cover Text may be added by (or through arrangements made by) any one entity. If the Document already includes a cover text for the same cover, previously added by you or by arrangement made by the same entity you are acting on behalf of, you may not add another; but you may replace the old one, on explicit permission from the previous publisher that added the old one.

The author(s) and publisher(s) of the Document do not by this License give permission to use their names for publicity for or to assert or imply endorsement of any Modified Version.

5. COMBINING DOCUMENTS

You may combine the Document with other documents released under this License, under the terms defined in section 4 above for modified versions, provided that you include in the combination all of the Invariant Sections of all of the original documents, unmodified, and list them all as Invariant Sections of your combined work in its license notice, and that you preserve all their Warranty Disclaimers.

The combined work need only contain one copy of this License, and multiple identical Invariant Sections may be replaced with a single copy. If there are multiple Invariant Sections with the same name but different contents, make the title of each such section unique by adding at the end of it, in parentheses, the name of the original author or publisher of that section if known, or else a unique number. Make the same adjustment to the section titles in the list of Invariant Sections in the license notice of the combined work.

In the combination, you must combine any sections Entitled "History" in the various original documents, forming one section Entitled "History"; likewise combine any sections Entitled "Acknowledgements", and any sections Entitled "Dedications". You must delete all sections Entitled "Endorsements."

6. COLLECTIONS OF DOCUMENTS

You may make a collection consisting of the Document and other documents released under this License, and replace the individual copies of this License in the various documents with a single copy that is included in the collection, provided that you follow the rules of this License for verbatim copying of each of the documents in all other respects.

You may extract a single document from such a collection, and distribute it individually under this License, provided you insert a copy of this License into the extracted document, and follow this License in all other respects regarding verbatim copying of that document.

7. AGGREGATION WITH INDEPENDENT WORKS

A compilation of the Document or its derivatives with other separate and independent documents or works, in or on a volume of a storage or distribution medium, is called an “aggregate” if the copyright resulting from the compilation is not used to limit the legal rights of the compilation’s users beyond what the individual works permit. When the Document is included in an aggregate, this License does not apply to the other works in the aggregate which are not themselves derivative works of the Document.

If the Cover Text requirement of section 3 is applicable to these copies of the Document, then if the Document is less than one half of the entire aggregate, the Document’s Cover Texts may be placed on covers that bracket the Document within the aggregate, or the electronic equivalent of covers if the Document is in electronic form. Otherwise they must appear on printed covers that bracket the whole aggregate.

8. TRANSLATION

Translation is considered a kind of modification, so you may distribute translations of the Document under the terms of section 4. Replacing Invariant Sections with translations requires special permission from their copyright holders, but you may include translations of some or all Invariant Sections in addition to the original versions of these Invariant Sections. You may include a translation of this License, and all the license notices in the Document, and any Warranty Disclaimers, provided that you also include the original English version of this License and the original versions of those notices and disclaimers. In case of a disagreement between the translation and the original version of this License or a notice or disclaimer, the original version will prevail.

If a section in the Document is Entitled “Acknowledgements”, “Dedications”, or “History”, the requirement (section 4) to Preserve its Title (section 1) will typically require changing the actual title.

9. TERMINATION

You may not copy, modify, sublicense, or distribute the Document except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense, or distribute it is void, and will automatically terminate your rights under this License.

However, if you cease all violation of this License, then your license from a particular copyright holder is reinstated (a) provisionally, unless and until the copyright holder explicitly and finally terminates your license, and (b) permanently, if the copyright holder fails to notify you of the violation by some reasonable means prior to 60 days after the cessation.

Moreover, your license from a particular copyright holder is reinstated permanently if the copyright holder notifies you of the violation by some reasonable means, this is the first time you have received notice of violation of this License (for any work) from that copyright holder, and you cure the violation prior to 30 days after your receipt of the notice.

Termination of your rights under this section does not terminate the licenses of parties who have received copies or rights from you under this License. If your rights have been terminated and not permanently reinstated, receipt of a copy of some or all of the same material does not give you any rights to use it.

10. FUTURE REVISIONS OF THIS LICENSE

The Free Software Foundation may publish new, revised versions of the GNU Free Documentation License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns. See <http://www.gnu.org/copyleft/>.

Each version of the License is given a distinguishing version number. If the Document specifies that a particular numbered version of this License “or any later version” applies to it, you have the option of following the terms and conditions either of that specified version or of any later version that has been published (not as a draft) by the Free Software Foundation. If the Document does not specify a version number of this License, you may choose any version ever published (not as a draft) by the Free Software Foundation. If the Document specifies that a proxy can decide which future versions of this License can be used, that proxy’s public statement of acceptance of a version permanently authorizes you to choose that version for the Document.

11. RELICENSING

“Massive Multiauthor Collaboration Site” (or “MMC Site”) means any World Wide Web server that publishes copyrightable works and also provides prominent facilities for anybody to edit those works. A public wiki that anybody can edit is an example of such a server. A “Massive Multiauthor Collaboration” (or “MMC”) contained in the site means any set of copyrightable works thus published on the MMC site.

“CC-BY-SA” means the Creative Commons Attribution-Share Alike 3.0 license published by Creative Commons Corporation, a not-for-profit corporation with a principal place of business in San Francisco, California, as well as future copyleft versions of that license published by that same organization.

“Incorporate” means to publish or republish a Document, in whole or in part, as part of another Document.

An MMC is “eligible for relicensing” if it is licensed under this License, and if all works that were first published under this License somewhere other than this MMC, and subsequently incorporated in whole or in part into the MMC, (1) had no cover texts or invariant sections, and (2) were thus incorporated prior to November 1, 2008.

The operator of an MMC Site may republish an MMC contained in the site under CC-BY-SA on the same site at any time before August 1, 2009, provided the MMC is eligible for relicensing.

ADDENDUM: How to use this License for your documents

To use this License in a document you have written, include a copy of the License in the document and put the following copyright and license notices just after the title page:

```
Copyright (C)  year  your name.
Permission is granted to copy, distribute and/or modify this document
under the terms of the GNU Free Documentation License, Version 1.3
or any later version published by the Free Software Foundation;
with no Invariant Sections, no Front-Cover Texts, and no Back-Cover
Texts. A copy of the license is included in the section entitled ‘‘GNU
Free Documentation License’’.
```

If you have Invariant Sections, Front-Cover Texts and Back-Cover Texts, replace the “with...Texts.” line with this:

```
with the Invariant Sections being list their titles, with
the Front-Cover Texts being list, and with the Back-Cover Texts
being list.
```

If you have Invariant Sections without Cover Texts, or some other combination of the three, merge those two alternatives to suit the situation.

If your document contains nontrivial examples of program code, we recommend releasing these examples in parallel under your choice of free software license, such as the GNU General Public License, to permit their use in free software.

LD Index

"		
"	70	
-		
-(.....	14	
--accept-unknown-input-arch	14	
--add-needed	14	
--add-stdcall-alias	29	
--allow-multiple-definition	19	
--allow-shlib-undefined	19	
--architecture=arch	4	
--as-needed	14	
--audit AUDITLIB	4	
--auxiliary=name	7	
--bank-window	36	
--base-file	29	
--be8	81	
--bss-plt	85	
--build-id	28	
--build-id=style	28	
--check-sections	16	
--copy-dt-needed-entries	16	
--cref	16	
--default-imported-symver	19	
--default-script=script	11	
--default-symver	19	
--defsym=symbol=exp	17	
--demangle[=style]	17	
--depaudit AUDITLIB	5	
--disable-auto-image-base	32	
--disable-auto-import	34	
--disable-long-section-names	29	
--disable-new-dtags	27	
--disable-runtime-pseudo-reloc	34	
--disable-stdcall-fixup	29	
--discard-all	12	
--discard-locals	12	
--dll	29	
--dll-search-prefix	32	
--dotsyms	86	
--dsbt-index	36	
--dsbt-size	36	
--dynamic-linker=file	17	
--dynamic-list-cpp-new	16	
--dynamic-list-cpp-typeinfo	16	
--dynamic-list-data	16	
--dynamic-list=dynamic-list-file	15	
--dynamicbase	35	
--eh-frame-hdr	27	
--emit-relocs	10	
--emit-stack-syms	88	
--emit-stub-syms	85, 86, 87	
--enable-auto-image-base	32	
--enable-auto-import	32	
--enable-extra-pe-debug	34	
--enable-long-section-names	29	
--enable-new-dtags	27	
--enable-runtime-pseudo-reloc	34	
--enable-stdcall-fixup	29	
--entry=entry	5	
--error-unresolved-symbols	26	
--exclude-all-symbols	30	
--exclude-libs	6	
--exclude-modules-for-implib	6	
--exclude-symbols	30	
--export-all-symbols	30	
--export-dynamic	6	
--extra-overlay-stubs	88	
--fatal-warnings	17	
--file-alignment	30	
--filter=name	7	
--fix-arm1176	82	
--fix-cortex-a8	80	
--fix-v4bx	81	
--fix-v4bx-interworking	81	
--force-dynamic	10	
--force-exe-suffix	17	
--forceinteg	35	
--format=format	5	
--format=version	88	
--gc-sections	18	
--got	36	
--got=type	83	
--gpsize=value	7	
--hash-size=number	28	
--hash-style=style	28	
--heap	30	
--help	18	
--image-base	30	
--just-symbols=file	11	
--kill-at	31	
--large-address-aware	31	
--ld-generated-unwind-info	27	
--leading-underscore	30	
--library-path=dir	8	
--library=namespec	8	
--local-store=lo:hi	88	
--major-image-version	31	
--major-os-version	31	
--major-subsystem-version	31	
--merge-exidx-entries	80	
--minor-image-version	31	
--minor-os-version	31	
--minor-subsystem-version	31	
--mri-script=MRI-cmdfile	5	
--multi-subspace	83	
--nmagic	10	
--no-accept-unknown-input-arch	14	

--no-add-needed.....	14	'--relax' on i960.....	80
--no-allow-shlib-undefined.....	19	--relax on PowerPC.....	84
--no-as-needed.....	14	'--relax' on Xtensa.....	96
--no-bind.....	35	--relocatable.....	10
--no-check-sections.....	16	--retain-symbols-file=filename.....	21
--no-copy-dt-needed-entries.....	16	--script=script.....	11
--no-define-common.....	17	--sdata-got.....	85
--no-demangle.....	17	--section-alignment.....	34
--no-dotsyms.....	86	--section-start=sectionname=org.....	23
--no-enum-size-warning.....	82	--secure-plt.....	85
--no-export-dynamic.....	6	--sort-common.....	22
--no-fatal-warnings.....	17	--sort-section=alignment.....	23
--no-fix-arm1176.....	82	--sort-section=name.....	23
--no-fix-cortex-a8.....	80	--split-by-file.....	23
--no-gc-sections.....	18	--split-by-reloc.....	23
--no-isolation.....	35	--stack.....	35
--no-keep-memory.....	18	--stack-analysis.....	88
--no-leading-underscore.....	30	--stats.....	23
--no-merge-exidx-entries.....	36, 80	--strip-all.....	11
--no-multi-toc.....	86	--strip-debug.....	11
--no-omagic.....	10	--stub-group-size.....	85
--no-opd-optimize.....	86	--stub-group-size=N.....	82, 83
--no-overlays.....	87	--subsystem.....	35
--no-plt-align.....	87	--support-old-code.....	80
--no-plt-static-chain.....	87	--sysroot=directory.....	23
--no-plt-thread-safe.....	87	--target-help.....	18
--no-print-gc-sections.....	18	--target1-abs.....	81
--no-relax.....	20	--target1-rel.....	81
--no-seh.....	35	--target2=type.....	81
--no-tls-optimize.....	85, 86	--thumb-entry=entry.....	81
--no-toc-optimize.....	86	--trace.....	11
--no-toc-sort.....	87	--trace-symbol=symbol.....	12
--no-trampoline.....	36	--traditional-format.....	23
--no-undefined.....	19	--tsaware.....	35
--no-undefined-version.....	19	--undefined=symbol.....	11
--no-warn-mismatch.....	19	--unique[=SECTION].....	12
--no-warn-search-mismatch.....	20	--unresolved-symbols.....	24
--no-wchar-size-warning.....	82	--use-blx.....	81
--no-whole-archive.....	20	--use-nul-prefixed-import-tables.....	81
--noinhibit-exec.....	20	--verbose[=NUMBER].....	24
--non-overlapping-opd.....	86	--version.....	12
--nxcompat.....	35	--version-script=version-scriptfile.....	24
--oformat=output-format.....	20	--vfp11-denorm-fix.....	82
--omagic.....	10	--warn-alternate-em.....	26
--out-implib.....	31	--warn-common.....	25
--output-def.....	31	--warn-constructors.....	26
--output=output.....	10	--warn-multiple-gp.....	26
--pic-executable.....	20	--warn-once.....	26
--pic-veneer.....	82	--warn-section-align.....	26
--plt-align.....	87	--warn-shared-textrel.....	26
--plt-static-chain.....	87	--warn-unresolved-symbols.....	26
--plt-thread-safe.....	87	--wdmdriver.....	35
--plugin.....	87	--whole-archive.....	26
--print-gc-sections.....	18	--wrap=symbol.....	27
--print-map.....	9	-A arch.....	4
--print-output-format.....	18	-a keyword.....	4
--reduce-memory-overheads.....	28	-assert keyword.....	15
--relax.....	20	-b format.....	5

-Bdynamic.....	15	-Ttext=org	23
-Bgroup	15	-u symbol	11
-Bshareable	22	-Ur	12
-Bstatic	15	-v	12
-Bsymbolic	15	-V	12
-Bsymbolic-functions	15	-x	12
-c MRI-cmdfile	5	-X	12
-call_shared	15	-Y path	12
-d	5	-y symbol	12
-dc	5	-z defs	19
-dn	15	-z keyword	12
-dp	5	-z muldefs	19
-dT script	11		
-dy	15	.	
-E	6	70
-e entry	5		
-EB	7	/	
-EL	7	/DISCARD/	58
-f name	7		
-F name	7	:	
-fini=name	7	:phdr	61
-g	7		
-G value	7	=	
-h name	8	=fillexp	61
-i	8		
-Ifile	17	>	
-init=name	8	>region	61
-L dir	8		
-l namespec	8	[
-M	9	[COMMON]	55
-m emulation	9		
-Map=mapfile	18	A	
-n	10	ABSOLUTE (MRI)	105
-N	10	absolute and relocatable symbols	73
-non_shared	15	absolute expressions	73
-nostdlib	20	ABSOLUTE(exp)	75
-O level	10	ADDR(section)	75
-o output	10	address, section	51
-P AUDITLIB	5	ALIAS (MRI)	105
-pie	20	ALIGN (MRI)	105
-q	10	align expression	75
-qmagic	20	align location counter	75
-Qy	20	ALIGN(align)	75
-r	10	ALIGN(exp,align)	75
-R file	11	ALIGN(section_align)	60
-rpath-link=dir	21	aligned common symbols	95
-rpath=dir	21	ALIGNOF(section)	76
-s	11	allocating memory	63
-S	11	architecture	47
-shared	22	architectures	4
-soname=name	8	archive files, from cmd line	8
-static	15		
-t	11		
-T script	11		
-Tbss=org	23		
-Tdata=org	23		
-Tdata-segment=org	24		
-Ttext-segment=org	24		

archive search path in linker script	42
arithmetic	69
arithmetic operators	72
ARM interworking support	80
ARM1176 erratum workaround	82
AS_NEEDED(<i>files</i>)	42
ASSERT	46
assertion in linker script	46
assignment in scripts	47
AT(<i>lma</i>)	59
AT> <i>lma_region</i>	59
automatic data imports	92

B

back end	97
BASE (MRI)	105
BE8	81
BFD canonical format	98
BFD requirements	97
big-endian objects	7
binary input format	5
BLOCK(<i>exp</i>)	76
bug criteria	101
bug reports	101
bugs in ld	101
BYTE(<i>expression</i>)	56

C

C++ constructors, arranging in link	57
CHIP (MRI)	105
COLLECT_NO_DEMANGLE	37
combining symbols, warnings on	25
command files	39
command line	3
common allocation	5, 17
common allocation in linker script	46
common symbol placement	55
COMMONPAGESIZE	70
compatibility, MRI	5
CONSTANT	70
constants in linker scripts	69
constraints on output sections	61
constructors	12
CONSTRUCTORS	57
constructors, arranging in link	57
Cortex-A8 erratum workaround	80
crash of linker	101
CREATE_OBJECT_SYMBOLS	57
creating a DEF file	91
cross reference table	16
cross references	46
current output location	70

D

data	56
------------	----

DATA_SEGMENT_ALIGN(<i>maxpagesize</i> , <i>commonpagesize</i>)	76
DATA_SEGMENT_END(<i>exp</i>)	76
DATA_SEGMENT_RELRO_END(<i>offset</i> , <i>exp</i>)	76
dbx	23
DEF files, creating	31
default emulation	36
default input format	36
DEFINED(<i>symbol</i>)	77
deleting local symbols	12
demangling, default	37
demangling, from command line	17
direct linking to a dll	92
discarding sections	58
discontinuous memory	63
DLLs, creating	30, 31
DLLs, linking to	32
dot	70
dot inside sections	71
dot outside sections	71
dynamic linker, from command line	17
dynamic symbol table	6

E

ELF program headers	64
emulation	9
emulation, default	36
END (MRI)	105
endianness	7
entry point	41
entry point, from command line	5
entry point, thumb	81
ENTRY(<i>symbol</i>)	41
error on valid input	101
example of linker script	40
exporting DLL symbols	89
expression evaluation order	73
expression sections	73
expression, absolute	75
expressions	69
EXTERN	46

F

fatal signal	101
file name wildcard patterns	54
FILEHDR	65
filename symbols	57
fill pattern, entire section	61
FILL(<i>expression</i>)	57
finalization function	7
first input file	43
first instruction	41
FIX_V4BX	81
FIX_V4BX_INTERWORKING	81
FORCE_COMMON_ALLOCATION	46
forcing input section alignment	60

forcing output section alignment	60
forcing the creation of dynamic sections	10
FORMAT (MRI)	105
functions in expressions	75

G

garbage collection	18, 56
generating optimized output	10
GNU linker	1
GNUTARGET	36
GROUP (<i>files</i>)	42
grouping input files	42
groups of archives	14

H

H8/300 support	79
header size	78
heap size	30
help	18
HIDDEN	48
holes	70
holes, filling	57
HPPA multiple sub-space stubs	83
HPPA stub grouping	83

I

i960 support	79
image base	30
implicit linker scripts	78
import libraries	88
INCLUDE <i>filename</i>	41
including a linker script	41
including an entire archive	26
incremental link	8
INHIBIT_COMMON_ALLOCATION	46
initialization function	8
initialized data in ROM	60
input file format in linker script	43
input filename symbols	57
input files in linker scripts	42
input files, displaying	11
input format	5
input object files in linker scripts	42
input section alignment	60
input section basics	52
input section wildcards	54
input sections	52
INPUT (<i>files</i>)	42
INSERT	46
insert user script into default script	46
integer notation	69
integer suffixes	69
internal object-file format	98
invalid input	101

K

K and M integer suffixes	69
KEEP	56

L

l =	64
lazy evaluation	73
ld bugs, reporting	101
LD_FEATURE (<i>string</i>)	47
LDDEMULATION	36
len =	64
LENGTH =	64
LENGTH (<i>memory</i>)	77
library search path in linker script	42
link map	9
link-time runtime library search path	21
linker crash	101
linker script concepts	39
linker script example	40
linker script file commands	41
linker script format	40
linker script input object files	42
linker script simple commands	41
linker scripts	39
LIST (MRI)	106
little-endian objects	7
LOAD (MRI)	106
load address	59
LOADADDR (<i>section</i>)	77
loading, preventing	59
local symbols, deleting	12
location counter	70
LONG (<i>expression</i>)	56

M

M and K integer suffixes	69
M68HC11 and 68HC12 support	80
machine architecture	47
machine dependencies	79
mapping input sections to output sections	52
MAX	77
MAXPAGESIZE	70
MEMORY	63
memory region attributes	63
memory regions	63
memory regions and sections	61
memory usage	18
MIN	77
Motorola 68K GOT generation	83
MRI compatibility	105
MSP430 extra sections	84

N

NAME (MRI)	106
name, section	51

names	70
naming the output file	10
NEXT(<i>exp</i>)	77
NMAGIC	10
NO_ENUM_SIZE_WARNING	82
NO_WCHAR_SIZE_WARNING	82
NOCROSSREFS(<i>sections</i>)	46
NOLOAD	59
not enough room for program headers	78

O

o =	64
objdump -i	97
object file management	97
object files	3
object formats available	97
object size	7
OMAGIC	10
ONLY_IF_RO	61
ONLY_IF_RW	61
opening object files	97
operators for arithmetic	72
options	3
ORDER (MRI)	106
org =	64
ORIGIN =	64
ORIGIN(<i>memory</i>)	77
orphan	70
output file after errors	20
output file format in linker script	43
output file name in linker script	42
output format	18
output section alignment	60
output section attributes	59
output section data	56
OUTPUT(<i>filename</i>)	42
OUTPUT_ARCH(<i>bfdarch</i>)	47
OUTPUT_FORMAT(<i>bfdname</i>)	43
OVERLAY	61
overlays	61

P

partial link	10
PE import table prefixing	81
PHDRS	64, 65
PIC_VENEER	82
position independent executables	20
PowerPC ELF32 options	85
PowerPC GOT	85
PowerPC long branches	84
PowerPC PLT	85
PowerPC stub symbols	85
PowerPC TLS optimization	85
PowerPC64 dot symbols	86
PowerPC64 ELF64 options	85
PowerPC64 multi-TOC	86

PowerPC64 OPD optimization	86
PowerPC64 OPD spacing	86
PowerPC64 PLT call stub static chain	87
PowerPC64 PLT call stub thread safety	87
PowerPC64 PLT stub alignment	87
PowerPC64 stub grouping	85
PowerPC64 stub symbols	86
PowerPC64 TLS optimization	86
PowerPC64 TOC optimization	86
PowerPC64 TOC sorting	87
precedence in expressions	72
prevent unnecessary loading	59
program headers	64
program headers and sections	61
program headers, not enough room	78
program segments	64
PROVIDE	48
PROVIDE_HIDDEN	49
PUBLIC (MRI)	106

Q

QUAD(<i>expression</i>)	56
quoted symbol names	70

R

read-only text	10
read/write from cmd line	10
region alias	43
region names	43
REGION_ALIAS(<i>alias</i> , <i>region</i>)	43
regions of memory	63
relative expressions	73
relaxing addressing modes	20
relaxing on H8/300	79
relaxing on i960	80
relaxing on M68HC11	80
relaxing on Xtensa	96
relocatable and absolute symbols	73
relocatable output	10
removing sections	58
reporting bugs in ld	101
requirements for BFD	97
retain relocations in final executable	10
retaining specified symbols	21
rodata segment origin, cmd line	24
ROM initialized data	60
round up expression	75
round up location counter	75
runtime library name	8
runtime library search path	21
runtime pseudo-relocation	92

S

scaled integers	69
scommon section	55

script files	11
scripts	39
search directory, from cmd line	8
search path in linker script	42
SEARCH_DIR(<i>path</i>)	42
SECT (MRI)	106
section address	51
section address in expression	75
section alignment	76
section alignment, warnings on	26
section data	56
section fill pattern	61
section load address	59
section load address in expression	77
section name	51
section name wildcard patterns	54
section size	77
section, assigning to memory region	61
section, assigning to program header	61
SECTIONS	50
sections, discarding	58
segment origins, cmd line	23
SEGMENT_START(<i>segment</i> , <i>default</i>)	77
segments, ELF	64
shared libraries	22
SHORT(<i>expression</i>)	56
SIZEOF(<i>section</i>)	77
SIZEOF_HEADERS	78
small common symbols	55
SORT	54
SORT_BY_ALIGNMENT	54
SORT_BY_INIT_PRIORITY	54
SORT_BY_NAME	54
SORT_NONE	55
SPU	88
SPU ELF options	87
SPU extra overlay stubs	88
SPU local store size	88
SPU overlay stub symbols	87
SPU overlays	87
SPU plugins	87
SQUAD(<i>expression</i>)	56
stack size	35
standard Unix system	3
start of execution	41
STARTUP(<i>filename</i>)	43
strip all symbols	11
strip debugger symbols	11
stripping all but some symbols	21
STUB_GROUP_SIZE	82
SUBALIGN(<i>subsection_align</i>)	60
suffixes for integers	69
symbol defaults	77
symbol definition, scripts	47
symbol names	70
symbol tracing	12
symbol versions	66
symbol-only input	11

symbolic constants	70
symbols, from command line	17
symbols, relocatable and absolute	73
symbols, retaining selectively	21
synthesizing linker	20
synthesizing on H8/300	79

T

TARGET(<i>bfdname</i>)	43
TARGET1	81
TARGET2	81
text segment origin, cmd line	24
thumb entry point	81
TI COFF versions	88
traditional format	23
trampoline generation on M68HC11	80
trampoline generation on M68HC12	80

U

unallocated address, next	77
undefined symbol	11
undefined symbol in linker script	46
undefined symbols, warnings on	26
uninitialized data placement	55
unspecified memory	57
usage	18
USE_BLX	81
using a DEF file	89
using auto-export functionality	89
Using decorations	91

V

variables, defining	47
verbose[= <i>NUMBER</i>]	24
version	12
VERSION { <i>script text</i> }	66
version script	66
version script, symbol versions	24
versions of symbols	66
VFP11_DENORM_FIX	82

W

warnings, on combining symbols	25
warnings, on section alignment	26
warnings, on undefined symbols	26
weak externals	95
what is this?	1
wildcard file name patterns	54

X

Xtensa options	96
Xtensa processors	96

The body of this manual is set in
cmr10 at 10.95pt,
with headings in **cmb10 at 10.95pt**
and examples in cmtt10 at 10.95pt.
cmti10 at 10.95pt and
cmsl10 at 10.95pt
are used for emphasis.